

Programming Instructions: OGRE v2, when newly manufactured, can only be interfaced with a SWD/JTAG.

Within the SWD/JTAG environment, execute the following:

Setup: Apply power to PCB by connecting 5V source to 5V pin, and ground to GND pin (see attached photo).

Connect J-Link to the target device via SWD interface at 4000 kHz

Verify target voltage is present before attempting connection — if you see "Target voltage too low," check power to the device and retry.

In J-Link Commander on your computer, connect to device AMA3B1KK-KQR

Run the following command:**

loadbin <OGRE2.ino.bin> 0x0000C000

A successful flash will show:

J-Link: Flash download: Program & Verify speed: ~150 KB/s
O.K.

*note to user: replace OGRE2.ino.bin with any compiled Arduino script. For example, upload svl.bin from Sparkfun instead if you want to enable serial programmability to your device. Afterwards, you can upload any Arduino script using the serial interface instead of SWD

(https://github.com/sparkfun/Apollo3_Uploader_SVL/tree/main/bootloader/gcc/artemis_module/bin)

