

LROBRUYA

ESP32 Basic Starter Kit

LROBRUYA

Wireless Control





Content

Preface	4
Kit List	5
ESP32 Introduction	6
ESP32 Arduino IDE	23
Project 1 ESP32 Hello World	33
Project 2 ESP32 Inputs Outputs	36
Project 3 ESP32 Analog Inputs	42
Project 4 ESP32 PWM(Analog Output)	49
Project 5 ESP32 RGB LED	55
Project 6 ESP32 PIR Motion Sensor	59
Project 7 ESP32 Switch Web Server	64
Project 8 RGB LED Web Server	82
Project 9 ESP32 Relay Web Server	92
Project 10 Output State Synchronization Web Server	102
Project 11 ESP32 DHT11 Web Server	113
Project 12 ESP32_OLED_Display	124



Preface

Company Profile

Founded in 2014, Shenzhen Lonten Technology Co., Ltd. focuses on the design, research production of Electronics Module for robotics related products. Consisting of professional researchers and skilled engineers, our R&D team constantly strives for creative function and excellent user experience. The company's R&D investments on arduino kits raspberry pi kits, as well as 3D printer and robots that back up STEAM education.

Customer Service

Our self-owned factory is certificated with BSCI and SO, covering an area of 5,000 square meters, and achieving an annual production capacity of over 10,000 units. Our products are all certified to CE, FCC, and ROHS standards, have exported to more than 100 countries including, but not limited to France, the United States of America, Australia, Russia, the United Kingdom, Germany, Singapore, Egypt, and India, bringing technological innovation to all walks of life.

Tutorial

This tutorial include codes, libraries and detailed user documentation. It is designed for beginners. You will learn all the basic knowledge about how to use ESP32 board, sensors and components.

LROBRYA

Kit List



ESP32 Development Board x1




0.96 inch OLED x1



830 Tie-Points Breadboard x1



Obstacle Avoidance Module x1



Photosensitive Resistor Module x1



DHT11 Temperature and Humidity Module x1



HC-SR501 PIR Motion Sensor x1



Potentiometer (10k) x1



Micro-USB Cable x1



Resistor-220R/1k/10k x30



Passive Buzzer x1
Active Buzzer x1



5V 2-Channel Relay Module x1



Button Switch x6



F-M DuPont Cable x10



F-F DuPont Cable x10



M-M DuPont Cable x10



LED-Red x5



LED-Yellow x5



LED-Green x5



LED-RGB x1

LROBRYA

ESP32 Introduction

New to ESP32? Start here! The ESP32 is a series of low-cost and low-power.

System on a Chip (SoC) microcontrollers developed by Espressif that include Wi-Fi and Bluetooth wireless capabilities and dual-core processor. If you're familiar with the ESP8266, the ESP32 is its successor, loaded with lots of new features.



ESP32 Specifications

If you want to get a bit more technical and specific, you can take a look at the following detailed specifications of the ESP32 (source: <http://esp32.net/>)—for more details, check the datasheet):

- Low cost: You can purchase ESP 32 from \$6, which makes it easy for



the general public to obtain it;

- Low power consumption: Compared with other microcontrollers, ESP 32 has extremely low power consumption and supports low-power mode states such as deep sleep to save electricity;
- WiFi function: ESP 32 can easily connect to a WiFi network to connect to the internet (station mode), or create its own WiFi wireless network (access point mode) so that other devices can connect to it - this is crucial for IoT and home automation projects - you can have multiple devices communicate with each other using their WiFi function; Bluetooth: ESP 32 supports classic Bluetooth and low-power Bluetooth (BLE) - suitable for various IoT applications;
- Dual Core: Most ESP 32s are dual core - they come with two Xtensa 32-bit LX6 microprocessors: core 0 And Core 1
- Rich peripheral input! Output interface - ESP 32 supports various inputs (reading data from the outside) and outputs (sending commands/signals to the outside) such as capacitive touch, ADC, DAC, UART, SPI, I2C, and peripheral devices, pulse width modulation, etc.
- Compatible with the Arduino "programming language": For those who are already familiar with Arduino board programming, you will

LROBROUYA

be happy to know that they can program ESP 32 using the Arduino style.

ESP32 Development Boards

ESP32 refers to the bare ESP32 chip. However, the “ESP32” term is also used to refer to ESP32 development boards. Using ESP32 bare chips is not easy or practical, especially when learning, testing, and prototyping.

Most of the time, you'll want to use an ESP32 development board.

We'll be using the ESP32 DEVKIT V1 board as a reference. The picture below shows the ESP32 DEVKIT V1 board, version with 30 GPIO pins.






Specifications – ESP32 DEVKIT V1

The following table shows a summary of the ESP32 DEVKIT V1 DOIT board features and specifications:

Number of cores	2 (dual core)
Wi-Fi	2.4 GHz up to 150 Mbits/s
Bluetooth	BLE (Bluetooth Low Energy) and legacy Bluetooth
Architecture	32 bits
Clock frequency	Up to 240 MHz
RAM	512 KB
Pins	30(depending on the model)

LROBRUYA

Peripherals	Capacitive touch, ADC (analog to digital converter), DAC (digital to analog converter), I2C (Inter-Integrated Circuit), UART (universal asynchronous receiver/transmitter), CAN 2.0 (Controller Area Network), SPI (Serial Peripheral Interface), I2S (Integrated Inter-IC Sound), RMII (Reduced Media-Independent Interface), PWM (pulse width modulation), and more.
Built-in buttons	RESET and BOOT buttons
Built-in LEDs	built-in blue LED connected to GPIO2; built-in red LED that shows the board is being powered
USB to UART bridge	CP2102






It comes with a microUSB interface that you can use to connect the board to your computer to upload code or apply power.

It uses the CP2102 chip (USB to UART) to communicate with your computer via a COM port using a serial interface. Another popular chip is the CH340. Check what's the USB to UART chip converter on your board because you'll need to install the required drivers so that your computer can communicate with the board.

This board also comes with a RESET button (may be labeled EN) to restart the board and a BOOT button to put the board in flashing mode (available to receive code). Note that some boards may not have a BOOT button.

It also comes with a built-in blue LED that is internally connected to GPIO 2. This LED is useful for debugging to give some sort of visual physical output. There's also a red LED that lights up when you provide power to the board.

LROBRYA



ESP32 Pinout

The ESP32 peripherals include:


- 18 Analog-to-Digital Converter (ADC) channels
- 3 SPI interfaces
- 3 UART interfaces
- 2 I2C interfaces
- 16 PWM output channels
- 2 Digital-to-Analog Converters (DAC)
- 2 I2S interfaces
- 10 Capacitive sensing GPIOs

The ADC (analog to digital converter) and DAC (digital to analog converter) features are assigned to specific static pins. However, you can decide which pins are UART, I2C, SPI, PWM, etc – you just need to assign them in the code. This is possible due to the ESP32 chip's

LROBRYA

multiplexing feature.

Although you can define the pins properties on the software, there are pins assigned by default as shown in the following figure.



Additionally, there are pins with specific features that make them suitable or not for a particular project. The following table shows what pins are best to use as inputs, outputs and which ones you need to be cautious.

The pins highlighted in green are OK to use. The ones highlighted in yellow are OK to use, but you need to pay attention because they may have an unexpected behavior mainly at boot. The pins highlighted in red are not recommended to use as inputs or outputs.

LROBRUYA

GP IO	Input	Output	Notes
0	pulled up	OK	outputs PWM signal at boot, must be LOW to enter flashing mode
1	TX pin	OK	debug output at boot
2	OK	OK	connected to on-board LED, must be left floating or LOW to enter flashing mode
3	OK	RX pin	HIGH at boot
4	OK	OK	
5	OK	OK	outputs PWM signal at boot, strapping pin
12	OK	OK	boot fails if pulled high, strapping pin
13	OK	OK	
14	OK	OK	outputs PWM signal at boot
15	OK	OK	outputs PWM signal at boot, strapping pin

LROBRYA

16	OK	OK	
17	OK	OK	
18	OK	OK	
19	OK	OK	
21	OK	OK	
22	OK	OK	
23	OK	OK	
25	OK	OK	
26	OK	OK	
27	OK	OK	
32	OK	OK	
33	OK	OK	
34	OK		input only
35	OK		input only
36	OK		input only
39	OK		input only

Continue reading for a more detail and in-depth analysis of the ESP32 GPIOs and its functions.



Input only pins

GPIOs 34 to 39 are GPIOs – input only pins. These pins don't have internal pull-up or pull-down resistors. They can't be used as outputs, so use these pins only as inputs:

- GPIO 34
- GPIO 35
- GPIO 36
- GPIO 39

SPI flash integrated on the ESP-WROOM-32

GPIO 6 to GPIO 11 are exposed in some ESP32 development boards. However, these pins are connected to the integrated SPI flash on the ESP-WROOM-32 chip and are not recommended for other uses. So, don't use these pins in your projects:

- GPIO 6 (SCK/CLK)
- GPIO 7 (SDO/SD0)
- GPIO 8 (SDI/SD1)
- GPIO 9 (SHD/SD2)
- GPIO 10 (SWP/SD3)
- GPIO 11 (CSC/CMD)

Capacitive touch GPIOs

The ESP32 has 10 internal capacitive touch sensors. These can sense variations in anything that holds an electrical charge, like the human skin. So they can detect variations induced when touching the GPIOs with a finger. These pins can be easily integrated into capacitive pads and replace mechanical buttons. The capacitive touch pins can also be used to



wake up the ESP32 from deep sleep.

Those internal touch sensors are connected to these GPIOs:

- T0 (GPIO 4)
- T1 (GPIO 0)
- T2 (GPIO 2)
- T3 (GPIO 15)
- T4 (GPIO 13)
- T5 (GPIO 12)
- T6 (GPIO 14)
- T7 (GPIO 27)
- T8 (GPIO 33)
- T9 (GPIO 32)

Analog to Digital Converter (ADC)

The ESP32 has 18 x 12 bits ADC input channels (while the ESP8266 only has 1x 10 bits ADC). These are the GPIOs that can be used as ADC and respective channels:


- ADC1_CH0 (GPIO 36)
- ADC1_CH1 (GPIO 37)
- ADC1_CH2 (GPIO 38)
- ADC1_CH3 (GPIO 39)
- ADC1_CH4 (GPIO 32)
- ADC1_CH5 (GPIO 33)
- ADC1_CH6 (GPIO 34)
- ADC1_CH7 (GPIO 35)
- ADC2_CH0 (GPIO 4)
- ADC2_CH1 (GPIO 0)
- ADC2_CH2 (GPIO 2)
- ADC2_CH3 (GPIO 15)
- ADC2_CH4 (GPIO 13)
- ADC2_CH5 (GPIO 12)
- ADC2_CH6 (GPIO 14)
- ADC2_CH7 (GPIO 27)
- ADC2_CH8 (GPIO 25)
- ADC2_CH9 (GPIO 26)

LROBRYA

Note: ADC2 pins cannot be used when Wi-Fi is used. So, if you're using Wi-Fi and you're having trouble getting the value from an ADC2 GPIO, you may consider using an ADC1 GPIO instead. That should solve your problem.

The ADC input channels have a 12-bit resolution. This means that you can get analog readings ranging from 0 to 4095, in which 0 corresponds to 0V and 4095 to 3.3V. You can also set the resolution of your channels on the code and the ADC range.

The ESP32 ADC pins don't have a linear behavior. You'll probably won't be able to distinguish between 0 and 0.1V, or between 3.2 and 3.3V. You need to keep that in mind when using the ADC pins. You'll get a behavior similar to the one shown in the following figure.





Digital to Analog Converter (DAC)

There are 2 x 8 bits DAC channels on the ESP32 to convert digital signals into analog voltage signal outputs. These are the DAC channels:

- DAC1 (GPIO25)
- DAC2 (GPIO26)

RTC GPIOs

There is RTC GPIO support on the ESP32. The GPIOs routed to the RTC low-power subsystem can be used when the ESP32 is in deep sleep.

These RTC GPIOs can be used to wake up the ESP32 from deep sleep when the Ultra Low Power (ULP) co-processor is running. The following GPIOs can be used as an external wake up source.

- RTC_GPIO0 (GPIO36)
- RTC_GPIO3 (GPIO39)
- RTC_GPIO4 (GPIO34)
- RTC_GPIO5 (GPIO35)
- RTC_GPIO6 (GPIO25)
- RTC_GPIO7 (GPIO26)
- RTC_GPIO8 (GPIO33)
- RTC_GPIO9 (GPIO32)
- RTC_GPIO10 (GPIO4)
- RTC_GPIO11 (GPIO0)
- RTC_GPIO12 (GPIO2)
- RTC_GPIO13 (GPIO15)
- RTC_GPIO14 (GPIO13)
- RTC_GPIO15 (GPIO12)
- RTC_GPIO16 (GPIO14)
- RTC_GPIO17 (GPIO27)

PWM

The ESP32 LED PWM controller has 16 independent channels that can



be configured to generate PWM signals with different properties. All pins that can act as outputs can be used as PWM pins (GPIOs 34 to 39 can't generate PWM).

To set a PWM signal, you need to define these parameters in the code:

- Signal's frequency;
- Duty cycle;
- PWM channel;
- GPIO where you want to output the signal.

I2C

The ESP32 has two I2C channels and any pin can be set as SDA or SCL.

When using the ESP32 with the Arduino IDE, the default I2C pins are:

- GPIO 21 (SDA)
- GPIO 22 (SCL)

If you want to use other pins when using the wire library, you just need to call:

```
Wire.begin(SDA, SCL);
```

SPI

By default, the pin mapping for SPI is:

SPI	MOSI	MISO	CLK	CS
VSPI	GPIO 23	GPIO 19	GPIO 18	GPIO 5
HSPI	GPIO 13	GPIO 12	GPIO 14	GPIO 15

Interrupts

All GPIOs can be configured as interrupts.



Strapping Pins

The ESP32 chip has the following strapping pins:

- GPIO 0 (must be LOW to enter boot mode)
- GPIO 2 (must be floating or LOW during boot)
- GPIO 4
- GPIO 5 (must be HIGH during boot)
- GPIO 12 (must be LOW during boot)
- GPIO 15 (must be HIGH during boot)

These are used to put the ESP32 into bootloader or flashing mode. On most development boards with built-in USB/Serial, you don't need to worry about the state of these pins. The board puts the pins in the right state for flashing or boot mode. More information on the [ESP32 Boot Mode Selection](#) can be found here.

However, if you have peripherals connected to those pins, you may have trouble trying to upload new code, flashing the ESP32 with new firmware, or resetting the board. If you have some peripherals connected to the strapping pins and you are getting trouble uploading code or flashing the ESP32, it may be because those peripherals are preventing the ESP32 from entering the right mode. Read the [Boot Mode Selection](#) documentation to guide you in the right direction. After resetting, flashing, or booting, those pins work as expected.

Pins HIGH at Boot

Some GPIOs change their state to HIGH or output PWM signals at boot



or reset.

This means that if you have outputs connected to these GPIOs you may get unexpected results when the ESP32 resets or boots.

- GPIO 1
- GPIO 3
- GPIO 5
- GPIO 6 to GPIO 11 (connected to the ESP32 integrated SPI flash memory – not recommended to use).
- GPIO 14
- GPIO 15

Enable (EN)

Enable (EN) is the 3.3V regulator's enable pin. It's pulled up, so connect to ground to disable the 3.3V regulator. This means that you can use this pin connected to a pushbutton to restart your ESP32, for example.

GPIO current drawn

The absolute maximum current drawn per GPIO is 40mA according to the “Recommended Operating Conditions” section in the ESP32 datasheet.

ESP32 Built-In Hall Effect Sensor

The ESP32 also features a built-in hall effect sensor that detects changes in the magnetic field in its surroundings



ESP32 Arduino IDE

There's an add-on for the Arduino IDE that allows you to program the ESP32 using the Arduino IDE and its programming language. In this tutorial we'll show you how to install the ESP32 board in Arduino IDE whether you're using Windows, Mac OS X or Linux.

Prerequisites: Arduino IDE Installed

Before starting this installation procedure, you need to have Arduino IDE installed on your computer. There are two versions of the Arduino IDE you can install: version 1 and version 2.

You can download and install Arduino IDE by clicking on the following link: arduino.cc/en/Main/Software

Which Arduino IDE version do we recommend? At the moment, there are some plugins for the ESP32 (like the SPIFFS Filesystem Uploader Plugin) that are not yet supported on Arduino 2. So, if you intend to use the SPIFFS plugin in the future, we recommend installing the legacy version 1.8.X. You just need to scroll down on the Arduino software page to find it.

LROBRUYA

Legacy IDE (1.8.X)



Arduino IDE 1.8.19

The open-source Arduino Software (IDE) makes it easy to write code and upload it to the board. This software can be used with any Arduino board.

Refer to the [Getting Started](#) page for installation instructions.

SOURCE CODE
Active development of the Arduino software is [hosted by GitHub](#). See the instructions for [building the code](#). Latest release source code archives are available [here](#). The archives are PGP-signed so


DOWNLOAD OPTIONS
Windows Win 7 and newer
Windows ZIP file
Windows app Win 8.1 or 10 [Get](#)
Linux 32 bits
Linux 64 bits
Linux ARM 32 bits
Linux ARM 64 bits
Mac OS X 10.10 or newer
[Release Notes](#)
[Checksums \(sha512\)](#)

Installing ESP32 Add-on in Arduino IDE

To install the ESP32 board in your Arduino IDE, follow these next instructions:

1. In your Arduino IDE, go to File > Preferences

LROBRUYA




2. Enter the following into the “Additional Board Manager URLs” field:

https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package_esp32_index.json

Then, click the “OK” button:

LROBRUYA




Note: if you already have the ESP8266 boards URL, you can separate the URLs with a comma as follows:

https://raw.githubusercontent.com/espressif/arduino-esp32/gh-pages/package_esp32_index.json,
http://arduino.esp8266.com/stable/package_esp8266com_index.json


3. Open the Boards Manager. Go to **Tools > Board > Boards Manager...**

LROBRYA




4. Search for **ESP32** and press install button for the "**ESP32 by Espressif Systems**":

LROBRYA



5. That's it. It should be installed after a few seconds.




Upload Test Code


Plug the ESP32 board to your computer. With your Arduino IDE open, follow these steps:

1. Select your Board in **Tools > Board** menu (in my case it's the **DOIT ESP32 DEVKIT V1**)

LROBRYA




2. Select the Port (if you don't see the COM Port in your Arduino IDE, you need to install the [CP210x USB to UART Bridge VCP Drivers](#)):



3. Open the following example under **File > Examples > WiFi (ESP32) > WiFiScan**

LROBRUYA



4. A new sketch opens in your Arduino IDE:

```
File Edit Sketch Tools Help
WiFiScan
4 * E.g. the return value of `encryptionType()` different because
5 */
6 #include "WiFi.h"
7
8 void setup()
9 {
10   Serial.begin(115200);
11
12   // Set WiFi to station mode and disconnect from an AP if it
13   WiFi.mode(WIFI_STA);
14   WiFi.disconnect();
15   delay(100);
16 }
```

The screenshot shows the Arduino IDE with the WiFiScan sketch open. The code is as follows:

```
File Edit Sketch Tools Help
WiFiScan
4 * E.g. the return value of `encryptionType()` different because
5 */
6 #include "WiFi.h"
7
8 void setup()
9 {
10   Serial.begin(115200);
11
12   // Set WiFi to station mode and disconnect from an AP if it
13   WiFi.mode(WIFI_STA);
14   WiFi.disconnect();
15   delay(100);
16 }
```


The status bar at the bottom of the IDE window displays the text "DOIT ESP32 DEVKIT V1, 80MHz, 921600, None, Disabled on COM7".

LROBRYA

5. Press the **Upload** button in the Arduino IDE. Wait a few seconds while the code compiles and uploads to your board.



6. If everything went as expected, you should see a “**Done uploading.**” message.



Done uploading. Done uploading.


```
Writing at 0x00008000... (100 %)
Wrote 3072 bytes (128 compressed) at 0x00008000 in 0.0 seconds (effective 1755.4 kbit/s)...
Hash of data verified.

Leaving...
Hard resetting via RTS pin...
```

7. Open the Arduino IDE Serial Monitor at a baud rate of 115200:



8. Press the ESP32 on-board **Enable** button and you should see the networks available near your ESP32:



```
scan start
scan done
48 networks found
1: TP-LINK_6CA0 (-55)*
2: ChinaNet-2GwA (-59)*
3: longvn-US (-60)*
4: FK (-67)*
5: LYZC08 (-67)*
6: TP-LINK_五月 (-68)*
7: 5H2 (-73)*
8: longvn2022 (-73)*
9: ChinaNet-AEF4 (-75)*
10: bubble lab (-76)*
11: ChinaNet-Zuzw (-77)*
12: IPCS5A93244401234 (-78)*
```


LROBRUYA

Troubleshooting

If you try to upload a new sketch to your ESP32 and you get this error message “**A fatal error occurred: Failed to connect to ESP32: Timed out waiting for packet header**”. It means that your ESP32 is not in flashing/uploading mode.

Having the right board name and COM port selected, follow these steps:

- Hold-down the “**BOOT**” button in your ESP32 board.



- Press the “**Upload**” button in the Arduino IDE to upload your sketch:




- After you see the “**Connecting....**” message in your Arduino IDE, release the finger from the “**BOOT**” button:

LROBRYA

```
esptool.py v2.6
Serial port COM7
Connecting. . . . .
```

- After that, you should see the “**Done uploading**” message:



```
Done uploading. ←
Writing at 0x00008000... (100 %)
Wrote 3072 bytes (128 compressed) at 0x00008000 in 0.0 seconds (effective 1890.5 kbit/s)...
Hash of data verified.

Leaving...
Hard resetting via RTS pin...
```

That's it. Your ESP32 should have the new sketch running. Press the “**ENABLE**” button to restart the ESP32 and run the new uploaded sketch.

Note: You'll also have to repeat that button sequence every time you want to upload a new sketch.

Project 1 ESP32 Hello World

For ESP32 beginners, we'll start with some simple things. In this project, you just need an ESP32 mainboard, a USB cable and a computer to complete “Hello World!” Project. It is not only a communication test for ESP32 mainboard and computer, but also a primary project for ESP32.

Prerequisites


We'll program the ESP32 using Arduino IDE. So, make sure you have the ESP32 boards add-on installed before proceeding:

LROBRYA

Installing ESP32 Add-on in Arduino IDE

Project Example

In this project, we use a USB cable to connect the ESP32 to the computer.



Parts Required

Here's a list of the parts to you need to build the circuit:

- [ESP32 DEVKIT V1](#)
- [USB cable](#)

Code

Open the code Project_1_ESP32_Hello_World.ino in arduino IDE

```
char val; // defines variable "val"
void setup() {
Serial.begin(115200); //sets baudrate to 115200
}
void loop() {
if (Serial.available() > 0) {
val=Serial.read(); //reads symbols assigns to "val"
if (val == 'L') { //check input for the letter "L"
Serial.println("Hello World!"); //shows "Hello World!"
}
}
}
```



Uploading the Code

Before clicking the upload button, go to **Tools > Board**, and select the board :DOIT ESP32 DEVKIT V1 board.

Go to **Tools > Port** and select the COM port the ESP32 is connected to.


Then, press the upload button and wait for the “Done uploading” message.



Note: If you see a lot of dots (connecting...__...) on the debugging window and the “Failed to connect to ESP32: Timed out waiting for packet header” message, that means you need to press the ESP32 on-board BOOT button after the dots start appearing.

Demonstration

Click to open serial port monitor, input an “L”, PC will receive the information from Arduino: Hello World!





Project 2 ESP32 Inputs Outputs

In this project you'll learn how to read digital inputs like a button switch and control digital outputs like an LED using the ESP32 with Arduino IDE.

Prerequisites

We'll program the ESP32 using Arduino IDE. So, make sure you have the ESP32 boards add-on installed before proceeding:

[Installing ESP32 Add-on in Arduino IDE](#)

ESP32 Control Digital Outputs

First, you need set the GPIO you want to control as an OUTPUT.

Use the pinMode() function as follows:

```
pinMode(GPIO, OUTPUT);
```

To control a digital output you just need to use the digitalWrite() function, that accepts as arguments, the GPIO (int number) you are referring to, and the state, either HIGH or LOW.

```
digitalWrite(GPIO, STATE);
```

All GPIOs can be used as outputs except GPIOs 6 to 11 (connected to the integrated SPI flash) and GPIOs 34, 35, 36 and 39 (input only GPIOs);

Learn more about the ESP32 GPIOs: [ESP32 GPIO Reference Guide](#)

ESP32 Read Digital Inputs

LROBRYA

First, set the GPIO you want to read as INPUT, using the `pinMode()` function as follows:

```
pinMode(GPIO, INPUT);
```

To read a digital input, like a button, you use the `digitalRead()` function, that accepts as argument, the GPIO (int number) you are referring to.


```
digitalRead(GPIO);
```

All ESP32 GPIOs can be used as inputs, except GPIOs 6 to 11 (connected to the integrated SPI flash).

Learn more about the ESP32 GPIOs: [ESP32 GPIO Reference Guide](#)

Project Example

To show you how to use digital inputs and digital outputs, we'll build a simple project example with a pushbutton and an LED. We'll read the state of the pushbutton and light up the LED accordingly as illustrated in the following figure.



LROBRUYA

Parts Required


Here's a list of the parts to you need to build the circuit:

- [ESP32 DEVKIT V1](#)
- [5 mm LED](#)
- [220 Ohm resistor](#)
- [Pushbutton](#)
- [10k Ohm resistor](#)
- [Breadboard](#)
- [Jumper wires](#)

Schematic Diagram

Before proceeding, you need to assemble a circuit with an LED and a pushbutton.

We'll connect the LED to GPIO 5 and the pushbutton to GPIO 4.





Code

Open the code Project_2_ESP32_Inputs_Outputs.ino in arduino IDE

```
// set pin numbers
const int buttonPin = 4; // the number of the pushbutton pin
const int ledPin = 5; // the number of the LED pin
// variable for storing the pushbutton status
int buttonState = 0;
void setup() {
  Serial.begin(115200);
  pinMode(buttonPin, INPUT); // initialize the pushbutton pin
  as an input
  pinMode(ledPin, OUTPUT); // initialize the LED pin as an output
}
void loop() {
  // read the state of the pushbutton value
  buttonState = digitalRead(buttonPin);
  Serial.println(buttonState); // check if the pushbutton is
  pressed.
  // if it is, the buttonState is HIGH
  if (buttonState == HIGH) {
    // turn LED on
    digitalWrite(ledPin, HIGH);
  } else {
    // turn LED off
    digitalWrite(ledPin, LOW);
  }
}
```

How the Code Works

In the following two lines, you create variables to assign pins:

```
const int buttonPin = 4;
const int ledPin = 5;
```

The Button is connected to GPIO 4 and the LED is connected to GPIO 5.

When using the Arduino IDE with the ESP32, 4 corresponds to GPIO 4

and 5 corresponds to GPIO 5.



Next, you create a variable to hold the button state. By default, it's 0 (not pressed).

```
int buttonState = 0;
```

In the setup(), you initialize the button as an INPUT, and the LED as an OUTPUT.

For that, you use the pinMode() function that accepts the pin you are referring to, and the mode: INPUT or OUTPUT.

```
pinMode(buttonPin, INPUT);
pinMode(ledPin, OUTPUT);
```

In the loop() is where you read the button state and set the LED accordingly.

In the next line, you read the button state and save it in the buttonState variable.

As we've seen previously, you use the digitalRead() function.

```
buttonState = digitalRead(buttonPin);
```

The following if statement, checks whether the button state is HIGH. If it is, it turns the LED on using the digitalWrite() function that accepts as argument the ledPin, and the state HIGH.

```
if (buttonState == HIGH)
{
  digitalWrite(ledPin, HIGH);
}
```

If the button state is not HIGH, you set the LED off. Just set LOW as a second argument to in the digitalWrite() function.

```
else
```

LROBRYA

```
{  
digitalWrite(ledPin, LOW);  
}
```

Uploading the Code

Before clicking the upload button, go to **Tools > Board**, and select the board :DOIT ESP32 DEVKIT V1 board.

Go to **Tools > Port** and select the COM port the ESP32 is connected to.

Then, press the upload button and wait for the “**Done uploading**” message.




Note: If you see a lot of dots (connecting...__...) on the debugging window and the “Failed to connect to ESP32: Timed out waiting for packet header” message, that means you need to press the ESP32 on-board BOOT button after the dots start appearing.

Demonstration


After uploading the code, test your circuit. Your LED should light up

when you press the pushbutton:



LROBRYA

And turn off when you release it:




Project 3 ESP32 Analog Inputs

This project shows how to read analog inputs with the ESP32 using Arduino IDE. Analog reading is useful to read values from variable resistors like potentiometers, or analog sensors.

Analog Inputs (ADC)


Reading an analog value with the ESP32 means you can measure varying voltage levels between 0 V and 3.3 V.

The voltage measured is then assigned to a value between 0 and 4095, in which 0 V corresponds to 0, and 3.3 V corresponds to 4095. Any voltage between 0 V and 3.3 V will be given the corresponding value in between.



ADC is Non-linear

Ideally, you would expect a linear behavior when using the ESP32 ADC pins. However, that doesn't happen. What you'll get is a behavior as shown in the following chart:



This behavior means that your ESP32 is not able to distinguish 3.3 V from 3.2 V.

You'll get the same value for both voltages: 4095.

LROBRYA

The same happens for very low voltage values: for 0 V and 0.1 V you'll get the same value: 0. You need to keep this in mind when using the ESP32 ADC pins.

analogRead() Function


Reading an analog input with the ESP32 using the Arduino IDE is as simple as using the `analogRead()` function. It accepts as argument, the GPIO you want to read:

```
analogRead(GPIO);
```

Only 15 are available in the DEVKIT V1 board (version with 30 GPIOs).

Grab your ESP32 board pinout and locate the ADC pins. These are highlighted with a red border in the figure below.

ESP32 DEVKIT V1





These analog input pins have 12-bit resolution. This means that when you read an analog input, its range may vary from 0 to 4095.

Note: ADC2 pins cannot be used when Wi-Fi is used. So, if you're using Wi-Fi and you're having trouble getting the value from an ADC2 GPIO, you may consider using an ADC1 GPIO instead, that should solve your problem.

To see how everything ties together, we'll make a simple example to read an analog value from a potentiometer.

Parts Required


For this example, you need the following parts:

- [ESP32 DEVKIT V1 Board](#)
- [Potentiometer](#)
- [Breadboard](#)
- [Jumper wires](#)

Schematic

Wire a potentiometer to your ESP32. The potentiometer middle pin should be connected to GPIO 4. You can use the following schematic diagram as a reference.

LROBRUYA



Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

Open the code Project_3_ESP32_Inputs_Outputs.ino in arduino IDE

```
// Potentiometer is connected to GPIO 4 (Analog ADC2_CH0)
const int potPin = 4;
// variable for storing the potentiometer value
int potValue = 0;
void setup() {
Serial.begin(115200);
delay(1000);
}
void loop() {
```



```
// Reading potentiometer value
potValue = analogRead(potPin);
Serial.println(potValue);
delay(500);
}
```

How the Code Works

This code simply reads the values from the potentiometer and prints those values in the Serial Monitor.

In the code, you start by defining the GPIO the potentiometer is connected to. In this example, GPIO 4.

```
const int potPin = 4;
```

In the setup(), initialize a serial communication at a baud rate of 115200.

```
Serial.begin(115200);
```

In the loop(), use the analogRead() function to read the analog input from the potPin.

```
potValue = analogRead(potPin);
```

Finally, print the values read from the potentiometer in the serial monitor.


```
Serial.println(potValue);
```

Upload the code provided to your ESP32. Make sure you have the right board and COM port selected in the Tools menu.

Testing the Example

After uploading the code and pressing the ESP32 reset button, open the Serial Monitor at a baud rate of 115200. Rotate the potentiometer and see the values changing.

LROBRYA



The maximum value you'll get is 4095 and the minimum value is 0.

```
COM7
2851
1623
2353
4095
4095
4095
4095
4095
3351
1999
134
0
0
0
```

Autoscroll Newline 115200 baud Clear output



Wrapping Up

In this article you've learned how to read analog inputs using the ESP32 with the Arduino IDE.


In summary:

- The ESP32 DEVKIT V1 DOIT board (version with 30 pins) has 15 ADC pins you can use to read analog inputs.
- These pins have a resolution of 12 bits, which means you can get values from 0 to 4095.
- To read a value in the Arduino IDE, you simply use the `analogRead()` function.
- The ESP32 ADC pins don't have a linear behavior. You'll probably won't be able to distinguish between 0 and 0.1V, or between 3.2 and 3.3V. You need to keep that in mind when using the ADC pins.

Project 4 ESP32 PWM(Analog Output)

In this project we'll show you how to generate PWM signals with the ESP32 using Arduino IDE. As an example we'll build a simple circuit that dims an LED using the LED PWM controller of the ESP32.

LROBRUYA



ESP32 LED PWM Controller

The ESP32 has a LED PWM controller with 16 independent channels that can be configured to generate PWM signals with different properties.

Here's the steps you'll have to follow to dim an LED with PWM using the Arduino IDE:

1. First, you need to choose a PWM channel. There are 16 channels from 0 to 15.
2. Then, you need to set the PWM signal frequency. For an LED, a frequency of 5000 Hz is fine to use.
3. You also need to set the signal's duty cycle resolution: you have resolutions from 1 to 16 bits. We'll use 8-bit resolution, which means you can control the LED brightness using a value from 0 to 255.



4. Next, you need to specify to which GPIO or GPIOs the signal will appear upon.

For that you'll use the following function:

`ledcAttachPin(GPIO, channel)`

This function accepts two arguments. The first is the GPIO that will output the signal, and the second is the channel that will generate the signal.

5. Finally, to control the LED brightness using PWM, you use the following function:

`ledcWrite(channel, dutycycle)`

This function accepts as arguments the channel that is generating the PWM signal, and the duty cycle.

Parts Required


To follow this tutorial you need these parts:

- [ESP32 DEVKIT V1 Board](#)
- [5mm LED](#)
- [220 Ohm resistor](#)
- [Breadboard](#)
- [Jumper wires](#)

Schematic

Wire an LED to your ESP32 as in the following schematic diagram. The LED should be connected to GPIO 4.

LROBRUYA



Note: you can use any pin you want, as long as it can act as an output. All pins that can act as outputs can be used as PWM pins.

For more information about the ESP32 GPIOs, read: [ESP32 Pinout](#)

Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

[Installing ESP32 Add-on in Arduino IDE](#)

Open the code Project_4_ESP32_PWM.ino in arduino IDE

```
// the number of the LED pin
```



```
#define ledPin 4; // 4 corresponds to GPIO4
// setting PWM properties

#define ledChannel 0; //PWM Channel 0

#define resolution 8; //8-bit resolution, we can control the
LED brightness using a value from 0 to 255
#define freq 5000; // PWM signal frequency 5000 Hz
void setup(){
// configure LED PWM functionalities
ledcSetup(ledChannel, freq, resolution);
// attach the channel to the GPIO to be controlled
ledcAttachPin(ledPin, ledChannel);}
void loop(){
// increase the LED brightness
for(int dutyCycle = 0; dutyCycle <= 255; dutyCycle++){
// changing the LED brightness with PWM
ledcWrite(ledChannel, dutyCycle);
delay(15);
}
// decrease the LED brightness
for(int dutyCycle = 255; dutyCycle >= 0; dutyCycle--){
// changing the LED brightness with PWM
ledcWrite(ledChannel, dutyCycle);
delay(15);
}}
```

How the Code Works

You start by defining the pin the LED is attached to. In this case the LED is attached to GPIO 4.

```
#define ledPin 4; // 4 corresponds to GPIO4
```

Then, you set the PWM signal properties. You choose channel 0 to generate the signal, and set a resolution of 8 bits, define a frequency of 5000 Hz. You can choose other properties, different than these, to generate different PWM signals.



```
#define ledChannel 0;
#define resolution 8;
#define freq 5000;
```

In the `setup()`, you need to configure LED PWM with the properties you've defined earlier by using the `ledcSetup()` function that accepts as arguments, the `ledChannel`, the frequency, and the resolution, as follows:

```
ledcSetup(ledChannel, freq, resolution);
```

Next, you need to choose the GPIO you'll get the signal from. For that use the `ledcAttachPin()` function that accepts as arguments the GPIO where you want to get the signal, and the channel that is generating the signal. In this example, we'll get the signal in the `ledPin` GPIO, that corresponds to GPIO 4. The channel that generates the signal is the `ledChannel`, that corresponds to channel 0.

```
ledcAttachPin(ledPin, ledChannel);
```

In the loop, you'll vary the duty cycle between 0 and 255 to increase the LED brightness.

```
for(int dutyCycle = 0; dutyCycle <= 255; dutyCycle++){
    // changing the LED brightness with PWM
    ledcWrite(ledChannel, dutyCycle);
    delay(15); }
```

And then, between 255 and 0 to decrease the brightness.

```
for(int dutyCycle = 255; dutyCycle >= 0; dutyCycle--){
    // changing the LED brightness with PWM
    ledcWrite(ledChannel, dutyCycle);
    delay(15); }
```

LROBRYA

To set the brightness of the LED, you just need to use the `ledcWrite()` function that accepts as arguments the channel that is generating the signal, and the duty cycle.

```
ledcWrite(ledChannel, dutyCycle);
```

As we're using 8-bit resolution, the duty cycle will be controlled using a value from 0 to 255. Note that in the `ledcWrite()` function we use the channel that is generating the signal, and not the GPIO.

Testing the Example

Upload the code to your ESP32. Make sure you have the right board and COM port selected. Look at your circuit. You should have a dimmer LED that increases and decreases brightness.



Project 5 ESP32 RGB LED

In this project we'll show you how to control an RGB LED with the ESP32 using Arduino IDE. RGB LEDs are a fun and easy way to add


LROBRYA

some color to your projects. Since they are like 3 regular LEDs in one, how to use and connect them is not much different.



How RGB LED Works

Most monitors adopt the RGB color standard, and all colors on a computer screen are a mixture of red, green and blue in varying proportions.



This RGB LED has 4 pins, with each color (red, green, blue) and a common cathode. To change its brightness, we can use the PWM of the ESP32 pins, which can give different duty cycle signals to the RGB to produce different colors of light.

LROBRUYA


If we use three 10-bit PWM to control the RGB, in theory, we can create $210*210*210 = 1,073,741,824$ (1billion) colors through different combinations.

Parts Required

To follow this tutorial you need these parts:

- [ESP32 DEVKIT V1 Board](#)
- [RGB LED](#)
- [3x 220 ohm resistors](#)
- [Jumper wires](#)
- [Breadboard](#)

Schematic





Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

Open the code Project_5_ESP32_RGB_LED.ino in arduino IDE


```
int ledPins[] = {13, 12, 14}; // define red, green, blue led pins
Const byte chns[] = {0, 1, 2}; //define the pwm channels
int red, green, blue;
void setup(){
for(int i = 0, i < 3, i++){ //setup the pwm channels,5Khz,8bit
ledcSetup(chns[i], 5000, 8);
ledcAttachPin(ledPins[i], chns[i]);
}
}
void loop(){
red = random(0, 255);
green = random(0, 255);
blue = random(0, 255);
setColor(red, green, blue);
delay(200);
}

void setColor(byte r, byte g, byte b) {
ledcWrite(chns[0], 255 - r); //Common anode LED, low level to
turn on the led.
ledcWrite(chns[1], 255 - g);
ledcWrite(chns[2], 255 - b);
}
```

LROBRYA

Testing the Example

Compile and upload the code to ESP32, after the code is uploaded successfully, power up with a USB cable and you will see that the RGB LED starts to display random colors.




Project 6 ESP32 PIR Motion Sensor

This project shows how to detect motion with the ESP32 using a PIR motion sensor. The buzzer will sound an alarm when motion is detected, and stop the alarm when no motion is detected for a preset time (such as 4 seconds).

How HC-SR501 Motion Sensor Works

LROBRYA



The working principle of HC-SR501 sensor is based on the change of the infrared radiation on the moving object. To be detected by the HC-SR501 sensor, the object must meet two requirements:

- The object is emitting the infrared way.
- The object is moving or shaking

So: If an object is emitting the infrared ray but NOT moving (e.g, a person stands still without moving), it is NOT detected by the sensor.

If an object is moving but NOT emitting the infrared ray (e.g, robot or vehicle), it is NOT detected by the sensor.

Introducing Timers

In this example we'll also introduce timers. We want the LED to stay on for a predetermined number of seconds after motion is detected. Instead of using a `delay()` function that blocks your code and doesn't allow you to

LROBROUYA

do anything else for a determined number of seconds, we should use a timer.



The delay() function

You should be familiar with the delay() function as it is widely used. This function is pretty straightforward to use. It accepts a single int number as an argument.

This number represents the time in milliseconds the program has to wait until moving on to the next line of code.

`delay(time in milliseconds)`

When you do `delay(1000)` your program stops on that line for 1 second.

`delay()` is a blocking function. Blocking functions prevent a program from doing anything else until that particular task is completed. If you need multiple tasks to occur at the same time, you cannot use `delay()`.

For most projects you should avoid using delays and use timers instead.

The millis() function

Using a function called `millis()` you can return the number of milliseconds that have passed since the program first started.

LROBROUYA

`millis()`


Why is that function useful? Because by using some math, you can easily verify how much time has passed without blocking your code.

Parts Required

To follow this tutorial you need the following parts

- [ESP32 DEVKIT V1 Board](#)
- [PIR motion sensor \(HC-SR501\)](#)
- [Active Buzzer](#)
- [Jumper wires](#)
- [Breadboard](#)

Schematic





Code

Before proceeding with this tutorial you should have the ESP32 add-on installed in your Arduino IDE. Follow one of the following tutorials to install the ESP32 on the Arduino IDE, if you haven't already.(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

Open the code Project_6_ESP32_PIR_Motion_Sensor.ino in arduino IDE.

Demonstration


Upload the code to your ESP32 board. Make sure you have the right board and COM port selected.

Open the Serial Monitor at a baud rate of 115200.



Move your hand in front of the PIR sensor. The buzzer should turn on, and the message is printed in the Serial Monitor saying "Motion detected!Buzzer alarm". After 4 seconds the buzzer should turn off.

LROBROUYA



Project 7 ESP32 Switch Web Server

In this project you'll create a standalone web server with an ESP32 that controls outputs (two LEDs) using the Arduino IDE programming environment. The web server is mobile responsive and can be accessed with any device that has a browser on the local network. We'll show you how to create the web server and how the code works step-by-step.

Project Overview

Before going straight to the project, it is important to outline what our web server will do, so that it is easier to follow the steps later on.

- The web server you'll build controls two LEDs connected to the ESP32 GPIO 26 and GPIO 27;



- You can access the ESP32 web server by typing the ESP32 IP address on a browser in the local network;
- By clicking the buttons on your web server you can instantly change the state of each LED.

Parts Required

For this tutorial you'll need the following parts:


- [ESP32 DEVKIT V1 Board](#)
- [2x 5mm LED](#)
- [2x 200 Ohm resistor](#)
- [Breadboard](#)
- [Jumper wires](#)

Schematic

Start by building the circuit. Connect two LEDs to the ESP32 as shown in the following schematic diagram – one LED connected to GPIO 26, and the other to GPIO 27.

Note: We're using the ESP32 DEVKIT DOIT board with 30 pins. Before assembling the circuit, make sure you check the pinout for the board you're using.

LROBRYA



Code

Here we provide the code that creates the ESP32 web server. Open the code `Project_7_ESP32_Switch_Web_Server.ino` in arduino IDE, but don't upload it yet. You need to make some changes to make it work for you.



We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

Setting Your Network Credentials

You need to modify the following lines with your network credentials: SSID and password. The code is well commented on where you should make the changes.

```
// Replace with your network credentials  
  
const char* ssid = "REPLACE_WITH_YOUR_SSID";  
  
const char* password = "REPLACE_WITH_YOUR_PASSWORD";
```


Uploading the Code

Now, you can upload the code and the web server will work straight away.


Follow the next steps to upload code to the ESP32:

- 1) Plug your ESP32 board in your computer;
- 2) In the Arduino IDE select your board in **Tools > Board** (in our case we're using the ESP32 DEVKIT DOIT board);

LROBRYA



3) Select the COM port in **Tools > Port**.



4) Press the **Upload** button in the Arduino IDE and wait a few seconds

while the code compiles and uploads to your board.



5) Wait for the “**Done uploading**” message.



```
Done uploading.   
Writing at 0x00008000... (100 %)  
Wrote 3072 bytes (128 compressed) at 0x00008000 in 0.0 seconds (effective 1890.5 kbit/s)...  
Hash of data verified.  
  
Leaving...  
Hard resetting via RTS pin...
```

Finding the ESP IP Address

After uploading the code, open the Serial Monitor at a baud rate of 115200



Press the ESP32 EN button (reset). The ESP32 connects to Wi-Fi, and outputs the ESP IP address on the Serial Monitor. Copy that IP address, because you need it to access the ESP32 web server.

```
rst.0x1 (POWERON_RESET), boot.0x15 (SPI_FAST_FLASH_BOOT)
configsip: 0, SPIWP:0xee
clk_drv:0x00,q_drv:0x00,d_drv:0x00,cs0_drv:0x00,hd_drv:0x00,wp_drv:0x00
mode:DIO, clock div:1
load:0x3fff0018, len:4
load:0x3fff001c, len:1044
load:0x40078000, len:8896
load:0x40080400, len:5816
entry 0x400806ac
Connecting to longvn-US
.
.
.
WiFi connected.
IP address:
192.168.50.242
```

LROBRUYA

Accessing the Web Server

To access the web server, open your browser, paste the ESP32 IP address, and you'll see the following page.

Note: Your browser and ESP32 should be connected to the same LAN.



If you take a look at the Serial Monitor, you can see what's happening on the background. The ESP receives an HTTP request from a new client (in this case, your browser).

LROBRYA

```
COM7
Connecting to longvn-US
.
.
.
WiFi connected.
IP address:
192.168.50.242
New Client.
GET / HTTP/1.1
Host: 192.168.50.242
Connection: keep-alive
Cache-Control: max-age=0
Upgrade-Insecure-Requests: 1
User-Agent: Mozilla/5.0 (Windows NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/85.0.4183.122 Safari/537.36
Accept: text/html, application/xhtml+xml, application/xml;q=0.9, image/*;q=0.8, application/javascript, application/x-javascript, application/xslt+xml, */*;q=0.5
Accept-Encoding: gzip, deflate
Accept-Language: zh-CN, zh;q=0.9
.
.
.
Autoscroll Newline 115200 baud Clear output
```

You can also see other information about the HTTP request.


Demonstration

Now you can test if your web server is working properly. Click the buttons to control the LEDs.



LROBRYA

At the same time, you can take a look at the Serial Monitor to see what's going on in the background. For example, when you click the button to turn GPIO 26 ON, ESP32 receives a request on the /26/on URL.



Client disconnected.

New Client.

GET /26/on HTTP/1.1

Host: 192.168.50.242

Connection: keep-alive

Upgrade-Insecure-Requests: 1

User-Agent: Mozilla/5.0 (Windows NT 10.0; Win64; x64) AppleWebKit/537.36 (KHTML, like Gecko) Chrome/85.0.4183.122 Safari/537.36

Accept: text/html, application/xhtml+xml, application/xml;q=0.9, image/*

Referer: http://192.168.50.242/27/off


Accept-Encoding: gzip, deflate

Accept-Language: zh-CN, zh;q=0.9

GPIO 26 on

Autoscroll Newline 115200 baud Clear output

When the ESP32 receives that request, it turns the LED attached to GPIO 26 ON and updates its state on the web page.



LROBRYA

The button for GPIO 27 works in a similar way. Test that it is working properly.



How the Code Works

In this section will take a closer look at the code to see how it works.

The first thing you need to do is to include the WiFi library.

```
#include <WiFi.h>
```

As mentioned previously, you need to insert your ssid and password in the following lines inside the double quotes.

```
const char* ssid = "";
```

```
const char* password = "";
```

Then, you set your web server to port 80.

```
WiFiServer server(80);
```

The following line creates a variable to store the header of the HTTP request:



String header;

Next, you create auxiliar variables to store the current state of your outputs. If you want to add more outputs and save its state, you need to create more variables.

```
String output26State = "off";
```

```
String output27State = "off";
```

You also need to assign a GPIO to each of your outputs. Here we are using GPIO 26 and GPIO 27. You can use any other suitable GPIOs.

```
const int output26 = 26;
```

```
const int output27 = 27;
```

setup()

Now, let's go into the `setup()`. First, we start a serial communication at a baud rate of 115200 for debugging purposes.

```
Serial.begin(115200);
```

You also define your GPIOs as OUTPUTs and set them to LOW.

```
// Initialize the output variables as outputs
```

```
pinMode(output26, OUTPUT);
```

```
pinMode(output27, OUTPUT);
```

```
// Set outputs to LOW
```

```
digitalWrite(output26, LOW);
```



```
digitalWrite(output27, LOW);
```

The following lines begin the Wi-Fi connection with WiFi.begin(ssid, password), wait for a successful connection and print the ESP IP address in the Serial Monitor.

```
// Connect to Wi-Fi network with SSID and password
Serial.print("Connecting to ");
Serial.println(ssid);
WiFi.begin(ssid, password);
while (WiFi.status() != WL_CONNECTED) {
    delay(500);
    Serial.print(".");
}
// Print local IP address and start web server
Serial.println("");
Serial.println("WiFi connected.");
Serial.println("IP address: ");
Serial.println(WiFi.localIP());
server.begin();
loop()
```

In the loop() we program what happens when a new client establishes a



connection with the web server.

The ESP32 is always listening for incoming clients with the following line:

```
WiFiClient client = server.available();  
// Listen for incoming clients
```

When a request is received from a client, we'll save the incoming data.

The while loop that follows will be running as long as the client stays connected. We don't recommend changing the following part of the code unless you know exactly what you are doing.

```
if (client) { // If a new client connects,  
  Serial.println("New Client."); // print a message out in the serial port  
  String currentLine = ""; // make a String to hold incoming data from the client  
  
  while (client.connected()) { // loop while the client's connected  
    if (client.available()) { // if there's bytes to read from the client,  
      char c = client.read(); // read a byte, then  
      Serial.write(c); // print it out the serial monitor  
      header += c;  
      if (c == '\n') { // if the byte is a newline character  
        // if the current line is blank, you got two newline characters in a row.
```



that's the end of the client HTTP request, so send a response:

```
if (currentLine.length() == 0) {  
  
    // HTTP headers always start with a response code (e.g. HTTP/1.1 200  
    OK) and a content-type so the client knows what's coming, then a blank  
    line:  
  
    client.println("HTTP/1.1 200 OK");  
  
    client.println("Content-type:text/html");  
  
    client.println("Connection: close");  
  
    client.println();
```

The next section of if and else statements checks which button was pressed in your web page, and controls the outputs accordingly. As we've seen previously, we make a request on different URLs depending on the button pressed.

```
// turns the GPIOs on and off  
  
if (header.indexOf("GET /26/on") >= 0)  
  
{  
  
    Serial.println("GPIO 26 on");  
  
    output26State = "on";  
  
    digitalWrite(output26, HIGH);}  
  
else if (header.indexOf("GET /26/off") >= 0) {
```



```
Serial.println("GPIO 26 off");

output26State = "off";

digitalWrite(output26, LOW);}

else if (header.indexOf("GET /27/on") >= 0) {

Serial.println("GPIO 27 on");

output27State = "on";

digitalWrite(output27, HIGH);}

else if (header.indexOf("GET /27/off") >= 0) {

Serial.println("GPIO 27 off");

output27State = "off";

digitalWrite(output27, LOW);}
```

For example, if you've press the GPIO 26 ON button, the ESP32 receives a request on the **/26/ON URL** (we can see that that information on the HTTP header on the Serial Monitor). So, we can check if the header contains the expression **GET /26/on**. If it contains, we change the output26state variable to ON, and the ESP32 turns the LED on.

This works similarly for the other buttons. So, if you want to add more outputs, you should modify this part of the code to include them.

Displaying the HTML web page



The next thing you need to do, is creating the web page. The ESP32 will be sending a response to your browser with some HTML code to build the web page.

The web page is sent to the client using this expressing `client.println()`.

You should enter what you want to send to the client as an argument.

The first thing we should send is always the following line, that indicates that we are sending HTML.

`<!DOCTYPE HTML><html>`

Then, the following line makes the web page responsive in any web browser.

```
client.println("<head><meta name=\"viewport\" content=\"width=device-width, initial-scale=1\">");
```

And the following is used to prevent requests on the favicon. – You don't need to worry about this line.

```
client.println("<link rel=\"icon\" href=\"data:;\">");
```

Styling the Web Page

Next, we have some CSS text to style the buttons and the web page appearance.

We choose the Helvetica font, define the content to be displayed as a block and aligned at the center.



```
client.println("<style>html { font-family: Helvetica; display:
```

```
inline-block; margin: 0px auto; text-align: center;}</style>");
```

We style our buttons with the #4CAF50 color, without border, text in white color, and with this padding: 16px 40px. We also set the text-decoration to none, define the font size, the margin, and the cursor to a pointer.

```
client.println(".button { background-color: #4CAF50; border: none;
```

```
color: white; padding: 16px 40px;");
```

```
client.println("text-decoration: none; font-size: 30px; margin: 2px; cursor:
```



```
pointer;});
```

We also define the style for a second button, with all the properties of the button we've defined earlier, but with a different color. This will be the style for the off button.

```
client.println(".button2 {background-color: #555555;}</style></head>");
```

Setting the Web Page First Heading

In the next line you can set the first heading of your web page. Here we have “**ESP32 Web Server**”, but you can change this text to whatever you like.

```
// Web Page Heading
```

```
client.println("<h1>ESP32 Web Server</h1>");
```



Displaying the Buttons and Corresponding State

Then, you write a paragraph to display the GPIO 26 current state. As you can see we use the output26State variable, so that the state updates instantly when this variable changes.

```
client.println("<p>GPIO 26 - State " + output26State + "</p>");
```

Then, we display the on or the off button, depending on the current state of the GPIO. If the current state of the GPIO is off, we show the ON button, if not, we display the OFF button.

```
if (output26State=="off") {  
  
    client.println("<p><a href=\"/26/on\"><button  
    class=\"button\">ON</button></a></p>");  
  
}  
  
else {  
  
    client.println("<p><a href=\"/26/off\"><button class=\"button  
button2\">OFF</button></a></p>");  
  
}
```

We use the same procedure for GPIO 27.

Closing the Connection

Finally, when the response ends, we clear the header variable, and stop the connection with the client with client.stop().



```
// Clear the header variable
```

```
header = "";
```

```
// Close the connection
```

```
client.stop();
```

Wrapping Up

In this tutorial we've shown you how to build a web server with the ESP32. We've shown you a simple example that controls two LEDs, but the idea is to replace those LEDs with a relay, or any other output you want to control.

Project 8 RGB LED Web Server

In this project we'll show you how to remotely control an RGB LED with an ESP32 board using a web server with a color picker.

Project Overview

Before getting started, let's see how this project works:

LROBRUYA




- The ESP32 web server displays a color picker.
- When you chose a color, your browser makes a request on a URL that contains the R, G, and B parameters of the selected color.
- Your ESP32 receives the request and splits the value for each color parameter.
- Then, it sends a PWM signal with the corresponding value to the GPIOs that are controlling the RGB LED.

How do RGB LEDs work

In a common cathode RGB LED, all three LEDs share a negative connection (cathode). All included in the kit are common-cathode RGB.

Common Cathode (-)




Red Anode

Common Cathode

Green Anode

Blue Anode





How to create different colors?

With an RGB LED you can, of course, produce red, green, and blue light, and by configuring the intensity of each LED, you can produce other colors as well.

For example, to produce purely blue light, you'd set the blue LED to the highest intensity and the green and red LEDs to the lowest intensity. For a white light, you'd set all three LEDs to the highest intensity.

Mixing colors

To produce other colors, you can combine the three colors in different intensities.


To adjust the intensity of each LED you can use a PWM signal.

Because the LEDs are very close to each other, our eyes see the result of the combination of colors, rather than the three colors individually.

To have an idea on how to combine the colors, take a look at the following chart.

This is the simplest color mixing chart, but gives you an idea how it works and how to produce different colors.

LROBRUYA




Parts Required

For this project you need the following parts:

- ESP32 DEVKIT V1 Board
- RGB LED
- 3x 220 ohm resistors
- Jumper wires
- Breadboard

Schematic





Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

After assembling the circuit, Open the code

Project_8_RGB_LED_Web_Server.ino in arduino IDE.

Before uploading the code, don't forget to insert your network credentials so that the ESP can connect to your local network.

```
const char* ssid = "REPLACE_WITH_YOUR_SSID";  
const char* password = "REPLACE_WITH_YOUR_SSID";
```

How the code works

The ESP32 sketch uses the WiFi.h library.

```
#include <WiFi.h>
```

The following lines define string variables to hold the R, G, and B parameters from the request.

```
String redString = "0";
```

```
String greenString = "0";
```

```
String blueString = "0";
```

The next four variables are used to decode the HTTP request later on.



```
int pos1 = 0;
```

```
int pos2 = 0;
```

```
int pos3 = 0;
```

```
int pos4 = 0;
```

Create three variables for the GPIOs that will control the strip R, G, and B parameters. In this case we're using GPIO 13, GPIO 12, and GPIO 14.

```
const int redPin = 13;
```

```
const int greenPin = 12;
```

```
const int bluePin = 14;
```

These GPIOs need to output PWM signals, so we need to configure the PWM properties first. Set the PWM signal frequency to 5000 Hz. Then, associate a PWM channel for each color.

```
const int freq = 5000;
```

```
const int redChannel = 0;
```

```
const int greenChannel = 1;
```

```
const int blueChannel = 2;
```

And finally, set the resolution of the PWM channels to 8-bit

```
const int resolution = 8;
```

In the setup(), assign the PWM properties to the PWM channels

```
ledcSetup(redChannel, freq, resolution);
```



```
ledcSetup(greenChannel, freq, resolution);
```

```
ledcSetup(blueChannel, freq, resolution);
```

Attach the PWM channels to the corresponding GPIOs

```
ledcAttachPin(redPin, redChannel);
```

```
ledcAttachPin(greenPin, greenChannel);
```

```
ledcAttachPin(bluePin, blueChannel);
```

The following code section displays the color picker in your web page and makes a request based on the color you've picked.

```
client.println("<!DOCTYPE html><html>");  
client.println("<head><meta name=\"viewport\""  
content="width=device-width, initial-scale=1">");  
client.println("<link rel=\"icon\" href=\"data:;\">");  
client.println("<link rel=\"stylesheet\""  
href="https://stackpath.bootstrapcdn.com/bootstrap/4.3.1/css/bootstrap.m  
in.css">");  
client.println("<script  
src=\"https://cdnjs.cloudflare.com/ajax/libs/jscolor/2.0.4/jscolo  
r.min.js\"></script>");  
client.println("</head><body><div class=\"container\">  
<div class=\"row\"><h1>ESP Color Picker</h1></div>");
```



```
client.println("<a class=\"btn btn-primary btn-lg\" href=\"#\"
id=\"change_color\" role=\"button\">Change Color</a> ");

client.println("<input class=\"jscolor
{onFineChange:'update(this)'}\" id=\"rgb\"></div>");

client.println("<script>function update(picker)
{document.getElementById('rgb').innerHTML =
Math.round(picker.rgb[0]) + ', ' + Math.round(picker.rgb[1]) + ,
' + Math.round(picker.rgb[2]);");

client.println("document.getElementById(\"change_color\").href=?r\
" + Math.round(picker.rgb[0]) + \"g\" + Math.round(picker.rgb[1])
+ \"b\" + Math.round(picker.rgb[2]) +
\"&\");}</script></body></html>");

// The HTTP response ends with another blank line

client.println();
```

When you pick a color, you receive a request with the following format.

?r201g32b255&

So, we need to split this string to get the R, G, and B parameters. The parameters are saved in redString, greenString, and blueString variables and can have values between 0 and 255.

```
pos1 = header.indexOf('r');
```



```
pos2 = header.indexOf('g');
pos3 = header.indexOf('b');
pos4 = header.indexOf('&');
redString = header.substring(pos1+1, pos2);
greenString = header.substring(pos2+1, pos3);
blueString = header.substring(pos3+1, pos4);
```

To control the strip with the ESP32, use the ledcWrite() function to generate PWM signals with the values decoded from the HTTP request.

```
ledcWrite(redChannel, redString.toInt());
ledcWrite(greenChannel, greenString.toInt());
ledcWrite(blueChannel, blueString.toInt());
```

Note: learn more about PWM with ESP32: Project 3 ESP32

PWM(Analog Output)

To control the strip with the ESP8266, we just need to use the analogWrite() function to generate PWM signals with the values decoded from the HTPP request.

```
analogWrite(redPin, redString.toInt());
analogWrite(greenPin, greenString.toInt());
analogWrite(bluePin, blueString.toInt());
```

Because we get the values in a string variable, we need to convert them to

LROBRYA


integers using the `toInt()` method.

Demonstration

After inserting your network credentials, select the right board and COM port and upload the code to your ESP32.

After uploading, open the Serial Monitor at a baud rate of 115200 and press the ESP Enable/Reset button. You should get the board IP address.

Note: Your browser and ESP32 should be connected to the same LAN.



```
..ets Jul 29 2019 12:21:46

rst:0x1 (POWERON_RESET), boot:0x13 (SPI_FAST_FLASH_BOOT)
configsip: 0, SPIWP:0xee
clk_drv:0x00, q_drv:0x00, d_drv:0x00, cs0_drv:0x00, hd_drv:0x00, wp_drv:0x00
mode:DIO, clock div:1
load:0x3fff0018, len:4
load:0x3fff001c, len:1044
load:0x40078000, len:8896
load:0x40080400, len:5816
entry 0x400806ac
Connecting to longvn-US
.....
WiFi connected.
IP address: 192.168.50.242
```

Open your browser and insert the ESP IP address. Now, use the color picker to choose a color for the RGB LED.


LROBRYA

Then, you need to press the “Change Color” button for the color to take effect.



To turn off the RGB LED , select the black color.

The strongest colors (at the top of the color picker), are the ones that will produce better results.



Project 9 ESP32 Relay Web Server

Using a relay with the ESP32 is a great way to control AC household appliances remotely. This tutorial explains how to control a relay module with the ESP32.

LROBRYA

We'll take a look at how a relay module works, how to connect the relay to the ESP32 and build a web server to control a relay remotely.

Introducing Relays

A relay is an electrically operated switch and like any other switch, it that can be turned on or off, letting the current go through or not. It can be controlled with low voltages, like the 3.3V provided by the ESP32 GPIOs and allows us to control high voltages like 12V, 24V or mains voltage (230V in Europe and 120V in the US).



On the left side, there are two sets of three sockets to connect high voltages, and the pins on the right side (low-voltage) connect to the ESP32 GPIOs.

Mains Voltage Connections

LROBRYA



The relay module shown in the previous photo has two connectors, each with three sockets: common (COM), Normally Closed (NC), and Normally Open (NO).

- COM: connect the current you want to control (mains voltage).
- NC (Normally Closed): the normally closed configuration is used when you want the relay to be closed by default. The NC are COM pins are connected, meaning the current is flowing unless you send a signal from the ESP32 to the relay module to open the circuit and stop the current flow.
- NO (Normally Open): the normally open configuration works the other way around: there is no connection between the NO and COM pins, so the circuit is broken unless you send a signal from the ESP32

to close the circuit.

Control Pins



The low-voltage side has a set of four pins and a set of three pins. The first set consists of VCC and GND to power up the module, and input 1 (IN1) and input 2 (IN2) to control the bottom and top relays, respectively. If your relay module only has one channel, you'll have just one IN pin. If you have four channels, you'll have four IN pins, and so on. The signal you send to the IN pins, determines whether the relay is active or not.

The relay is triggered when the input goes below about 2V. This means that you'll have the following scenarios:

- Normally Closed configuration (NC):

HIGH signal – current is flowing

LROBRYA

LOW signal – current is not flowing

- Normally Open configuration (NO):


HIGH signal – current is not flowing

LOW signal – current in flowing

You should use a normally closed configuration when the current should be flowing most of the times, and you only want to stop it occasionally.

Use a normally open configuration when you want the current to flow occasionally (for example, turn on a lamp occasionally).

Power Supply Selection



The second set of pins consists of GND, VCC, and JD-VCC pins.


The JD-VCC pin powers the electromagnet of the relay. Notice that the module has a jumper cap connecting the VCC and JD-VCC pins; the one shown here is yellow, but yours may be a different color.

LROBRYA

With the jumper cap on, the VCC and JD-VCC pins are connected. That means the relay electromagnet is directly powered from the ESP32 power pin, so the relay module and the ESP32 circuits are not physically isolated from each other.

Without the jumper cap, you need to provide an independent power source to power up the relay's electromagnet through the JD-VCC pin. That configuration physically isolates the relays from the ESP32 with the module's built-in optocoupler, which prevents damage to the ESP32 in case of electrical spikes.


Schematic



Warning: Use of high voltage power supplies may cause serious injury.

LROBRYA

Therefore, 5mm LEDs are used instead of high supply voltage bulbs in the experiment. If you're not familiar with mains voltage ask someone who is to help you out. While programming the ESP or wiring your circuit make sure everything is disconnected from mains voltage.



Installing the Library for ESP32

To build this web server, we use the [ESPAsyncWebServer library](#) and [AsyncTCP Library](#).

Installing the ESPAsyncWebServer library

Follow the next steps to install the [ESPAsyncWebServer library](#):



1. [Click here to download the ESPAsyncWebServer library](#). You should have a .zip folder in your Downloads folder
2. Unzip the .zip folder and you should get *ESPAsyncWebServer-master* folder
3. Rename your folder from *ESPAsyncWebServer-master* to *ESPAsyncWebServer*
4. Move the *ESPAsyncWebServer* folder to your Arduino IDE installation libraries folder

Alternatively, in your Arduino IDE, you can go to **Sketch > Include Library > Add .ZIP library...** and select the library you've just downloaded.

Installing the AsyncTCP Library for ESP32

The [ESPAsyncWebServer](#) library requires the [AsyncTCP](#) library to work.

Follow the next steps to install that library:

1. [Click here to download the AsyncTCP library](#). You should have a .zip folder in your Downloads folder
2. Unzip the .zip folder and you should get *AsyncTCP-master* folder
3. Rename your folder from *AsyncTCP-master* to *AsyncTCP*
4. Move the *AsyncTCP* folder to your Arduino IDE installation libraries folder



4. Finally, re-open your Arduino IDE

Alternatively, in your Arduino IDE, you can go to **Sketch > Include Library > Add .ZIP library...** and select the library you've just downloaded.

Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

After installing the required libraries, Open the code

Project_9_ESP32_Relay_Web_Server.ino in arduino IDE.

Before uploading the code, don't forget to insert your network credentials so that the ESP can connect to your local network.


```
const char* ssid = "REPLACE_WITH_YOUR_SSID";  
const char* password = "REPLACE_WITH_YOUR_SSID";
```

Demonstration

After making the necessary changes, upload the code to your ESP32.

Open the Serial Monitor at a baud rate of 115200 and press the ESP32 EN button to get its IP address. Then, open a browser in your local network and type the ESP32 IP address to get access to the web server.

LROBRYA



Serial monitor window showing the following text:

```
ets Jul 29 2019 12:21:46


rst:0x1 (POWERON_RESET), boot:0x13 (SPI_FAST_FLASH_BOOT)
configsip: 0, SPIWP:0xee
clk_drv:0x00, q_drv:0x00, d_drv:0x00, cs0_drv:0x00, hd_drv:0x00, wp_drv:0x00
mode:DIO, clock div:1
load:0x3fff0018, len:4
load:0x3fff001c, len:1044
load:0x40078000, len:8896
load:0x40080400, len:5816
entry 0x400806ac
Connecting to WiFi..
192.168.50.242
```

The line "192.168.50.242" is highlighted with a red box and an arrow pointing to it.

Note: Your browser and ESP32 should be connected to the same LAN.

You should get something as follows with as two buttons as the number of relays you've defined in your code.

Now, you can use the buttons to control your relays using your computer.




LROBRYA

Project 10 Output State Synchronization Web Server

This Project shows how to control the ESP32 or ESP8266 outputs using a web server and a physical button simultaneously. The output state is updated on the web page whether it is changed via physical button or web server.

Project Overview

Let's take a quick look at how the project works.



- The ESP32 or ESP8266 hosts a web server that allows you to control the state of an output;
- The current output state is displayed on the web server;



- The ESP is also connected to a physical pushbutton that controls the same output;
- If you change the output state using the physical pushbutton, its current state is also updated on the web server.
- In summary, this project allows you to control the same output using a web server and a push button simultaneously. Whenever the output state changes, the web server is updated.


Parts Required

Here's a list of the parts to you need to build the circuit:

- [ESP32 DEVKIT V1 Board](#)
- [5 mm LED](#)
- [220Ohm resistor](#)
- [Pushbutton](#)
- [10k Ohm resistor](#)
- [Breadboard](#)
- [Jumper wires](#)

Schematic

LROBRUYA



Installing the Library for ESP32

To build this web server, we use the [ESPAsyncWebServer library](#) and [AsyncTCP Library](#). (If you have already done this step, you can skip to the next step.)

Installing the ESPAsyncWebServer library

Follow the next steps to install the [ESPAsyncWebServer library](#):

1. [Click here to download the ESPAsyncWebServer library](#). You should have a .zip folder in your Downloads folder



2. Unzip the .zip folder and you should get *ESPAsyncWebServer-master*

folder

3. Rename your folder from *ESPAsyncWebServer-master* to

ESPAsyncWebServer

4. Move the *ESPAsyncWebServer* folder to your Arduino IDE installation

libraries folder

Alternatively, in your Arduino IDE, you can go to **Sketch > Include**

Library > Add .ZIP library... and select the library you've just

downloaded.

Installing the AsyncTCP Library for ESP32

The [ESPAsyncWebServer](#) library requires the [AsyncTCP](#) library to work.

Follow the next steps to install that library:

1. [Click here to download the AsyncTCP library](#). You should have a .zip folder in your Downloads folder

2. Unzip the .zip folder and you should get *AsyncTCP-master* folder

3. Rename your folder from *AsyncTCP-master* to *AsyncTCP*

4. Move the *AsyncTCP* folder to your Arduino IDE installation libraries folder

5. Finally, re-open your Arduino IDE

Alternatively, in your Arduino IDE, you can go to **Sketch > Include**



Library > Add .ZIP library... and select the library you've just downloaded.

Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

After installing the required libraries, Open the code

Project_10_Output_State_Synchronization_Web_Server.ino in arduino IDE.

Before uploading the code, don't forget to insert your network credentials so that the ESP can connect to your local network.

```
const char* ssid = "REPLACE_WITH_YOUR_SSID";  
const char* password = "REPLACE_WITH_YOUR_SSID";
```

How the Code Works

Button State and Output State

The ledState variable holds the LED output state. For default, when the web server starts, it is LOW.

```
int ledState = LOW; // the current state of the output pin
```



The buttonState and lastButtonState are used to detect whether the pushbutton was pressed or not.

```
int buttonState; // the current reading from the input pin
```

```
int lastButtonState = HIGH; // the previous reading from the input pin
```

Button (web server)

We didn't include the HTML to create the button on the the index_html variable.

That's because we want to be able to change it depending on the current LED state that can also be changed with the pushbutton.

So, we've create a placeholder for the button %BUTTONPLACEHOLDER% that will be replaced with HTML text to create the button later on the code (this is done in the processor() function).

```
<h2>ESP Web Server</h2>
```

```
%BUTTONPLACEHOLDER%
```

processor()

The processor() function replaces any placeholders on the HTML text with actual values. First, it checks whether the HTML texts contains any placeholders %BUTTONPLACEHOLDER%.

```
if(var == "BUTTONPLACEHOLDER") {
```



Then, call the `outputState()` function that returns the current output state.

We save it in the `outputStateValue` variable.

```
String outputStateValue = outputState();
```

After that, use that value to create the HTML text to display the button with the right state:

```
buttons += "<h4>Output - GPIO 2 - State <span  
id=\"outputState\"><span></h4><label class=\"switch\"><input  
type=\"checkbox\" onchange=\"toggleCheckbox(this)\" id=\"output\" \"  
+ outputStateValue + "><span class=\"slider\"></span></label>";
```

HTTP GET Request to Change Output State (JavaScript)

When you press the button, the `toggleCheckbox()` function is called. This function will make a request on different URLs to turn the LED on or off.

```
function toggleCheckbox(element) {  
  
  var xhr = new XMLHttpRequest();  
  
  if(element.checked){ xhr.open("GET", "/update?state=1", true); }  
  
  else { xhr.open("GET", "/update?state=0", true); }  
  
  xhr.send();}
```

To turn on the LED, it makes a request on the `/update?state=1` URL:

```
if(element.checked){ xhr.open("GET", "/update?state=1", true); }
```

Otherwise, it makes a request on the `/update?state=0` URL.



HTTP GET Request to Update State (JavaScript)

To keep the output state updated on the web server, we call the following function that makes a new request on the */state* URL every second.

```
setInterval(function () {  
  
    var xhttp = new XMLHttpRequest();  
  
    xhttp.onreadystatechange = function() {  
  
        if (this.readyState == 4 && this.status == 200) {  
  
            var inputChecked;  
  
            var outputStateM;  
  
            if( this.responseText == 1){  
  
                inputChecked = true;  
  
                outputStateM = "On";  
  
            }  
  
            else {  
  
                inputChecked = false;  
  
                outputStateM = "Off";  
  
            }  
  
            document.getElementById("output").checked = inputChecked;  
  
            document.getElementById("outputState").innerHTML =  
  
            outputStateM;  
        }  
    }  
}, 1000);
```



```
}

};

 xhttp.open("GET", "/state", true);

 xhttp.send();}, 1000 );
```

Handle Requests

Then, we need to handle what happens when the ESP32 or ESP8266 receives requests on those URLs.

When a request is received on the root / URL, we send the HTML page as well as the processor.

```
server.on("/", HTTP_GET, [](AsyncWebServerRequest*request){

request->send_P(200, "text/html", index_html, processor);});
```

The following lines check whether you received a request on the */update?state=1* or */update?state=0* URL and changes the ledState accordingly.

```
server.on("/update", HTTP_GET, [] (AsyncWebServerRequest *request)

{

String inputMessage;

String inputParam;

// GET input1 value on <ESP_IP>/update?state=<inputMessage>

if (request->hasParam(PARAM_INPUT_1)) {
```



```
inputMessage = request->getParam(PARAM_INPUT_1)->value();

inputParam = PARAM_INPUT_1;

digitalWrite(output, inputMessage.toInt());

ledState = !ledState;

}

else {

inputMessage = "No messag

inputParam = "none";

}

Serial.println(inputMessage);

request->send(200, "text/plain", "OK");});
```

When a request is received on the `/state` URL, we send the current output state:

```
server.on("/state", HTTP_GET, [] (AsyncWebServerRequest *request) {

request->send(200, "text/plain",

String(digitalRead(output)).c_str());});
```

loop()


In the `loop()`, we debounce the pushbutton and turn the LED on or off depending on the value of the `ledState` variable.

```
digitalWrite(output, ledState);
```



Demonstration

Upload the code to your ESP32 board. Then, open the Serial Monitor at a baud rate of 115200. Press the on-board EN/RST button to get its IP address.



The image shows a screenshot of a Serial Monitor window titled "COM7". The window has a "Send" button in the top right corner. The text area contains the following logs:

```
ets Jul 29 2019 12:21:46

rst:0x1 (POWERON_RESET), boot:0x13 (SPI_FAST_FLASH_BOOT)
configsip: 0, SPIWP:0xee
clk_drv:0x00, q_drv:0x00, d_drv:0x00, cs0_drv:0x00, hd_drv:0x00, wp_drv:0x00
mode:DIO, clock div:1
load:0x3fff0018, len:4
load:0x3fff001c, len:1044
load:0x40078000, len:8896
load:0x40080400, len:5816
entry 0x400806ac
Connecting to WiFi...
192.168.50.242
```

At the bottom of the window, there are buttons for "Autoscroll", "Newline", "115200 baud", and "Clear output". A red arrow points to the IP address "192.168.50.242" in the log.

Open a browser on your local network, and type the ESP IP address. You should have access to the web server as shown below.

Note: Your browser and ESP32 should be connected to the same LAN.

LROBRYA



You can toggle the button on the web server to turn the LED on.



You can also control the same LED with the physical pushbutton. Its state will always be updated automatically on the web server.

Project 11 ESP32 DHT11 Web Server

In this project, you'll learn how to build an asynchronous ESP32 web server with the DHT11 that displays temperature and humidity using Arduino IDE.



Prerequisites

The web server we'll build updates the readings automatically without the need to refresh the web page.

With this project you'll learn:

- How to read temperature and humidity from DHT sensors;
- Build an asynchronous web server using the [ESPAsyncWebServer library](#);
- Update the sensor readings automatically without the need to refresh the web page.

Asynchronous Web Server

To build the web server we'll use the [ESPAsyncWebServer library](#) that provides an easy way to build an asynchronous web server. Building an asynchronous web server has several advantages as mentioned in the library GitHub page,

such as:

- “Handle more than one connection at the same time”;
- “When you send the response, you are immediately ready to handle other connections while the server is taking care of sending the response in the background”;
- “Simple template processing engine to handle templates”;


Parts Required

LROBRUYA

To complete this tutorial you need the following parts:

- [ESP32 development board](#)
- [DHT11 Module](#)
- Breadboard
- [Jumper wires](#)

Schematic



Installing Libraries

You need to install a couple of libraries for this project:

- The [DHT](#) and the [Adafruit Unified Sensor Driver](#) libraries to read from the DHT sensor.



- [ESPAsyncWebServer](#) and [Async TCP](#) libraries to build the asynchronous web server.

Follow the next instructions to install those libraries:

Installing the DHT Sensor Library

To read from the DHT sensor using Arduino IDE, you need to install the [DHT sensor library](#). Follow the next steps to install the library.

1. [Click here to download the DHT Sensor library](#). You should have a .zip folder in your Downloads folder
2. Unzip the .zip folder and you should get *DHT-sensor-library-master* folder
3. Rename your folder from DHT-sensor-library-master to *DHT_sensor*
4. Move the *DHT_sensor* folder to your Arduino IDE installation libraries folder
5. Finally, re-open your Arduino IDE

Alternatively, in your Arduino IDE, you can go to **Sketch > Include Library > Add .ZIP library...** and select the library you've just downloaded.

Installing the Adafruit Unified Sensor Driver

You also need to install the [Adafruit Unified Sensor Driver library](#) to work with the DHT sensor. Follow the next steps to install the library.

1. [Click here to download the Adafruit Unified Sensor library](#). You should



have a .zip folder in your Downloads folder

2. Unzip the .zip folder and you should get *Adafruit_sensor-master* folder
3. Rename your folder from *Adafruit_sensor-master* to *Adafruit_sensor*
4. Move the *Adafruit_sensor* folder to your Arduino IDE installation libraries folder
5. Finally, re-open your Arduino IDE

Alternatively, in your Arduino IDE, you can go to **Sketch > Include Library > Add .ZIP library...** and select the library you've just downloaded.

Installing the ESPAsyncWebServer library

Follow the next steps to install the [ESPAsyncWebServer](#) library:

1. [Click here to download the ESPAsyncWebServer library](#). You should have a .zip folder in your Downloads folder
2. Unzip the .zip folder and you should get *ESPAsyncWebServer-master* folder
3. Rename your folder from *ESPAsyncWebServer-master* to *ESPAsyncWebServer*
4. Move the *ESPAsyncWebServer* folder to your Arduino IDE installation libraries folder

Alternatively, in your Arduino IDE, you can go to **Sketch > Include**



Library > Add .ZIP library... and select the library you've just downloaded.

Installing the Async TCP Library for ESP32

The [ESPAsyncWebServer](#) library requires the [AsyncTCP](#) library to work.

Follow the next steps to install that library:

1. [Click here to download the AsyncTCP library](#). You should have a .zip folder in your Downloads folder
2. Unzip the .zip folder and you should get *AsyncTCP-master* folder
3. Rename your folder from *AsyncTCP-master* to *AsyncTCP*
4. Move the *AsyncTCP* folder to your Arduino IDE installation libraries folder
5. Finally, re-open your Arduino IDE

Alternatively, in your Arduino IDE, you can go to **Sketch > Include Library > Add .ZIP library...** and select the library you've just downloaded.

Code

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

[Installing ESP32 Add-on in Arduino IDE](#)



After installing the required libraries, Open the code

Project_11_ESP32_DHT11_Web_Server.ino in arduino IDE.

Before uploading the code, don't forget to insert your network credentials so that the ESP can connect to your local network.

```
const char* ssid = "REPLACE_WITH_YOUR_SSID";
```

```
const char* password = "REPLACE_WITH_YOUR_SSID";
```

How the Code Works

In the following paragraphs we'll explain how the code works. Keep reading if you want to learn more or jump to the Demonstration section to see the final result.

Importing libraries

First, import the required libraries. The WiFi, ESPAsyncWebServer and the ESPAsyncTCP are needed to build the web server. The Adafruit_Sensor and the DHT libraries are needed to read from the DHT11 or DHT22 sensors.

```
#include "WiFi.h"  
  
#include "ESPAsyncWebServer.h"  
  
#include <ESPAsyncTCP.h>  
  
#include <Adafruit_Sensor.h>  
  
#include <DHT.h>
```



Variables definition

Define the GPIO that the DHT data pin is connected to. In this case, it's connected to GPIO 4.

```
#define DHTPIN 4 // Digital pin connected to the DHT sensor
```

Then, select the DHT sensor type you're using. In our example, we're using the DHT22. If you're using another type, you just need to uncomment your sensor and comment all the others.

```
#define DHTTYPE DHT11
```

```
// DHT 11
```

Instantiate a DHT object with the type and pin we've defined earlier.

```
DHT dht(DHTPIN, DHTTYPE);
```

Create an AsyncWebServer object on port 80.

```
AsyncWebServer server(80);
```

Read Temperature and Humidity Functions

We've created two functions: one to read the temperature. We've created two functions: one to read the temperature (readDHTTemperature()) and the other to read humidity (readDHTHumidity()).

```
String readDHTTemperature() {  
    // Sensor readings may also be up to 2 seconds 'old' (its a very slow  
    sensor)
```



```
// Read temperature as Celsius (the default)

float t = dht.readTemperature();

// Read temperature as Fahrenheit (isFahrenheit = true)

//float t = dht.readTemperature(true);

// Check if any reads failed and exit early (to try again).

if (isnan(t)) {

    Serial.println("Failed to read from DHT sensor!");

    return "--";

}

else {

    Serial.println(t);

    return String(t);

}
```

Getting sensor readings is as simple as using the readTemperature() and readHumidity() methods on the dht object.

```
float t = dht.readTemperature();

float h = dht.readHumidity();
```

We also have a condition that returns two dashes (--) in case the sensor fails to get the readings.



```
if (isnan(t)) {  
  
Serial.println("Failed to read from DHT sensor!");  
  
return "--";}
```

The readings are returned as string type. To convert a float to a string, use the `String()` function.

```
return String(t);
```

By default, we're reading the temperature in Celsius degrees. To get the temperature in Fahrenheit degrees, comment the temperature in Celsius and uncomment the temperature in Fahrenheit, so that you have the following:


```
float t = dht.readTemperature();  
  
// Read temperature as Fahrenheit (isFahrenheit = true)  
  
//float t = dht.readTemperature(true);
```

Upload the Code

Now, upload the code to your ESP32. Make sure you have the right board and COM port selected. Upload code reference steps.

After uploading, open the Serial Monitor at a baud rate of 115200. Press the ESP32 reset button. The ESP32 IP address should be printed in the serial monitor.

LROBRYA



Serial monitor window showing the ESP32 boot process and WiFi connection. The text in the window is:

```
ets Jul 29 2019 12:21:46

rst:0x1 (POWERON_RESET), boot:0x13 (SPI_FAST_FLASH_BOOT)
configsip: 0, SPIWP:0xee
clk_drv:0x00, q_drv:0x00, d_drv:0x00, cs0_drv:0x00, hd_drv:0x00, wp_drv:0x00
mode:DIO, clock div:1
load:0x3fff0018, len:4
load:0x3fff001c, len:1044
load:0x40078000, len:8896
load:0x40080400, len:5816
entry 0x400806ac
Connecting to WiFi...
192.168.50.242
```

The line "192.168.50.242" is highlighted with a red box and an arrow pointing to it.

Demonstration

Open a browser and type the ESP32 IP address. Your web server should display the latest sensor readings.

Note: Your browser and ESP32 should be connected to the same LAN.

Notice that the temperature and humidity readings are updated automatically without the need to refresh the web page.




Project 12 ESP32_OLED_Display

This project shows how to use the 0.96 inch SSD1306 OLED display with ESP32 using Arduino IDE.

Introducing 0.96 inch OLED Display

The [OLED display](#) that we'll use in this tutorial is the SSD1306 model: a monicolor, 0.96 inch display with 128×64 pixels as shown in the following figure.




The OLED display doesn't require backlight, which results in a very nice contrast in dark environments. Additionally, its pixels consume energy only when they are on, so the OLED display consumes less power when compared to other displays.

LROBRUYA

Because the OLED display uses I2C communication protocol, wiring is very simple. You can use the following table as a reference.

OLED Pin	ESP32
Vin	3.3V
GND	GND
SCL	GPIO 22
SDA	GPIO 21

Schematic



LROBRYA


Installing SSD1306 OLED Library – ESP32

There are several libraries available to control the OLED display with the ESP32.


In this tutorial we'll use two Adafruit libraries: [Adafruit_SSD1306 library](#) and [Adafruit_GFX library](#).

Follow the next steps to install those libraries.

1. Open your Arduino IDE and go to **Sketch > Include Library > Manage Libraries**. The Library Manager should open.
2. Type “**SSD1306**” in the search box and install the SSD1306 library from Adafruit.



3. After installing the SSD1306 library from Adafruit, type “**GFX**” in the search box and install the library.



4. After installing the libraries, restart your Arduino IDE.

Code

After installing the required libraries, Open the code

Project_12_ESP32_OLED_Display.ino in arduino IDE.

We'll program the ESP32 using Arduino IDE, so make sure you have the ESP32 add-on installed before proceeding:(If you have already done this step, you can skip to the next step.)

Installing ESP32 Add-on in Arduino IDE

```
#include <Wire.h>
```

```
#include <Adafruit_GFX.h>
```

```
#include <Adafruit_SSD1306.h>
```

```
#define SCREEN_WIDTH 128 // OLED display width, in pixels
```



```
#define SCREEN_HEIGHT 64 // OLED display height, in pixels

// Declaration for an SSD1306 display connected to I2C (SDA, SCL pins)

Adafruit_SSD1306 display(SCREEN_WIDTH, SCREEN_HEIGHT,
&Wire, -1);

void setup() {
Serial.begin(115200);

if(!display.begin(SSD1306_SWITCHCAPVCC, 0x3C)) { // Address
0x3D for 128x64

Serial.println(F("SSD1306 allocation failed"));

for(;;);

}

delay(2000);

display.clearDisplay();

display.setTextSize(2);

display.setTextColor(WHITE);

display.setCursor(0, 30);

// Display static text

display.println("LONTEN");

display.display();

delay(100);
```



```
}
```

```
void loop() {  
  
    // Scroll in various directions, pausing in-between:  
  
    display.startscrollright(0x00, 0x0F);  
  
    delay(7000);  
  
    display.stopscroll();  
  
    delay(1000);  
  
    display.startscrollleft(0x00, 0x0F);  
  
    delay(7000);  
  
    display.stopscroll();  
  
    delay(1000);  
  
}
```

How the Code Works

Importing libraries

First, you need to import the necessary libraries. The Wire library to use I2C and the Adafruit libraries to write to the display: Adafruit_GFX and Adafruit_SSD1306.

```
#include <Wire.h>  
  
#include <Adafruit_GFX.h>  
  
#include <Adafruit_SSD1306.h>
```



Initialize the OLED display

Then, you define your OLED width and height. In this example, we're using a 128×64 OLED display. If you're using other sizes, you can change that in the SCREEN_WIDTH, and SCREEN_HEIGHT variables.

```
#define SCREEN_WIDTH 128 // OLED display width, in pixels
```

```
#define SCREEN_HEIGHT 64 // OLED display height, in pixels
```

Then, initialize a display object with the width and height defined earlier with I2C communication protocol (&Wire).

```
Adafruit_SSD1306 display(SCREEN_WIDTH, SCREEN_HEIGHT,  
&Wire, -1);
```

The (-1) parameter means that your OLED display doesn't have a RESET pin. If your OLED display does have a RESET pin, it should be connected to a GPIO. In that case, you should pass the GPIO number as a parameter.

In the setup(), initialize the Serial Monitor at a baud rate of 115200 for debugging purposes.

```
Serial.begin(115200);
```

Initialize the OLED display with the begin() method as follows:

```
if(!display.begin(SSD1306_SWITCHCAPVCC, 0x3C)) {  
    Serial.println("SSD1306 allocation failed");
```



```
for(;;) // Don't proceed, loop forever}
```

This snippet also prints a message on the Serial Monitor, in case we're not able to connect to the display.

```
Serial.println("SSD1306 allocation failed");
```

In case you're using a different OLED display, you may need to change the OLED address. In our case, the address is 0x3C.

```
if(!display.begin(SSD1306_SWITCHCAPVCC, 0x3C)) {
```

After initializing the display, add a two second delay, so that the OLED has enough time to initialize before writing text:

```
delay(2000);
```

Clear display, set font size, color and write text

After initializing the display, clear the display buffer with the `clearDisplay()` method:

```
display.clearDisplay();
```

Before writing text, you need to set the text size, color and where the text will be displayed in the OLED.

Set the font size using the `setTextSize()` method:

```
display.setTextSize(1);
```

Set the font color with the `setTextColor()` method:

```
display.setTextColor(WHITE);
```



WHITE sets white font and black background.

Define the position where the text starts using the `setCursor(x,y)` method.

In this case, we're setting the text to start at the (0,0) coordinates – at the top left corner.

```
display.setCursor(0,0);
```

Finally, you can send the text to the display using the `println()` method, as follows:

```
display.println("LONTEN");
```

Then, you need to call the `display()` method to actually display the text on the screen.

```
display.display();
```

The Adafruit OLED library provides useful methods to easily scroll text.

`startscrollright(0x00, 0x0F)`: scroll text from left to right

`startscrollleft(0x00, 0x0F)`: scroll text from right to left

`startscrolldiagright(0x00, 0x07)`: scroll text from left bottom corner to right upper corner

`startscrolldiagleft(0x00, 0x07)`: scroll text from right bottom corner to left upper corner

Upload the Code

Now, upload the code to your ESP32.

LROBRUYA

After uploading the code, the OLED will display scrolling text.

