Check resistance between ECT sensor terminals.

. ECT sensor may be checked in situ if engine temperature and resistance readings are compared.









































































































