







	Pushbuttons				
	SWO	SW1	SW2	SW3	
GND					
RXD					
TXD					
AT90S2333/AT90S4433	LEDS LEDO		ATtiny15		
	LED1				
	LED2				
	LED3				
	LED4 LED5				
	LEDS	Charging B1			
	_				
	AVR® Ba	ttery Charger			
PC3 PC4 PC5	Reference				
IBAT2 PWM2 VBAT2	Power	SUPPly RESET	PWM1 VBAT1	IBAT1	
AREF	Vcc !	5V ok			
	VIN				
	1 2.11				
	AGND				

