TEENSY CONVOLUTION MAIN IQ BOARD

Part ITEMS

ENC_2 ALPS_EC12E_SW

ENC_3 ALPS_EC12E_SW

ENC_TUNE ALPS_EC12E_SW

FB1 FB2 FB3 FERRITE BEAD 1206

FUSE 1206

PCA9674 SOIC16R

C1 C2 C3 C4 C5 C6 1206 10NF - NC

C7 C8 C9 C11 C2 C14 100NF 1206

C10 C13 C16 10Uf 1206


R1 R2 R3 R4 R5 R6 R11 R12 R13 R14 R15 R16 R19 R20 R23 1206 100 OHM

R21 R22 1206 10K


R7 R8 R9 1206 100 OHM - JUMPER 0 OHM

R10 1206 2 K

RG1 3V3 SOT223





EA8DGL FW / EA7GIB PCB / EB5DXJ STL 3D BOX --- Mod for MSi0001 / QSD IQ PCB – 06/2020 V1.0 DOC **DD4WH https://github.com/DD4WH/Teensy-ConvolutionSDR**




EA8DGL FW / EA7GIB PCB / EB5DXJ STL 3D BOX --- Mod for MSi0001 / QSD IQ PCB – 06/2020 V1.0 DOC **DD4WH** https://github.com/DD4WH/Teensy-ConvolutionSDR

DAC PCM5102A MOD TO VCC Vin **3V3** NC GND GND FLT GND GND **DMP** R 23/100 Ohm SCL GND **BCK** 21 7 DIN LCK 20 **FMT** GND XMT 3V3







Mod. MUX for SW @EA8DGL FW

R17/R18 NC

SJ1-SJ3 CLOSE


Only for QSD IQ PCB - SOFT S0 PIN 2 / S1 PIN 3 del T4 00 de 0-4 mhz 01 de 4 a 9 mhz 10 de 9 a 16 mhz 11 > 16 mhz

Only for MSi001 PCB - SOFT msi001_cs_pin = 1

msi001_dat_pin = 2

 $msi001_clk_pin = 3$

EA8DGL FW / EA7GIB PCB / EB5DXJ STL 3D BOX --- Mod for MSi0001 / QSD IQ PCB – 06/2020 V1.0 DOC **DD4WH https://github.com/DD4WH/Teensy-ConvolutionSDR**



EA8DGL FW / EA7GIB PCB / EB5DXJ STL 3D BOX --- Mod for MSi0001 / QSD IQ PCB – 06/2020 V1.0 DOC **DD4WH** https://github.com/DD4WH/Teensy-ConvolutionSDR