
VRP远程管理




前言

如果企业网络中有一台或多台网络设备需要远程进行配置和管理,管理员可以使用Telnet远程连接到每一台设备上,对这些网络设备进行集中的管理和维护。



允许终端远程登录到任何可以充当Telnet服务器的设备。

Telnet服务器和终端之间无需直连,只需保证两者之间可以互相通信即可。




认证模式

AAA 登陆时需要用户名和密码		
Password 登录时只需要密码	登录时只需要密码	

配置命令:

user-interface vty 0 4	进入VTY配置模式
authentication-mode password/aaa	配置认证模式
set authentication password cipher Huawei	配置认证密码
user privilege level 15	配置用户级别
user-interface maximum-vty 15	配置最大VTY会话数量
aaa	进入AAA配置模式
local-user wakin password cipher Huawei	创建本地用户和密码
local-user wakin privilege level 15	配置用户级别
local-user wakin service-type telnet	配置用户可用服务

Telnet 配置 – Password 方式



[Huawei]user-interface vty 0 4


[Huawei-ui-vty0-4]authentication-mode password

[Huawei-ui-vty0-4]set authentication password cipher Huawei

[Huawei-ui-vty0-4]user privilege level 15

[Huawei]user-interface maximum-vty 15

Telnet 配置 – AAA 方式



[Huawei]user-interface vty 0 4

[Huawei-ui-vty0-4]authentication-mode aaa

Info: The password was cleared.


[Huawei]aaa

[Huawei-aaa]local-user wakin password cipher Huawei.com

[Huawei-aaa]local-user wakin privilege level 15

[Huawei-aaa]local-user wakin service-type telnet

Telnet 验证



Login authentication
Password:

Info: The max number of VTY users is 10, and the number
 of current VTY users on line is 1.

The current login time is 2013-04-19 16:32:00.

<Huawei>



总结

● 如果网络设备已经配置完成Telnet服务,但是用户仍然不能实现远程访问,原因可能是什么?