

1. Overview

The AquaFlow 200 is a countertop water filter pitcher with a 2.5 liter capacity and a replaceable 3-stage carbon filter cartridge. It removes chlorine taste and odor, sediment, and reduces trace levels of lead and mercury. Each filter cartridge is rated for approximately 150 liters or two months of typical household use, whichever comes first.

2. Setup Instructions

Before first use, remove the filter cartridge from its plastic wrapping and soak it in cold water for 15 minutes. Rinse the cartridge under running tap water for 30 seconds to clear any loose carbon dust. Insert the cartridge into the funnel housing until it clicks into place. Run two full pitcher cycles of tap water through the filter and discard this water before drinking any filtered water, as the first cycles may contain residual carbon fines.

3. Daily Operation

Fill the upper reservoir with tap water up to the marked fill line. Do not use water from an unregulated well or water that has not been tested for microbiological safety, as the AquaFlow 200 is not certified to remove bacteria or viruses. A full reservoir takes approximately 8 to 10 minutes to filter completely into the lower pitcher. The lower pitcher holds 2.5 liters. Do not force the reservoir lid closed while filtering is in progress, as this can cause overflow.

4. Filter Replacement

The filter status indicator on the lid turns from green to red when replacement is due. To replace the cartridge, twist it counterclockwise a quarter turn and lift it out of the funnel housing. Dispose of the old cartridge according to local recycling guidelines; do not puncture or burn it. Follow the same soak-and-rinse procedure from Section 2 for the new cartridge before reinserting it. Reset the status indicator by holding the reset button on the lid for 3 seconds until it blinks green twice.

5. Cleaning and Maintenance

Wash the pitcher, lid, and reservoir by hand with warm water and mild dish soap every two weeks. Do not use abrasive scouring pads, as they can scratch the plastic and harbor bacteria. The pitcher body is not dishwasher safe; the lid and reservoir top rack are dishwasher safe. Never immerse the filter cartridge itself in soapy water. Wipe the cartridge housing with a damp cloth only.

6. Troubleshooting

If water filters slower than usual, the cartridge may be nearing the end of its life or may be clogged with sediment; try rinsing it under running water for one minute. If filtered water has a plastic taste after setup, repeat the two discard cycles described in Section 2. If the status indicator does not light up at all, check that the two AAA batteries in the lid compartment are inserted with correct polarity. If water leaks from the base, confirm the lower pitcher is fully seated and the gasket ring is not twisted.

7. Safety Warnings

Do not use hot or carbonated water in the AquaFlow 200; it is rated for cold tap water only, between 4 and 30 degrees Celsius. Keep the unit out of direct sunlight to prevent algae growth in the reservoir. This product is not a substitute for emergency water disinfection during a boil-water advisory. Keep small parts, including the filter cartridge wrapping, away from children.