

GPS Time Sync User Guide

Installing, configuring, and operating GPS Time Sync 1.20

Version 1.20 | Windows desktop utility | VK-172 USB GPS receiver

Last changed: July 17, 2026

Table of Contents

Purpose	3
What You Need	3
Quick Start	3
Main Window.....	3
Synchronization Settings.....	4
Tray Operation	5
Logging	5
Troubleshooting.....	5
Files Installed or Used	5

Purpose

GPS Time Sync is a Windows utility that reads trusted NMEA time from a GPS receiver and corrects the Windows system clock when the configured drift threshold is reached. The application is written primarily for the VK-172 USB GPS dongle, with manual COM-port selection available for other compatible NMEA receivers.

Administrator rights required. Windows protects system clock changes. Run GPS Time Sync as administrator when you expect the program to correct the computer clock.

What You Need

Item	Requirement
Operating system	Microsoft Windows
GPS receiver	VK-172 USB GPS dongle recommended
Receiver output	Valid NMEA sentences; RMC, GGA, and GSV are used by the program
Typical serial speed	9600 baud
Privileges	Administrator rights for clock correction

Quick Start

1. Plug the VK-172 GPS dongle into the computer.
2. Start GPS Time Sync. On first use, the main form appears so settings can be reviewed.
3. Confirm the selected COM port. If the receiver is not detected, choose the COM port shown in Windows Device Manager.
4. Confirm the baud rate. The usual value for the VK-172 is 9600 baud.
5. Choose Set Local or Set UTC.
6. Set the comparison interval and drift threshold.
7. Click Save to apply the current settings and reopen the selected serial port.
8. Leave the application running or click Hide To Tray.

Main Window

The main window displays GPS position, fix status, satellite counts, the GPS-derived date/time, synchronization settings, and the live log window.

GPS Time Sync
Version 1.20 02/01/2026 17:41

Current Date: 5/27/2026 Current Time: 16:16:45

Latitude and Longitude: Fix quality: None Satellites in use: 4

Approximate Elevation: Note: This changes with satellite movement Fix mode: None Satellites in view: 11

Sync Settings

COM Port: COM3 Interval (Seconds): 60 Drift ≥: 2

UTC/Local Time: ☐ Set UTC ☒ Set Local

Enable Logging: ☒

Baud Rate: 9600

Logging

```
$GPGSAA,1,20,29,15,05,62.03,58.06,21.82*3D
$GPGSV,3,1,11,05,33,055,33,10,05,264,11,02,122,15,83,055,34*71
$GPGSV,3,2,11,18,50,325,19,20,53,049,35,21,08,068,23,33,283,19*72
$GPGSV,3,3,11,24,22,151,22,29,51,213,21,30,02,040,*43
$GPGLL,201646.00,V,N*4D
```

Hide To Tray Save Close

GPS Time Sync 1.20 main window

Area	What it means
Latitude and Longitude	Current GPS position when a valid fix is available.
Fix quality	GPS, DGPS, RTK, Float RTK, or None based on GGA fix quality.
Fix mode	GPS when RMC status is valid; None when it is not.
Satellites in use	Number of satellites used for the current fix.
Satellites in view	Visible satellites reported by GSV messages.
Approximate elevation	Altitude converted from meters to feet; normal GPS variation is expected.
Current Date / Current Time	GPS-derived time shown as local or UTC according to the selected mode.
Logging window	Incoming NMEA data when logging is enabled, plus diagnostic messages.

Synchronization Settings

Setting	Use
COM Port	The serial port assigned to the GPS receiver.
Interval (Seconds)	How often the program compares Windows time to GPS time.
Drift >=	The allowed difference, in seconds, before correction is attempted.
Set UTC	Sets Windows system UTC directly from GPS UTC.
Set Local	Converts GPS UTC through Windows time-zone rules and sets local time.

Setting	Use
Enable Logging	Shows incoming NMEA sentences in the log window for troubleshooting.
Baud Rate	Displayed serial speed currently applied to the port.

Save behavior. In the current source, Save applies the interval, closes and reopens the serial port, and logs 'Settings saved'. It does not write persistent settings to an INI file.

Tray Operation

GPS Time Sync can run quietly from the system tray. Click Hide To Tray to hide the main window while keeping the program active. Click the tray icon to restore the main window.

Logging

Log	Purpose
Logging window	Shows live NMEA sentences when Enable Logging is checked.
GPSTimeChange.log	Records startup, shutdown, setting changes, time updates, and relevant errors beside the executable.
Maximum visible lines	The log window retains up to 500 lines while the application is running.

Troubleshooting

Problem	What to do
VK-172 not detected	Reconnect the receiver, open Device Manager, identify the COM port, select it manually, and click Save.
Cannot open COM port	Check that the selected COM port is correct and that no other program is using it.
Clock does not update	Run as administrator, confirm valid GPS time is being received, and check GPSTimeChange.log.
Elevation changes	This is normal. GPS altitude fluctuates with satellite geometry.
No NMEA lines shown	Confirm Enable Logging is checked and that the GPS receiver has a clear view of the sky.

Files Installed or Used

File or folder	Description
GPSTimeSync.exe	Main application executable.
Help\index.html	HTML help entry point opened by the Help button.
GPSTimeChange.log	Time-change and diagnostic log written beside the executable.

File or folder	Description
GPSTimeSync.lock	Single-instance lock file used while the application is running.
EULA.txt	End User License Agreement.