

Service Parts Catalog - Parte 4

HP LaserJet Series

TechGuide IA — Consulta Inteligente de Manuais HP

Figure 5-1321 Release the support shaft 1 2 2. Remove the support shaft. Figure 5-1322 Remove the support shaft 3. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Remove the cartridge door assembly 1207

Figure 5-1323 Remove the guide 2 1 4. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-1324 Release the pressure-release link 1 2 5. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. 1208 Chapter 5 Removal and replacement

Figure 5-1325 Release the door 3 1 2 6. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-1326 Release the left-side retainer arm Remove the cartridge door assembly 1209

7. Remove the door. Figure 5-1327 Remove the door 13. Remove the right cover Follow these steps to remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. 1. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-1328 Locate the tabs and bosses 1210 Chapter 5 Removal and replacement

2. Remove two screws (callout 1). Figure 5-1329 Remove two screws 1 3. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-1330 Release one boss 4. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Remove the right cover 1211

Figure 5-1331 Release two bosses 5. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-1332 Release one tab 6. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. 1212 Chapter 5 Removal and replacement

Figure 5-1333 Release one tab 7. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-1334 Remove the cover 2 1 3 14. Remove the left cover Follow these steps to remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. Remove the left cover 1213

1. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-1335 Locate of the tabs and bosses 2. Remove one screw (callout 1). Figure 5-1336 Remove one screw 1 1214 Chapter 5 Removal and replacement

3. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-1337 Release one boss and three tabs 2 1 4. At the bottom edge of the cover, release two tabs. Figure 5-1338 Release two tabs 5. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. Remove the left cover 1215

Figure 5-1339 Remove the cover 1 2 15. Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645) Follow these steps to remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645). NOTE: The ISA includes the document feeder, sub-scanner assembly (SSA), and the scanner control board (SCB). 1. Remove one screw (callout 1). IMPORTANT: This screw fastens the ISA ground plate to the printer chassis. Do not lose this screw. Figure 5-1340 Remove one screw 1 1216 Chapter 5 Removal and replacement

2. Disconnect three connectors (callout 1), pass the wire harnesses and cables through the opening in the cover (callout 2), and then release them from the retainers (callout 3). NOTE: One cable (callout 4) does not need to pass through the opening in the cover. TIP: It might be easier if the WiFi PCA and holder (not all models; callout 5) is detached from the printer, and then moved out of the way. Figure 5-1341 Disconnect cables and connectors 4 1 2 3 5 3. Disconnect three connectors (callout 1), and then remove six screws (callout 2). Figure 5-1342 Disconnect connectors and remove screws 1 2 Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645) 1217

4. Slightly slide the ISA towards the back of the printer to release it. Figure 5-1343 Slide the ISA towards the back of the printer 5. Remove the ISA. Figure 5-1344 Remove the ISA 16. Remove the top cover (M527/E52545/M528/E52645) Follow these steps to remove the top cover (M527/E52545/M528/E52645). 1218 Chapter 5 Removal and replacement

1. At the front right of the printer, remove one screw (callout 1), and then remove the sheet-metal plate (callout 2). Figure 5-1345 Remove one screw and the plate 1 2 2. At the top rear of the printer, remove three screws (callout 1). Figure 5-1346 Remove three screws 1 3. At the top front of the printer, remove three screws (callout 1). NOTE: The screw (callout 2) on the lower-right portion of the cover is a different color than the other two screws, and is surrounded by sheet-metal. It might appear that this screw does not need to be removed. Remove this screw. Remove the top cover (M527/E52545/M528/E52645) 1219

Figure 5-1347 Remove three screws 1 2 4. At the front left of the printer, release one boss. Figure 5-1348 Release one boss 5. Rotate the front of the cover up and away from the printer. CAUTION: As the cover is rotated up, carefully pass the cables and wire harnesses the hole in the cover (callout 1). 1220 Chapter 5 Removal and replacement

Figure 5-1349 Rotate the front of the cover up 1 6. Remove the cover. Figure 5-1350 Remove the cover 17. Remove the top cover (M501/M506/E50045/M507/E50145) Follow these steps to remove the top cover (M501/M506/E50045/M507/E50145). The M506x/E50045x is shown in this procedure. However, the steps are correct for all M506/E50045/ M507/E50145 models and the M501 printer. Remove the top cover (M501/M506/E50045/M507/E50145) 1221

1. Remove two screws (callout 1). Figure 5-1351 Remove two screws 1 2. M506/E50045/ only: Release one cable retainer from the chassis. TIP: Depress the tab on the retainer to release it. Figure 5-1352 Release one cable retainer 1222 Chapter 5 Removal and replacement

3. M507/E50145 only: Disconnect two connectors. Figure 5-1353 Disconnect two connectors 4. Release one boss. Figure 5-1354 Release one boss 5. M506/E50045/ only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M506x/E50045x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Remove the top cover (M501/M506/E50045/M507/E50145) 1223

Figure 5-1355 Remove the cover (M506/E50045) 1 6. M507/E50145only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M507x/E50145x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). IMPORTANT: If the top cover is being replaced, make sure to transfer the WiFi PCA from the discarded cover to the replacement cover. NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-1356 Remove the cover (M507/E50145) 1 1224 Chapter 5 Removal and replacement

18. Remove the paper delivery tray (output bin) Follow these steps to remove the paper delivery tray (output bin). NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. 1. Release two tabs (callout 1), and then slide the cover toward the front of the printer (callout 2). Figure 5-1357 Release two tabs 1 2 1 2. Remove the bin. Figure 5-1358 Remove the bin 19. Remove the formatter case Follow these steps to remove the formatter case. Remove the paper delivery tray (output bin) 1225

1. M506/E50045/M507/E50145 only: Remove two screws (callout 1), and then remove the sheet-metal plate (callout 2). NOTE: M507/E50145 only: The M507/E50145 sheet-metal plate includes a separate black plastic cable guide (not shown). Do not lose the guide when removing the plate. Figure 5-1359 Remove the sheet-metal plate 2 1 2. Carefully pass all cables and wire harnesses through the opening in the formatter case. NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. Figure 5-1360 Pass all cables and wire harnesses through the opening 1226 Chapter 5 Removal and replacement

3. Remove one screw (callout 1), and then push down on one tab (callout 2) to release it. Figure 5-1361 Remove one screw 1 2 4. Remove the guide. Figure 5-1362 Remove the guide Remove the formatter case 1227

5. Remove four screws (callout 1). Figure 5-1363 Remove four screws 1 6. Remove five screws (callout 1). Figure 5-1364 Remove five screws 1 1228 Chapter 5 Removal and replacement

7. Disconnect one connector (callout 1), and then move the guide out of the way (callout 2). Figure 5-1365 Disconnect one connector 2 1 8. Slightly lift up the formatter case (callout 1), rotate the top of the case away from the chassis (callout 2), and then lift up the case to release it (callout 3). CAUTION: Pass the FFC through the opening (callout 4) in the formatter while removing the case. Figure 5-1366 Release the formatter case 2 3 1 4 9. Remove the formatter case. NOTE: WiFi models only: If the formatter case is being replaced, make sure that the WiFi PCA and bracket (callout 1) are transferred to the replacement case. Remove the formatter case 1229

Figure 5-1367 Remove the formatter case 1 20. Remove the LVPS Follow these steps to remove the LVPS. 1. Remove one screw (callout 1), and then move the power-switch assembly (callout 2) out of the way. Figure 5-1368 Move the power-switch assembly 1 2 1230 Chapter 5 Removal and replacement

2. Disconnect one connector (callout 1), and then release the wire harness from the guide (callout 2). Figure 5-1369 Disconnect one connector 1 2 3. Disconnect two connectors (callout 1). TIP: Squeeze the locking lever on the lower connector to release it. Figure 5-1370 Disconnect two connectors 1 Remove the LVPS 1231

4. Remove two screws (callout 1). Figure 5-1371 Remove two screws 1 5. Release one tab (callout 1), and then rotate the top of the LVPS out and away from the printer (callout 2). Figure 5-1372 Release one tab 1 2 6. Slide the LVPS up and away from the printer to release it. Reinstallation tip: Push down on the LVPS to make sure that it is fully seated on the holder. 1232 Chapter 5 Removal and replacement

Figure 5-1373 Release the LVPS 7. Remove the LVPS. Figure 5-1374 Remove the LVPS 21. Remove the fan (FM2) Follow these steps to remove the fan (FM2). Remove the fan (FM2) 1233

1. Disconnect one connector (callout 1), and then release the wire harness from the retainer (callout 2). Figure 5-1375 Disconnect one connector 1 2 2. Release two tabs (callout 1), and then rotate the top of the fan out and away from the printer (callout 2). Figure 5-1376 Release two tabs 2 1 3. Remove the fan. CAUTION: When reinstalled the fan must draw air into the printer. Make sure that the two arrows embossed on the right side of the fan body face downward and into the printer. 1234 Chapter 5 Removal and replacement

Figure 5-1377 Remove the fan 22. Remove the fuser power supply (FPS) Follow these steps to remove the fuser power supply (FPS). TIP: The FPS includes the optional paper feeder connector (Jetlink accessory tray connector) . 1. Disconnect three connectors (callout 1). Figure 5-1378 Disconnect three connectors 1 Remove the fuser power supply (FPS) 1235

2. Remove one screw (callout 1). Figure 5-1379 Remove one screw 1 3. Disconnect the tray accessory connector (circle callout) and release the wire harness from the guide. 4. Release four tabs. TIP: It might be easier to release the upper two tabs by using a small flat-blade screw driver. 1236 Chapter 5 Removal and replacement

Figure 5-1380 Release four tabs 5. Rotate the left end of the assembly out and away from the printer (callout 1), slide the assembly to the left to release the right side alignment pins (callout 2), and then remove the assembly. Figure 5-1381 Remove the assembly 1 2 23. Remove internal cable and holder brackets Follow these steps to remove internal cable and holder brackets. IMPORTANT: It is recommended to bring the printer back to the shop to perform the following removal and replacement repairs. NOTE: Lay the engine on its left side to make removal or the following parts easier. Remove internal cable and holder brackets 1237

1. Remove one (1) screw from the upper cable bracket. NOTE: The upper cable bracket assembly does not need to be completely removed, simply detached and then moved up out of the way and placed on the top of the printer. 2. Remove the cable routing from the upper cable bracket. 3. Lift up on the left side of the cable bracket (callout 1) and slide the bracket towards the front of the printer (callout 2) to remove the bracket. 1 2 1238 Chapter 5 Removal and replacement
4. Remove the fuser power supply bracket (small lower rear bracket) by pulling in the upper and left side of the bracket and lifting it from the printer. 5. Remove the cables from the lower front cable bracket. Remove internal cable and holder brackets 1239
6. Remove three (3) screws (callout 1) from the bracket assembly. 1 7. Gently pry up the two (2) tabs on the lower right side of the bracket to remove the bracket from the printer. 1240 Chapter 5 Removal and replacement
8. Remove two (2) screws (callout 1) from the metal M1 motor shield and remove the shield from the printer. 1 9. Remove the yellow cable from the cable bracket guide. 10. Remove two (2) screws (callout 1) and then remove the cable bracket located to the right of the main motor, M1. NOTE: Carefully lift off the bracket to ensure that the clutch on the back of the guide does not fall off when removing. Remove internal cable and holder brackets 1241
- 1 24. Remove the delivery assembly Follow these steps to remove the delivery assembly. IMPORTANT: It is recommended to bring the printer back to the shop to perform the following removal and replacement repairs. NOTE: Lay the engine on its left side to make removal or the following parts easier. 1. After removing the cable guide, access the 3 screws for the main drive metal cover and remove. Figure 5-1382 Remove main gear drive metal cover 1242 Chapter 5 Removal and replacement
2. Carefully pull up on and remove the duplex gear to access the screws underneath. Figure 5-1383 Remove gear TIP: Note the position of the solenoid on the lower right of the gear for reassembly. 3. Remove two (2) screws (callout 1) from the left side of the engine and set the engine up on the feet. IMPORTANT: Ask someone to hold the main gear assembly (callout 2) in place so the gears do not fall off when the engine is set up. Figure 5-1384 Remove screws 2 1 Remove the delivery assembly 1243
4. Release one tab (callout 1), and then remove the fan duct (callout 2). Figure 5-1385 Remove the fan duct 1 2 5. Remove 3 screws from the delivery assembly. Figure 5-1386 Remove 3 screws 1244 Chapter 5 Removal and replacement
6. Unplug the delivery assembly connector. Figure 5-1387 Unplug the connector 7. Remove the delivery assembly by slightly pulling the chassis sides apart. Figure 5-1388

Remove the delivery assembly

IMPORTANT: Save the drive gear from the old paper delivery assembly to put on the new one. 25. Installation special instructions Use these specific steps when installing the new delivery assembly. Installation special instructions 1245

1. On installation of the new part, make sure the gears on the new delivery assembly do not fall off before installing since they are not held in by screws. NOTE: Make sure to move the drive gear from the old paper delivery assembly to the new one. Figure 5-1389 Delivery drive gear
2. On installation, make sure the main drive gear train does not fall off. Pay special attention to the duplex gear from the removal step, make sure the solenoid is in the right position when installing the gear. Figure 5-1390 Check solenoid 3. Follow the removal steps in reverse order to install all parts that were removed from the printer. 26. Unpack the replacement assembly Follow these steps to unpack the replacement assembly. 1246 Chapter 5 Removal and replacement
1. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 2. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. NOTE: If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. 3. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Remove and replacement: Trays Learn how to remove and replace the printer trays. Removal and replacement: Tray 2 Learn how to remove and replace Tray 2. To view a short video of this procedure, click the link below. View a video of how to remove and replace Tray 2. Mean time to repair: 5 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Remove and replacement: Trays 1247

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-46 Part information

Part number Part description

RM2-5690-000CN Cassette (Tray 2) assembly

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Print a page from Tray 2 to make sure that the paper feeder is functioning correctly. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-1391 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it.

NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. 1248 Chapter 5 Removal and replacement

Figure 5-1392 Release and remove the tray 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Tray 3 Learn how to remove and replace Tray 3. To view a short video of this procedure, click the link below. Removal and replacement: Tray 3 1249

View a video of how to remove and replace Tray 3. Mean time to repair: 5 minutes Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-47 Part information

Part number Part description

RM2-5758-000CN Cassette (Tray 3) assembly

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Print a page from Tray 3 to make sure that the paper feeder is functioning correctly. 1. Remove the tray. 1250 Chapter 5 Removal and replacement

a. Pull the tray straight out of the printer until it stops. Figure 5-1393 Pull the tray out of the printer b. Slightly lift up on the front of the tray to release it, and then continue to pull the tray out of the accessory to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-1394 Release and remove the tray 2. Unpack the replacement assembly. Removal and replacement: Tray 3 1251

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly,

reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Remove and replacement: Accessories Learn how to remove and replace the accessories. Removal and replacement: 550-sheet paper feeder Learn how to remove and replace the optional 550-sheet paper feeder. To view a short video of this procedure, click the link below. NOTE: The printer accepts up to three optional paper trays. View a video of how to remove and replace the 550-sheet feeder. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. 1252 Chapter 5 Removal and replacement

Table 5-48 Part information

Part number Part description

F2A72-67901 Optional 550-sheet paper feeder with instruction guide

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Print a page from the optional tray (or trays) to make sure that the paper feeder is functioning correctly. 1. Remove the optional 550-sheet paper feeder. a. Slide the tray out of the printer. Figure 5-1395 Open the tray Removal and replacement: 550-sheet paper feeder 1253

b. Pull up on the blue lever to unlock it. Figure 5-1396 Unlock the front accessory lock c. At the rear of the printer, pull out on the blue lever to unlock it. Figure 5-1397 Unlock the rear accessory lock d. Close the tray. Figure 5-1398 Close the tray 3 e. Lift the printer off of the accessory. CAUTION: The printer is heavy. HP recommends two people lift the printer. 1254 Chapter 5 Removal and replacement

Figure 5-1399 Lift the printer off of the accessory 3 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 3. Install the optional 550-sheet paper feeder. Removal and replacement: 550-sheet paper feeder 1255

a. Remove the orange shipping tape, and then place the printer on the replacement accessory. CAUTION: The printer is heavy. HP recommends two people lift the printer. NOTE: The printer accepts up to three optional paper trays. Figure 5-1400 Remove shipping tape 3 3 4 5 b. Slide the tray out of the printer. Figure 5-1401 Open the tray 1256 Chapter 5 Removal and replacement

c. Push down on the blue lever to lock it. Figure 5-1402 Lock the front accessory lock d. At the rear of the printer, push in on the blue lever to lock it. NOTE: Repeat these steps to make sure all of the installed trays are locked together and to the printer base. Figure 5-1403 Lock the rear accessory lock e. Position the appropriate tray number plate in the depression in the tray, and then push in to install it. TIP: Number plates are included with the accessory. Removal and replacement: 550-sheet paper feeder 1257

Figure 5-1404 Install the tray number plate 3 4 5 f. Close the tray. Figure 5-1405 Close the tray 3 Removal and replacement: Document feeder rollers (MFP) Learn how to remove and replace the document feeder pickup and feed roller assembly and the separation roller assembly. To view a short video of this procedure, click the link below. View a video of how to remove and replace the document feeder pickup and feed roller assembly and the separation roller assembly. Mean time to repair: 10 minutes Service level: Easy 1258 Chapter 5 Removal and replacement

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **IMPORTANT:** When replacement rollers are installed, reset the New Document Feeder Kit firmware counter. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts.
Table 5-49 Part information

Part number Part description

B5L52-67903 Document feeder maintenance kit accessory with instruction guide

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use the document feeder to copy a page to make sure that it is functioning correctly. 1. Remove the document feeder pickup and feed roller assembly. Removal and replacement: Document feeder rollers (MFP) 1259

a. Open the document feeder jam access door. Figure 5-1406 Open the door b. Raise the blue lever to release the document feeder pickup and feed roller assembly. Figure 5-1407 Raise the blue lever 1260 Chapter 5 Removal and replacement

c. Slide the roller assembly toward the front of the printer (callout 1), and then away from the document feeder (callout 2) to remove it. Figure 5-1408 Remove the roller assembly 1 2 2. Remove the document feeder separation roller assembly. a. Open the document feeder separation roller assembly cover. Figure 5-1409 Open the cover Removal and replacement: Document feeder rollers (MFP) 1261

b. Remove the cover. Figure 5-1410 Remove the cover c. Slide the roller assembly toward the front of the printer, and then rotate it up and away from the document feeder to remove it. Figure 5-1411 Remove the roller assembly 3. Unpack the replacement assembly. a. Dispose of the defective part. **NOTE:** HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 1262 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. **CAUTION:** Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. **IMPORTANT:** Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. **NOTE:** When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 4. Install the document feeder separation roller assembly. **CAUTION:** Do not touch the spongy portion of the replacement roller. Skin oils on the roller can cause paper handling problems. HP recommends washing your hands before handling the assembly. a. Place the solid-shaft end of the assembly (the gear end will face the front of the printer) in the slot provided in the roller holder, and then rotate the gear end down and into the document feeder. **NOTE:** The roller might seem loose until the cover is installed and snapped closed. The cover helps hold the roller in place. Figure 5-1412 Install the roller assembly Removal and replacement: Document feeder rollers (MFP) 1263

b. Position the roller cover on the document feeder. Figure 5-1413 Install the roller cover c. Close the roller cover. Figure 5-1414 Close the roller cover d. Push down to snap the cover into place. **NOTE:** When the cover is correctly installed, an audible click is heard when it snaps into place. 1264 Chapter 5 Removal and replacement

Figure 5-1415 Push down on the roller cover 5. Install the document feeder pickup and feed roller assembly. **CAUTION:** Do not touch the spongy portion of the replacement roller. Skin oils on the roller can cause paper handling problems. HP recommends washing your hands before handling the assembly. a. Position the roller assembly in the holder (callout 1) with the drive shaft end of the assembly facing toward the rear of the printer. Slide the assembly toward the rear of the printer to engage the two keyed drive shafts with the two drive bushings (callout 2). Figure 5-1416 Install the roller assembly 1 2 Removal and replacement: Document feeder rollers (MFP) 1265

b. Lower the blue lever until it snaps over the roller assembly solid shaft. Figure 5-1417 Close the blue lever c. Close the document feeder jam access door. **NOTE:** When the door is completely closed, an audible click is heard when it latches closed. Figure 5-1418 Close the door 6. Reverse the removal steps to install the assembly. Also use the following special installation instructions. **NOTE:** Resetting the firmware counter is firmware dependent. Do one of the following. Reset the firmware counter (FS3) a. From the Home screen on the control panel, scroll to and touch the Administration button. 1266 Chapter 5 Removal and replacement

Figure 5-1419 Home screen (FS3) b. Open the following menus: ● Manage Supplies ● Reset Supplies ● New Document Feeder Kit c. Select the Reset item to reset the firmware counter. Reset the firmware counter (FS4) a. At the printer control panel, do the following. Figure 5-1420 Home screen (FS4) b. Scroll to, and then select the Settings button. c. Open the following menus: ● Manage Supplies ● Reset Supplies d. Select the Document Feeder Kit item, and then select the Reset button to reset the firmware counter. Removal and replacement: Fax printed-circuit board (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) Learn how to remove and replace the fax printed-circuit board.

Removal and replacement: Fax printed-circuit board (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) 1267

To view a short video of this procedure, click the link below. View a video of how to remove and replace the FAX PCA. Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **CAUTION:** This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-50 Part information

Part number Part description

B5L53-67901 Fax printed-circuit board with instruction guide

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Send/receive a fax using the printer. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). 1268 Chapter 5 Removal and replacement

Figure 5-1421 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-1422 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the fax PCA (M527/E52545/M528/E52645 fax models). **CAUTION:** ESD-sensitive part. Removal and replacement: Fax printed-circuit board (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) 1269

a. Disconnect three connectors (callout 1). Figure 5-1423 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-1424 Release the fax PCA 1270 Chapter 5 Removal and replacement

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-1425 Remove the fax PCA 1 2 3. Unpack the replacement assembly. a. Dispose of the defective part. **NOTE:** HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. **CAUTION:** Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. **IMPORTANT:** Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. **NOTE:** When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Fax printed-circuit board (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) 1271

4. Install the fax PCA (M527/E52545/M528/E52645 fax models). **CAUTION:** ESD-sensitive part. a. Before proceeding, take note of the location of the slots (callout 1) in the sheet-metal where the fax PCA cradle mounting tab and fax port (callout 2) must be installed. Figure 5-1426 Locate the slots in the sheet-metal 2 1 b. Insert the fax PCA cradle mounting tab and fax port in the slots in the sheet-metal plate (callout 1), and then rotate the connector end of the fax PCA toward the formatter (callout 2). Figure 5-1427 Install the fax PCA 2 1 1272 Chapter 5 Removal and replacement

c. Engage the retainer with the slot in the formatter. Reinstallation tip: Pinch the retainer to easily engage it with the slot. Figure 5-1428 Engage the fax PCA d. Connect three connectors (callout 1). Figure 5-1429 Connect three connectors 1 Removal and replacement: Fax printed-circuit board (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) 1273

5. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). Figure 5-1430 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. Figure 5-1431 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Install accessory: Internal USB ports (MFP) Learn how to remove and replace the internal USB ports. To view a short video of this procedure, click the link below. 1274 Chapter 5 Removal and replacement

View a video of how to remove and replace the internal USB ports. Mean time to repair: 7 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **CAUTION:** This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-51 Part information

Part number Part description

F2A87A Internal USB ports (M527/E52545) 1PV95A Internal USB ports (M528/E52645)

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Install accessory: Internal USB ports (MFP) 1275

Figure 5-1432 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-1433 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the fax PCA (M527/E52545/M528/E52645 fax models). **CAUTION:** ESD-sensitive part. 1276 Chapter 5 Removal and replacement

a. Disconnect three connectors (callout 1). Figure 5-1434 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-1435 Release the fax PCA Install accessory: Internal USB ports (MFP) 1277

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-1436 Remove the fax PCA 1 2 3. Unpack the accessory a. Dispose of the old part. **NOTE:** HP recommends responsible disposal of the defective part. b. Unpack the replacement part from the packaging.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 1278 Chapter 5 Removal and replacement

Figure 5-1437 Recycle and unpack 4. Install the internal USB ports module. **CAUTION:** ESD-sensitive part. a. Position the notches on the internal USB ports PCA over the clips on the PCA holder and press down to attach the PCA to the holder. Make sure that the clips snap into place. Figure 5-1438 Install the PCA in the holder Install accessory: Internal USB ports (MFP) 1279

b. Connect the wire harness to the PCA. Figure 5-1439 Connect one cable c. Position the PCA and bracket in the printer with the top tab aligned with the top slot (callout 1), and bottom edge of the bracket aligned with the bottom slot (callout 2). **NOTE:** When correctly installed, the PCA and bracket are firmly held in place. Figure 5-1440 Position the internal USB ports module d. Slide the PCA and bracket to the left until the tab on the bottom edge snaps into place. **NOTE:** When correctly installed, the PCA and bracket are firmly held in place. 1280 Chapter 5 Removal and replacement

Figure 5-1441 Install the internal USB ports module e. Pass the wire harness through the provided opening in the chassis. Figure 5-1442 Install the wire harness Install accessory: Internal USB ports (MFP) 1281

f. Connect one connector on the formatter. Figure 5-1443 Connect one connector 5. Install the fax PCA (M527/E52545/M528/E52645 fax models). **CAUTION:** ESD-sensitive part. a. Before proceeding, take note of the location of the slots (callout 1) in the sheet-metal where the fax PCA cradle mounting tab and fax port (callout 2) must be installed. Figure 5-1444 Locate the slots in the sheet-metal 2 1 1282 Chapter 5 Removal and replacement

b. Insert the fax PCA cradle mounting tab and fax port in the slots in the sheet-metal plate (callout 1), and then rotate the connector end of the fax PCA toward the formatter (callout 2). Figure 5-1445 Install the fax PCA 2 1 c. Engage the retainer with the slot in the formatter.

Reinstallation tip: Pinch the retainer to easily engage it with the slot. Figure 5-1446 Engage the fax PCA Install accessory: Internal USB ports (MFP) 1283

d. Connect three connectors (callout 1). Figure 5-1447 Connect three connectors 1 6. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). Figure 5-1448 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. 1284 Chapter 5 Removal and replacement

Figure 5-1449 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Install accessory: Internal USB ports (M506/E50045) Learn how to remove and replace the internal USB ports. To view a short video of this procedure, click the link below. View a video of how to remove and replace the internal USB ports. Mean time to repair: 7 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **CAUTION:** This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-52 Part information

Part number Part description

F2A87A Internal USB ports (M506/E50045) Install accessory: Internal USB ports (M506/E50045) 1285

Required tools

● No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-1450 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 1286 Chapter 5 Removal and replacement

Figure 5-1451 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Unpack the accessory. a. Dispose of the old part. **NOTE:** HP recommends responsible disposal of the defective part. b. Unpack the replacement part from the packaging. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Figure 5-1452 Recycle and unpack 3. Install the internal USB ports module. **CAUTION:** ESD-sensitive part. Install accessory: Internal USB ports (M506/E50045) 1287

a. Position the notches on the internal USB ports PCA over the clips on the PCA holder and press down to attach the PCA to the holder. Make sure that the clips snap into place. Figure 5-1453 Install the PCA in the holder b. Connect the wire harness to the PCA. Figure 5-1454 Connect the wire harness 1288 Chapter 5 Removal and replacement

c. Position the tab on the PCA bracket in the slot on the formatter cage (callout 1), and then rotate the left end of the bracket toward the formatter to engage three tabs (callout 2). Figure 5-1455 Install the internal USB ports module 1 2 d. Connect one connector on the USB PCA. Figure 5-1456 Connect one connector Install accessory: Internal USB ports (M506/E50045) 1289

e. Connect one connector on the formatter. Figure 5-1457 Connect one connector 4. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). Figure 5-1458 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. 1290 Chapter 5 Removal and replacement

Figure 5-1459 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Install accessory: Internal USB ports (M507/E50145) Learn how to remove and replace the internal USB ports. To view a short video of this procedure, click the link below. View a video of how to remove and replace the internal USB ports. Mean time to repair: 7 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **CAUTION:** This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-53 Part information

Part number Part description

1PV95A Internal USB ports (M507/E50145) Install accessory: Internal USB ports (M507/E50145) 1291

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-1460 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 1292 Chapter 5 Removal and replacement

Figure 5-1461 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Unpack the accessory. a. Dispose of the old part. **NOTE:** HP recommends responsible disposal of the defective part. b. Unpack the replacement part from the packaging. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Figure 5-1462 Unpack and recycle Install accessory: Internal USB ports (M507/E50145) 1293

3. Install the internal USB ports module. **CAUTION:** ESD-sensitive part. a. Position the notches on the internal USB ports PCA over the clips on the PCA holder and press down to attach the PCA to the holder. Make sure that the clips snap into place. Figure 5-1463 Install the PCA in the holder b. Connect the wire harnesses to the PCA. Figure 5-1464 Connect the wire harnesses 1294 Chapter 5 Removal and replacement c. Position the tab on the PCA bracket in the slot on the formatter cage (callout 1), and then rotate the left end of the bracket toward the formatter to engage three tabs (callout 2). Figure 5-1465 Install the internal USB ports module 1 2 d. Disconnect one connector. Figure 5-1466 Disconnect one connector Install accessory: Internal USB ports (M507/E50145) 1295

e. Connect one connector (short wire harness from internal USB ports to formatter). Figure 5-1467 Connect one connector f. Connect two connectors (long wire harness from internal USB ports to formatter). Figure 5-1468 Connect two connectors 4. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). 1296 Chapter 5 Removal and replacement

Figure 5-1469 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. Figure 5-1470 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Install accessory: Trusted platform module (TPM) Learn how to remove and replace the trusted platform module (TPM). To view a short video of this procedure, click the link below. View a video of how to remove and replace the TPM. Mean time to repair: 7 minutes Service level: Easy Install accessory: Trusted platform module (TPM) 1297

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. **CAUTION:** This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-54 Part information

Part number Part description

F5S62-61001 Trusted platform module (TPM)

Required tools

No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). 1298 Chapter 5 Removal and replacement

Figure 5-1471 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-1472 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the hard-disk drive (HDD models). **CAUTION:** ESD sensitive part. Install accessory: Trusted platform module (TPM) 1299

a. Release the locking connector (callout 1), and then pinch the retainer (callout 2) to release it. Figure 5-1473 Release the HDD 1 2 b. Rotate the connector end of the HDD out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-1474 Remove the HDD 1 2 3. Remove the accessory from its package. a. Save all packaging for recycling. b. For complete information about HP recycling programs, go to <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html>. 1300 Chapter 5 Removal and replacement

4. Install the TPM. **CAUTION:** ESD-sensitive part. a. Note the location on the formatter of an installed TPM (M507/E50145 right; M528/E52645 left). Figure 5-1475 TPM location (M507/E50145/M528/E52645) b. M507/E50145 only: Align the connector on the TPM (callout 1) with the connector on the formatter (callout 2). **NOTE:** The TPM can only be installed in one direction on the formatter. Figure 5-1476 Align the connectors (M507/E50145) 2 1 Install accessory: Trusted platform module (TPM) 1301

c. M528/E52645 only: Align the connector on the TPM (callout 1) with the connector on the formatter (callout 2). **NOTE:** The TPM can only be installed in one direction on the formatter. Figure 5-1477 Align the connectors (M528/E52645) 2 1 d. M507/E50145 only: Push the TPM onto the formatter to install it. **IMPORTANT:** Press on the TPM at the connector to make sure it is fully seated on the formatter connector. Figure 5-1478 Install the TPM (M507/E50145) e. M528/E52645 only: Push the TPM onto the formatter to install it. **IMPORTANT:** Press on the TPM at the connector to make sure it is fully seated on the formatter connector. 1302 Chapter 5 Removal and replacement

Figure 5-1479 Install the TPM (M528/E52645) 5. Install the HDD (HDD models). **CAUTION:** ESD sensitive part. a. Before proceeding, take note of the location of the slot (callout 1) in the sheet-metal where the HDD cradle mounting tab (callout 2) must be installed. **CAUTION:** This portion of the sheet-metal is a knock-out plate (callout 1). Do not push on it with sufficient force to detach it when installing the HDD. Figure 5-1480 Locate the slot in the sheet-metal 1 2 Install accessory: Trusted platform module (TPM) 1303

b. Insert the HDD cradle mounting tab in the slot in the sheet-metal (callout 1), and then rotate the connector end (callout 2) of the HDD toward the formatter. Figure 5-1481 Install the HDD 2 1 c. Make sure that the locking connector (callout 1) latches and that the standoff (callout 2) engages with the slot in the formatter (it might be necessary to pinch the retainer to engage it with the slot). Figure 5-1482 Install the HDD 1 2 6. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). 1304 Chapter 5 Removal and replacement

Figure 5-1483 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. Figure 5-1484 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Install accessory: Trusted platform module (TPM) 1305

1306

6 Parts and diagrams

Printer parts information including exploded assembly diagrams and part number lists.

HP service and support

Learn about access to additional service and support information.

Additional service and support for channel partners

Channel partners can use the HP Partner Portal or the Channel Services Delivery Platform (CSDP) to access the HP Web-based Interactive Search Engine (WISE). Find information about the following topics. ● Service manuals, service cost data, and service advisories ● The latest control panel message (CPMD) troubleshooting information ● Remove and replace part instructions and videos ● Solutions for printer issues and emerging issues ● Printer specifications, warranty, and regulatory information ● Install, configure, and how to information View a video of how to use the HP Partner First Portal to access WISE. Access WISE for Channel partners (HP Partner Portal) 1. Sign-in to the HP Partner Portal (click <https://partner.hp.com> to access the sign-in page). 2. Select the Services & Support item (near the top of the screen). 3. Select the Technical Support (WISE) item. 4. Select the Technical Documentation item. 5. Use the WISE portal to search for printer information. Access WISE for Channel partners (CSDP) 1. Sign-in to the CSDP portal (click csdp.hp.com to access the sign-in page). 2. Select the Knowledge and Training item. Parts and diagrams 1307

3. Select the HP Technical Documentation item. 4. Use the WISE portal to search for printer information. Additional service and support for HP internal personnel HP internal personnel, go to one of the following Web-based Interactive Search Engine (WISE) sites: View a video of how to access WISE for internal HP users. Americas (AMS) ● WISE - English ● WISE - Spanish ● WISE - Portuguese ● WISE - French Asia Pacific / Japan (APJ) ● WISE - English ● WISE - Japanese ● WISE - Korean ● WISE - Chinese (simplified) ● WISE - Chinese (traditional) ● WISE - Thai Europe / Middle East / Africa (EMEA) ● WISE - English

Additional technical support WISE videos

The videos below provide additional ways to access printer information using WISE. View a video of how to use WISE to find technical support videos (model number search). View a video of how to use WISE to find technical support videos (Product detail page [PDP] search). 1308 Chapter 6 Parts and diagrams

Order parts by authorized service providers

Find information about ordering parts and supplies for the printer. Ordering Order parts by authorized service providers. Table 6-1 Ordering

Item or provider Description

Order supplies and paper www.hp.com/go/suresupply Order parts from authorized service providers www.hp.com/buy/parts or partsurfer.hp.com Order through service or support providers Contact an HP-authorized service or support provider. Order using the HP Embedded Web Server (EWS) To access, in a supported web browser on your computer, enter the printer IP address or host name in the address/URL field. The EWS contains a link to the HP SureSupply web site, which provides options for purchasing Original HP supplies.

Orderable parts

Not all of the parts shown in the exploded assembly diagrams are orderable parts. Refer to the tables following the diagrams or the alphabetical/numerical parts lists to determine if a part is orderable.

Supplies and accessories

Following are the part numbers for the supplies and accessories that are available for the printers. To order cartridges, visit <http://www.hp.com> (some portions of the HP Web site are available in English only). Ordering cartridges online is not supported in all countries/regions. However, many countries/ regions have information about ordering by telephone, locating a local store, and printing a shopping list. In addition, go to hp.com/supplies to obtain information about purchasing HP products in your country/ region. Use only the replacement cartridges that have the same cartridge number as the cartridge that is being replaced. Find the cartridge number in the following places: ● On the label of the cartridge that is being replaced. ● On a sticker inside the printer. Open the cartridge door to locate the sticker. ● Open the printer software (HP Printer Assistant), and then click Shop > Shop For Supplies Online. ● Open the HP Embedded Web Server (EWS), and then click Tools > Supply Status (under the Product Information item). Order parts by authorized service providers 1309

Table 6-2 Supplies part numbers

Item Description Cartridge number Part number

HP 872A Black Original

LaserJet Toner Cartridge

Standard-capacity

replacement black toner cartridge (M501/M506/

E50045/M527/E52545)

87A CF287A (service:

CF287-67901)

HP 872X High Yield Black

Original LaserJet Toner

Cartridge

High-capacity replacement

black toner cartridge (M501/M506/

E50045/M527/E52545)

87X CF287X (service:

CF287-67902)

HP 89A Black Original

LaserJet Toner Cartridge

Standard-capacity

replacement black toner cartridge (M507/E50145/

M528/E52645)

89A CF289A (service:

CF289-67901)

HP 89X High Yield Black

Original LaserJet Toner

Cartridge

High-capacity replacement

black toner cartridge (M507/E50145/

M528/E52645)

89X CF289X (service:

CF289-67902)

HP 89Y Extra High Yield

Black Original LaserJet

Toner Cartridge

Extra high-capacity

replacement black toner cartridge (M507/E50145/

M528/E52645)

89Y CF289Y (service:

CF289-67903)

HP Black contract

LaserJet Toner Cartridge

Standard-capacity

replacement black toner cartridge (contract; M507/

E50145/M528/E52645)

89YC CF289YC (service:

CF289-67904)

HP Black managed

LaserJet Toner Cartridge

Standard-capacity

replacement black toner cartridge (managed; M507/

E50145/M528/E52645)

89A CF289A (service:

CF289-67905)

HP Staple Cartridge Pack Replacement staple

cartridges for the f and z models. Contains two staple cartridges of 1500 staples each (MFP only). Not applicable Q7432A HP LaserJet 200 ADF

Roller Replacement Kit

Replacement feed rollers

for the document feeder (MFP only). Not applicable B5L52A Table 6-3 Accessories

Item Description Part number

1 x 550-sheet paper feeder Optional 550-sheet paper feeder (The M501 printer supports one 1 x 550-sheet paper feeder. All other models support up to three 1 x 550- sheet paper feeders.)

F2A72A

Printer stand and cabinet Optional stand with storage cabinet to support the printer (Recommended when using multiple optional paper feeders.)

F2A73A

500 GB HP Secure High Performance Hard Disk DriveAccessory hard drive (M506/E50045/M507/E50145/ M527/E52545/M528/E52645 only)

B5L29A

1310 Chapter 6 Parts and diagrams

Table 6-3 Accessories (continued)

Item Description Part number

TAA FIPS/CC Hard Disk Drive Hard Disk Drive (M527/E52545/ M528/E52645 only)

5EH03A

HP 1GB DDR3 x32 144-pin 800MHz

SODIMM

Optional DIMM for expanding

the memory (M527/E52545/M528/

E52645)

E5K48A

HP 2GB DDR3 x32 144-pin 800MHz

SODIMM

Optional DIMM for expanding

the memory (M527/E52545/M528/

E52645)

E5K49A

HP 1GB 90-pin DDR3 x32 Slim DIMM Optional DIMM for expanding the memory (M506/E50045/M507/

E50145)

G6W84A

1GB 90-Pin DDR3 Slim DIMM TAA CompliantOptional DIMM for expanding the memory (M506/E50045/M507/

E50145)

2NR03A

2GB 144-Pin DDR3 DIMM TAA CompliantOptional DIMM for expanding the memory (M527/E52545/M528/

E52645)

2NR09A

HP LaserJet Keyboard Overlay Kit

for Simplified Chinese & Traditional Chinese Language-specific, adhesive overlay for the physical keyboard (z models only)

A7W12A

HP LaserJet Keyboard Overlay Kit for

Swedish Language-specific, adhesive overlay for the physical keyboard (z models only)

A7W14A

HP Internal USB ports Two internal USB ports for

connecting third-party devices

B5L28A

HP Trusted Platform Module Automatically encrypts all data that passes through the printer

F5S62A

HP Foreign Interface Harness Optional port for connecting third party devicesB5L31A

HP LaserJet MFP Analog Fax

Accessory 600

Optional fax accessory for the dn

model (M527/E52545)

B5L53A

HP LaserJet MFP Analog Fax

Accessory 700

Optional fax accessory for the dn

model (M528/E52645)

2EH31A

HP Jetdirect 2900nw Print Server USB wireless print server accessory J8031A HP Jetdirect 3000w NFC/Wireless

Accessory

WiFi direct accessory for “touch” printing from mobile devices (M506/ E50045/M527/E52545 only)

J8030A

HP JetDirect 3100w BLE/NFC/

Wireless Accessory

WiFi direct accessory for “touch” printing from mobile devices (M507/ E50145/M528/E52645 only)

3JN69A

HP Accessibility Kit (M528 only) Accessibility kit including button adhesives and an accessibility handle (M528/E52645 only)

2TD64A

HP USB Universal Card Reader

(M528 only) USB proximity card reader (M528/ E52645 only)

X3D03A

HP Legic Reader HP card reader accessory 4QL32A Supplies and accessories 1311

Customer self-repair kits

Following are the available customer self-repair kits part numbers. Customer Self-Repair (CSR) parts are available for many HP LaserJet printers to reduce repair time. More information about the CSR program and benefits can be found at www.hp.com/go/csr-support and www.hp.com/go/csr-faq. Genuine HP replacement parts can be ordered at www.hp.com/buy/parts or by contacting an HP authorized service or support provider. When ordering, one of the following will be needed: part number, serial number (found on back of printer), printer number, or printer name. ● Parts listed as A: Easy ● Parts listed as B: Difficult and/or requires tools Table 6-4 Customer self-repair kits

Kit Description CSR level Part number

Control panel (M527/

E52545/M528/E52645

only)

Control panel and

screwdriver

A B5L47-67018

Control panel kit (M506x/ E50045x only)

Control panel and

screwdriver

A G1W41-67907

Control panel kit (M507x/ E50145x only)

Control panel and

screwdriver

A K0Q15-67901

White backing (MFP only) White backing (document feeder) and retention clips

A 5851-6570

embedded MultiMedia Card (eMMC) kit (M527dn/E52545dn/ M528dn/E52645dn only) eMMC module 16GB A 5851-6587 embedded MultiMedia Card (eMMC) kit (M506/ E50045 only) eMMC module 4GB A 5851-6436 Transfer roller Transfer roller A F2A68-67910 Multipurpose tray (Tray 1) pickup roller and separation pad

Roller and separation pad

for Tray 1

B F2A68-67914

Tray 2/3 roller kit

(M506/E50045/M507/

E50145/ M527/E52545/

M528/E52645 only) Rollers for Tray 2 and the optional 550-sheet paper feeders. NOTE: This kit contains rollers for two trays, both Tray 2 and the optional 550 sheet feeder.

B RM2-5752-000CN

NOTE: (Replaces F2A68-67913 that is obsolete) Tray 2- roller kit

(M501/M506/E50045/

M507/E50145/ M527/

E52545/M528/E52645)

Rollers for Tray 2 NOTE: This roller kit is for one tray only!

For a roller kit for

tray 2 and optional 550 sheet feeder order

RM2-5752-000CN

B J8H60-67903

1312 Chapter 6 Parts and diagrams

Table 6-4 Customer self-repair kits (continued)

Kit Description CSR level Part number

Document feeder

maintenance kit (MFP only) Pickup, feed, and separation ADF roller kit

A W5U23-67901

Keyboard kit (M527c/z/E52545c/z/ M528cz/E52645cz only) Physical pull-out keyboard B B5L47-67019 (US English Keyboard kit (M527c/z/E52545c/z/ M528cz/E52645cz only) Physical pull-out keyboard B B5L47-67020 (UK English)

Foreign Interface Harness

kit (MFP only) FIH accessory A B5L31-67902

How to use the parts lists and diagrams

Learn how to use the parts lists and diagrams. The figures in this chapter show the major sub-assemblies in the printer and their component parts. A parts list table follows each exploded view assembly diagram. The table lists the item number, the associated part number, and the description of each part. If a part is not listed in the table, then it is not a field replacement unit (FRU). NOTE: The abbreviation "PCA" stands for "printed circuit-board assembly." Components described as a PCA might consist of a single circuit board or a circuit board plus other parts, such as cables and sensors. How to use the parts lists and diagrams 1313

Parts and diagrams: Document feeder and scanner whole units Parts diagram and part list for the document feeder and scanner whole units. Figure 6-1 Document feeder and image scanner assembly (MFP only) 1 2 3 4 5 6 Table 6-5 Document feeder and image scanner assembly (MFP only) Ref No

Part number Description Qty

1 B5L47-67906 Document feeder kit (M527/E52545/M528/ E52645 Enterprise) 1 1 B5L47-67907 Document feeder kit (M527/E52545/M528/ E52645 Flow) 1 2 F2A76-67909 Image scanner assembly kit (M527/E52545/

M528/E52645)

1 3 B5L47-67018 Control panel kit (M527/E52545/M528/

E52645)

1 4 B5L47-67019 Keyboard US (M527/E52545/M528/E52645) 1 4 B5L47-67020 Keyboard UK (M527/E52545/M528/E52645) 1 5 B5L46-40021 Cover, HIP (M527/E52545/M528/E52645) 1 6 B5L46-60117 Bezel, control panel (M527/E52545/M528/

E52645)

1 Not shown B5L46-40002 Cover, keyboard (M527/E52545/M528/E52645) 1 1314 Chapter 6 Parts and diagrams
Table 6-5 Document feeder and image scanner assembly (MFP only) (continued) Ref No

Part number Description Qty

Not shown 5851-5939 Cable, WU USB control panel (M527/E52545) 1 Not shown 5851-5938 Cable, HIP USB control panel (M527/E52545/

M528/E52645)

1 Not shown 5851-5936 Cable, HDMI control panel (M527/E52545/

M528/E52645)

1 Not shown 5851-5935 Cable, 18-pin control panel (M527/E52545/

M528/E52645)

1 Not shown F2A76-50004 Cable, HDMI PAB to SCAM (M527/E52545/

M528/E52645)

1 Not shown COM39-60064 Hinge, left document feeder (M527/E52545/

M528/E52645)

1 Not shown COM39-60065 Hinge, right document feeder (M527/E52545/

M528/E52645)

1 Not shown B5L46-40028 Cover, USB (M527/E52545) 1 Not shown B5L46-60116 Cable, stapler (M5278/E52645) 1 Not shown B5L46-40011 Cover, rear image scanner (M527/E52545) 1 Not shown B5L47-67901 Scan-control board (SCB) kit (M528/E52645) 1 Not shown B5L47-67903 Scan-control board (SCB) kit (M527/E52545) 1 Not shown 5851-6019 Keyboard overlay kit (FR, IT, RU, DE, ES: UK Kybd) 1 Not shown 5851-6020 Keyboard overlay kit (FR-CN, ES-LA, ES: US Keyboard) 1 Not shown 5851-6021 Keyboard overlay kit (FR-SW, DE-SW, DA: UK Keyboard) 1 Not shown 5851-6022 Keyboard overlay kit (ZHTW, ZHCN) 1 Not shown 5851-6023 Keyboard overlay kit (ES, PT) 1 Not shown 5851-6024 Keyboard overlay kit (JA-KG, JA-KT) 1 Parts and diagrams: Document feeder and scanner whole units 1315

Parts and diagrams: Covers (M501/M506/E50045/M507/

E50145)

Parts diagram and parts list for the SFP printer covers. Figure 6-2 Covers (M501/M506/E50045/M507/E50145)

SIMPLEX MODEL

DUPLEX LCD MODEL

DUPLEX MF MODEL

(J6) (J7) (J6) (J7) (J2) A01 A01 A01 A01 A01 A01 A02 A02 A02 A02 1 2 3 3 4 4 4 5 7 7 8 9 9 9 10 11 12 6 1316 Chapter 6 Parts and diagrams
Table 6-6 Covers (M501/M506/E50045/M507/E50145) Ref No

Part number Description Qty

1 RC4-4437-000CN Cover, right (M501/M506/E50045) 1 1 RC4-4137-000CN Cover, right (M507/E50145) 1 2 RC4-4439-000CN Tray, paper delivery output bin (M501/M506/

E50045)

1 2 RC4-4141-000CN Tray, paper delivery output bin (M507/E50145) 1 3 RC4-4142-000CN Cover, HIP (M506/E50045/M507/E50145 duplex models) 1 4 RC4-4149-000CN Cover, USB (M506/E50045/M507/E50145) 1 5 F2A68-40002 Plate, name (M506/E50045) 1 5 1PV87-40001 Plate, name (M507) 1 5 1PU51-40001 Plate, name (E50145dn) 5 J8H60-40001 Plate, name (M501) 1 6 RC4-4433-000CN Cover, I/O (M506/E50045/M507/E50145) 1 7 RK2-7104-000CN Cable, HIP (M506/E50045 duplex models) 1 7 RK3-0526-000CN Cable, HIP (M507/E50145 duplex models) 1 8 F2A68-67919 Door, cartridge kit (M506n/dn/E50045n/dn) 1 8 F2A68-67920 Door, cartridge kit (M506x/E50045x) 1 8 RM2-5677-000CN Door, cartridge (M501/M507/E50145) 1 Not Shown RM2-5735-000CN Cover, top (M501) 1 9 RM2-5687-000CN Cover, top (M506/E50045 simplex models) 1 9 RM2-5699-000CN Cover, top (M506/E50045 duplex LCD models) 1 9 RM2-5686-000CN Cover, top (M506/E50045 duplex MF models) 1 9 RM2-5726-000CN Cover, top (M501 duplex models) 1 9 RM2-2587-000CN Cover, top (M507/E50145 duplex models) 1 9 RM2-2607-000CN Cover, top (M507/E50145 simplex models) 1 10 RM2-5712-000CN Door, rear (M501/M506/E50045/M507/E50145 simplex models) 1 10 RM2-5711-000CN Door, rear (M501/M506/E50045/M507/E50145 duplex models) 1 11 RM2-5727-000CN Cover, left (M501/M506/E50045) 1 11 RM2-5713-000CN Cover, left (M507/E50145) 1 12 RC4-4200-000CN Cover, formatter (M501) 1 12 RM2-5725-000CN Cover, formatter (M506/E50045/M507/

E50145)

1 Not shown RC4-3010-000CN Hinge, cartridge door left 1 Parts and diagrams: Covers (M501/M506/E50045/M507/E50145) 1317
Table 6-6 Covers (M501/M506/E50045/M507/E50145) (continued) Ref No

Part number Description Qty

Not shown RC4-4479-000CN Link, pressure release (cartridge door) 1 Not shown RC4-3002-000CN Shaft, support 1 Not shown RC5-5148-000CN Cover, WiFi 1 Not shown RC4-3219-000CN Cover, full detect sensor 1 Not shown 7121-8684 Jewel, HP logo (2pc; M507/E50145) 1 No reference G1W41-67907 Control panel kit (M506x/E50045x) 1 No reference K0Q15-67901 Control panel kit (M507x/E50145x) 1 No reference J8H60-67904 Control panel (M501) 1 No reference RM2-2610-000CN Control panel (507n/dn) 1 No reference K0Q15-60106 Control panel E50145 1 1318 Chapter 6 Parts and diagrams

Parts and diagrams: Covers (M527/E52545/M528/E52645) Parts diagram and parts list for the MFP printer covers. Figure 6-3 Covers (M527/E52545/M528/E52645) 11 A01 A01 A01 A01 A01 A02 A02 A02 A02 1 2 3 6 7 8 9 10 5 4 Parts and diagrams: Covers (M527/E52545/M528/E52645) 1319

Table 6-7 Covers (M527/E52545/M528/E52645) Ref No

Part number Description Qty

1 RC4-4437-000CN Cover, right (M527/E52545/M528/E52645) 1 2 RC4-4141-000CN Tray, paper delivery output bin (M527/E52545/

M528/E52645)

1 3 RC4-4147-000CN Cover, top left (M527/E52545/M528/E52645) 1 4 RC4-4150-000CN Cover, top rear (M527/E52545) 1 5 RC4-4433-000CN Cover, I/O (M527/E52545) 1 6 F2A76-67912 Door, cartridge kit (M527/E52545) 1 6 RM2-5691-000CN Door, cartridge (M528/E52645) 1 7 RM2-5711-000CN Door, rear (M527/E52545/M528/E52645) 1 8 RM2-5727-000CN Cover, left (M527/E52545) 1 8 RM2-5713-000CN Cover, left (M528/E52645) 1 9 RM2-5717-000CN Cover, formatter (M527/E52545/M528/

E52645)

1 10 RM2-5718-000CN Cover, top (M527/E52545/M528/E52645) 1 11 F2A74-40001 Plate, name (M527/E52545) 1 11 1PV64-40001 Plate, name (M528dn/f) 1 11 1PV66-40001 Plate, name (M528c/z) 1 11 1PS54-40001 Plate, name (E52645dn) 1 11 1PS55-40001 Plate, name (E52645c) 1 Not shown 7121-8684 Jewel, HP logo (2pc; M528/E52645) 1 Not shown F2A76-40003 Cover, stationary stapler, inner (M527c/f/z/ E52545c/f/z/M528c/f/z/E52645c/f/z) 1 Not shown F2A76-40004 Door, stapler flap (M527c/f/z/E52545c/f/z) 1 Not shown F2A76-40005 Cover, stapler blank (M527dn/E5245dn) 1 Not shown B5L24-00035 Sticker, stapler cartridge replacement (M527/

M528/E52645)

1 Not shown 5851-1885 Plug/cap, fax port (M527/E52545) 1 Not shown RC4-3010-000CN Hinge, cartridge door left 1 Not shown RC4-4479-000CN Link, pressure release (cartridge door) 1 Not shown RC4-3002-000CN Shaft, support 1 Not shown RC4-3219-000CN Cover, full detect sensor 1 1320 Chapter 6 Parts and diagrams
Parts and diagrams: Internal assemblies (1 of 4) Parts diagram and parts list for the internal printer assemblies. Figure 6-4 Internal assemblies (1 of 4)

M506/E50045

M527/E52545

(FM1)

(J372)

(SW2)

(J802)

(J162)

(J133)

(J341)

(J8) (J9)

(J851)

(J161)

(J376)

A01 A01

A01 A01

A02 A03 A04 A05 A06 A07 A08 A09 A10 A11 A12 A13 A14 A15 A15 A15 A16 A17

A17 A17

A18 1 2 3 4 5 6 7 8 Parts and diagrams: Internal assemblies (1 of 4) 1321
Table 6-8 Internal assemblies (1 of 4) Ref No

Part number Description Qty

1 RK2-0534-000CN Microswitch (SW2) 1 2 RK2-8068-000CN Fan (FM1) 1 3 RK2-6259-000CN Cable, flat-flexible 1 4 RK2-6260-000CN Cable, flat-flexible 1 5 RK2-7067-000CN Cable, USB (M506/E50045) 1 5 RK2-7067-000CN Cable, USB (M507/E50145) 1 6 RM2-5528-000CN Laser/scanner assembly (M501/M506/

E50045/M527/E52545)

1 6 RM2-2891-000CN Laser/scanner assembly (M507/E50145/

M528/E52645)

1 7 RM2-5702-000CN Cable, TAG assembly (M501/M506/E50045/

M527/E52545)

1 7 RM2-2596-000CN Cable, TAG assembly (M507/E50145/M528/

E52645)

1 8 RM2-7945-000CN Power supply, high-voltage (HVPS) (M501/

M506/E50045/M527/E52545)

1 8 RM3-7424-000CN Power supply, high-voltage (HVPS) (M507/

E50145/M528/E52645)

1 1322 Chapter 6 Parts and diagrams

Parts and diagrams: Internal assemblies (2 of 4) Parts diagram and parts list for the internal printer assemblies. Figure 6-5 Parts and diagrams: Internal assemblies (2 of 4)

Duplex LCD model

Duplex MF model

Duplex LCD model

Duplex MF model

(J405)

(J151)

(J407)

(J291)

(SW5)

(J860)

(J152)

(J131)

(J410)

(J241)

(J159)

(J860)

(M1)

(J712)

(CL2)

(J663)

(J663)

(J154)

A01 A02 A04 A09 A10 A12 A14 A15 A16 A01 A01 A03 A11 A13 A15 A05 A06 A07 A08 6 1 2 3 4 7 5 8 Parts and diagrams: Internal assemblies (2 of 4) 1323

Table 6-9 Parts and diagrams: Internal assemblies (2 of 4) Ref No

Part number Description Qty

1 RM2-5689-000CN Film bias assembly 1 2 RM2-5690-000CN Cassette (Tray 2) 1 3 RM2-5701-000CN Switch, lever assembly 1 4 RM2-5745-000CN Roller, separation (Tray 2/3) 1 5 RM2-8514-000CN Clutch, paper re-pickup assembly (duplex LCD and MF models) 1 6 RM2-2585-000CN Fixing (fuser) assembly 110V-127V (M501/

M506/E50045/M527/E52545)

1 6 RM2-2585-000CN Fixing (fuser) assembly 110V-127V (M507/

E50145/M528/E52645)

1 6 RM2-2586-000CN Fixing (fuser) assembly 220V-240V (M501/

M506/E50045/M527/E52545)

1 6 RM2-2586-000CN Fixing (fuser) assembly 220V-240V (M507/

E50145/M528/E52645)

1 7 RM2-8684-000CN Motor, main M1 1 8 RM2-8597-000CN Switch, power PCA assembly 1 Not shown RK2-8657-000CN Cable, flat flexible (FFC) 1 Not shown RK3-0503-000CN Cable, flat flexible (FFC) 1 1324 Chapter 6 Parts and diagrams

Parts and diagrams: Internal assemblies (3 of 4) Parts diagram and parts list for the internal printer assemblies. Figure 6-6 Parts and diagrams: Internal assemblies (3 of 4)

Duplex LCD Model

Duplex MF Model

(SL3)

(J143)

A01 A02 A03 A04 A05 A06 A08 A09 A10 A11 A11 16 1 2 3 4 5 7 6 8 9 10 11 12 14 13 15 Parts and diagrams: Internal assemblies (3 of 4) 1325

Table 6-10 Parts and diagrams: Internal assemblies (3 of 4) Ref No

Part number Description Qty

1 F2A68-67910 Roller, transfer kit 1 2 RC4-3133-000CN Holder, transfer roller right 1 3 RC4-3134-000CN Holder, transfer roller left 1 10 RM1-5421-000CN Solenoid assembly 1 11 RM2-5671-000CN Registration assembly (M501/M506/E50045/

M527/E52545)

1 11 RM2-2577-000CN Registration assembly (M507/E50145/M528/

E52645)

1 12 RM2-5700-000CN Gear, multipurpose 1 13 RU8-2935-000CN Spring, compression (included in the multipurpose tray roller and separation pad kit) 1 15 J8H60-67903 Roller, Tray 2-3 kit (M501) 1 15 F2A68-67913 Roller, Tray 2-x kit (M506/E50045/M507/

E50145/M527/E52545/M528/E52645)

1 16 F2A68-67914 Roller and pad, Tray 1 pickup and separation pad kit 1 Not shown B5L46-60102 Stapler unit (M527/E52545/M528/E52645) 1 Not shown F2A76-60113 Cable, stapler 6-pin (M527/E52545/M528/

E52645)

1 Not shown B5L24-60001 Near-field communications (NFC) PCA (M527/

E52545)

1 Not shown J8030-61001 Near-field communications (NFC) HP JetDirect 3000W NFC accessory (M528/

E52645)

1 Not shown F2A76-40007 Bracket, WiFi PCA (M506z/E50045/M507z/ E50145z/M527/E52545/M528/E52645) 1 Not shown F2A76-60112 Cable, WiFi PCA (M506z/E50045z/M507z/ E50145z/M527/E52545/M528/E52645) 1 Not shown 1150-7968 Wireless embedded PCA (M506z/E50045z/ M507z/E50145z/M527/E52545M528/E52645) 1 Not shown RM2-5666-000CN Assembly-Intermediate Paper Feed 1 1326 Chapter 6 Parts and diagrams

Parts and diagrams: Internal assemblies (4 of 4) Parts diagram and parts list for the internal printer assemblies. Figure 6-7 Parts and diagrams: Internal assemblies (4 of 4)

M527/E52545 M506/E50045

Duplex-MF model

M506/E50045

(J602)

(J216)

(J132)

1 2 RK2-6526-000CN Cable, flat flexible (M501) 1 3 RM2-5715-000CN Paper feed drive assembly 1 4 RM2-7948-000CN Fixing (fuser) power supply (FPS) 110V-127V (includes tray connector) 1 4 RM2-7949-000CN Fixing (fuser) power supply (FPS) 220V-240V (includes tray connector) 1 5 RM2-7951-000CN Low-voltage power supply (LVPS) 110V-127V

(M527/E52545/M528/E52645)

1 5 RM2-7952-000CN Low-voltage power supply (LVPS) 220V-240V

(M527/E52545/M528/E52645)

1 5 RM2-7941-000CN Low-voltage power supply (LVPS) 110V-127V

(M501/M506/E50045/M507/E50145)

1 5 RM2-7942-000CN Low-voltage power supply (LVPS) 220V-240V

(M501/M506/E50045/M507/E50145)

1 6 RM2-7955-000CN Memory PCA (M506/E50045/M507/E50145/

M527/E52545/M528/E52645)

1 7 RM2-8614-000CN DC controller PC board (PCA) For simplex models - (M506/E50045) 1 7 RM3-7476-000CN DC controller PC board (PCA) For simplex models - (M507/E50145) 1 7 RM2-8711-030CN DC controller PC board (PCA) - M501dn/ M501n 1 7 RM2-8612-000CN DC controller PC board (PCA) For duplex models - (M506/M527/E52545/E50045) 1 7 RM3-7475-010CN DC controller PC board (PCA) For duplex models - (M507/M528/E52645/E50145) 1 Not shown F2A76-67910 Formatter PCA kit (M527/E52545) 1 Not shown 1PV64-60002 Formatter PCA kit (M528/E52645) 1 Not shown 1PV64-60003 Formatter PCA kit (M528/E52645; China) 1 Not shown 1PV87-60001 Formatter PCA kit (M507x/dng /E50145) 1 Not shown 1PV87-60002 Formatter (M507dn) 1 Not shown 1PV87-60003 Formatter (M507n) 1 Not shown 1PV86-60004 Formatter (M507x/dng) China/India 1 Not shown 1PV86-60007 Formatter (M507dn) China/India 1 Not shown 1PV86-60008 Formatter (M507n) China/India 1 Not shown F2A68-67915 Formatter PCA kit (M506n/dn /E50045n/dn) 1 1328 Chapter 6 Parts and diagrams Table 6-11 Parts and diagrams: Internal assemblies (4 of 4) (continued) Ref No

Part number Description Qty

Not shown F2A68-67916 Formatter PCA kit (M506x /E50045dw) 1 Not shown J8H60-67901 Formatter PCA (M501n) 1 Not shown J8H60-67902 Formatter PCA (M501n; China) 1 Not shown J8H61-67901 Formatter PCA (M501dn) 1 Not shown J8H61-67902 Formatter PCA (M501dn; China) 1 Not shown RL2-0888-000CN Case, formatter (M501) 1 Not shown RL2-0885-000CN Case, formatter PCA (M506/E50045/M507/

E50145)

1 Not shown RL2-0895-000CN Case, formatter (M527/E52545/M528/E52645) 1 Not shown CC456-60002 Fax PCA (M527/E52545) 1 Not shown 2EH31-67901 Fax PCA; HP analog fax 700 accessory (M528/

E52645)

1 Not shown 5851-5605 Cradle, fax PCA (M527/E52545) 1 Not shown 5851-5997 Cable, fax PCA (M527/E52545) 1 Parts and diagrams: Internal assemblies (4 of 4) 1329

Parts and diagrams: 1x550-sheet paper feeder Parts diagram and parts list for the 1x550-sheet paper feeder. Figure 6-8 Parts and diagrams: 1x550-sheet paper feeder 1 Table 6-12 Parts and diagrams: 1x550-sheet paper feeder Ref No

Part number Description Qty

1 F2A72-67901 1x550-sheet paper feeder (whole unit) 1 1330 Chapter 6 Parts and diagrams

Alphabetical parts list

Table 6-13 Alphabetical parts list

Description Part number Table and page

1x550-sheet paper feeder (whole unit) F2A72-67901 Parts and diagrams: 1x550- sheet paper feeder on page 1330 Bezel, control panel (M527/E52545/M528/E52645) B5L46-60117 Document feeder and image scanner assembly (MFP only) on page 1314 Bracket, WiFi PCA (M506z/E50045/M507z/E50145z/M527/

E52545/M528/E52645)

F2A76-40007 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Cable, 18-pin control panel (M527/E52545/M528/E52645) 5851-5935 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, HDMI PAB to SCAM (M527/E52545/M528/E52645) F2A76-50004 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, HDMI control panel (M527/E52545/M528/E52645) 5851-5936 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, HIP (M506/E50045 duplex models) RK2-7104-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cable, HIP (M507/E50145 duplex models) RK3-0526-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cable, HIP USB control panel (M527/E52545/M528/E52645) 5851-5938 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, TAG assembly (M501/M506/E50045/M527/E52545) RM2-5702-000CN Internal assemblies (1 of 4) on page 1322 Cable, TAG assembly (M507/E50145/M528/E52645) RM2-2596-000CN Internal assemblies (1 of 4) on page 1322 Cable, USB (M506/E50045) RK2-7067-000CN Internal assemblies (1 of 4) on page 1322 Cable, USB (M507/E50145) RK2-7067-000CN Internal assemblies (1 of 4) on page 1322 Cable, WU USB control panel (M527/E52545) 5851-5939 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, WiFi PCA (M506z/E50045z/M507z/E50145z/M527/E52545/

M528/E52645)

F2A76-60112 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Cable, fax PCA (M527/E52545) 5851-5997 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Cable, flat flexible (M506/E50045/M507/E50145/M527/E52545/

M528/E52645)

RK2-6261-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Alphabetical parts list 1331

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Cable, flat flexible (FFC) RK2-8657-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Cable, flat flexible (FFC) RK3-0503-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Cable, flat flexible (M501) RK2-6526-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Cable, flat-flexible RK2-6259-000CN Internal assemblies (1 of 4) on page 1322 Cable, flat-flexible RK2-6260-000CN Internal assemblies (1 of 4) on page 1322 Cable, stapler (M5278/E52645) B5L46-60116 Document feeder and image scanner assembly (MFP only) on page 1314 Cable, stapler 6-pin (M527/E52545/M528/E52645) F2A76-60113 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Case, formatter (M527/E52545/M528/E52645) RL2-0895-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Case, formatter (M501) RL2-0888-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Case, formatter PCA (M506/E50045/M507/E50145) RL2-0885-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Cassette (Tray 2) RM2-5690-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Clutch, paper re-pickup assembly (duplex LCD and MF models) RM2-8514-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Control panel (507n/dn) RM2-2610-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Control panel (M501) J8H60-67904 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Control panel E50145 K0Q15-60106 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Control panel kit (M527/E52545/M528/E52645) B5L47-67018 Document feeder and image scanner assembly (MFP only) on page 1314 Control panel kit (M506x/E50045x) G1W41-67907 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Control panel kit (M507x/E50145x) K0Q15-67901 Covers (M501/M506/E50045/ M507/E50145) on page 1317 1332 Chapter 6 Parts and diagrams

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Cover, HIP (M506/E50045/M507/E50145 duplex models) RC4-4142-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, HIP (M527/E52545/M528/E52645) B5L46-40021 Document feeder and image scanner assembly (MFP only) on page 1314 Cover, I/O (M506/E50045/M507/E50145) RC4-4433-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, I/O (M527/E52545) RC4-4433-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, USB (M506/E50045/M507/E50145) RC4-4149-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, USB (M527/E52545) B5L46-40028 Document feeder and image scanner assembly (MFP only) on page 1314 Cover, WiFi RC5-5148-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, formatter (M506/E50045/M507/E50145) RM2-5725-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, formatter (M527/E52545/M528/E52645) RM2-5717-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, formatter (M501) RC4-4200-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, full detect sensor RC4-3219-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, full detect sensor RC4-3219-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, keyboard (M527/E52545/M528/E52645) B5L46-40002 Document feeder and image scanner assembly (MFP only) on page 1314 Cover, left (M501/M506/E50045) RM2-5727-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, left (M507/E50145) RM2-5713-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, left (M527/E52545) RM2-5727-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, left (M528/E52645) RM2-5713-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, rear image scanner (M527/E52545) B5L46-40011 Document feeder and image scanner assembly (MFP only) on page 1314 Cover, right (M527/E52545/M528/E52645) RC4-4437-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, right (M501/M506/E50045) RC4-4437-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, right (M507/E50145) RC4-4137-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Alphabetical parts list 1333

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Cover, stapler blank (M527dn/E5245dn) F2A76-40005 Covers (M527/E52545/M528/ E52645) on page 1320 Cover, stationary stapler, inner (M527c/f/z/E52545c/f/z/ M528c/f/z/E52645c/f/z) F2A76-40003 Covers (M527/E52545/M528/ E52645) on page 1320 Cover, top (M501 duplex models) RM2-5726-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M501) RM2-5735-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M506/E50045 duplex LCD models) RM2-5699-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M506/E50045 duplex MF models) RM2-5686-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M506/E50045 simplex models) RM2-5687-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M507/E50145 duplex models) RM2-2587-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M507/E50145 simplex models) RM2-2607-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Cover, top (M527/E52545/M528/E52645) RM2-5718-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, top left (M527/E52545/M528/E52645) RC4-4147-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cover, top rear (M527/E52545) RC4-4150-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Cradle, fax PCA (M527/E52545) 5851-5605 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 DC controller PC board (PCA) For simplex models - (M506/

E50045)

RM2-8614-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 DC controller PC board (PCA) - M501dn/ M501n RM2-8711-030CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 DC controller PC board (PCA) For duplex models - (M506/M527/

E52545/E50045)

RM2-8612-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 DC controller PC board (PCA) For duplex models - (M507/M528/

E52645/E50145)

RM3-7475-010CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 DC controller PC board (PCA) For simplex models - (M507/E50145) RM3-7476-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Document feeder kit (M527/E52545/M528/E52645 Enterprise) B5L47-67906 Document feeder and image scanner assembly (MFP only) on page 1314 1334 Chapter 6 Parts and diagrams

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Document feeder kit (M527/E52545/M528/E52645 Flow) B5L47-67907 Document feeder and image scanner assembly (MFP only) on page 1314 Door, cartridge (M501/M507/E50145) RM2-5677-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Door, cartridge (M528/E52645) RM2-5691-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Door, cartridge kit (M506n/dn/E50045n/dn) F2A68-67919 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Door, cartridge kit (M506x/E50045x) F2A68-67920 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Door, cartridge kit (M527/E52545) F2A76-67912 Covers (M527/E52545/M528/ E52645) on page 1320 Door, rear (M501/M506/E50045/M507/E50145 duplex models) RM2-5711-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Door, rear (M501/M506/E50045/M507/E50145 simplex models) RM2-5712-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Door, rear (M527/E52545/M528/E52645) RM2-5711-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Door, stapler flap (M527c/f/z/E52545c/f/z) F2A76-40004 Covers (M527/E52545/M528/ E52645) on page 1320 Fan (FM1) RK2-8068-000CN Internal assemblies (1 of 4) on page 1322 Fan (FM2) RK2-8068-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Fax PCA (M527/E52545) CC456-60002 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Fax PCA; HP analog fax 700 accessory (M528/E52645) 2EH31-67901 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Film bias assembly RM2-5689-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Fixing (fuser) assembly 110V-127V (M501/M506/E50045/M527/

E52545)

RM2-2585-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Fixing (fuser) assembly 110V-127V (M507/E50145/M528/E52645) RM2-2585-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Fixing (fuser) assembly 220V-240V (M501/M506/E50045/M527/

E52545)

RM2-2586-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Fixing (fuser) assembly 220V-240V (M507/E50145/M528/E52645) RM2-2586-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Alphabetical parts list 1335
Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Fixing (fuser) power supply (FPS) 110V-127V (includes tray connector) RM2-7948-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Fixing (fuser) power supply (FPS) 220V-240V (includes tray connector) RM2-7949-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter (M507dn) 1PV87-60002 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter (M507dn) China/India 1PV86-60007 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter (M507n) 1PV87-60003 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter (M507n) China/India 1PV86-60008 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter (M507x/dng) China/India 1PV86-60004 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA (M501dn) J8H61-67901 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA (M501dn; China) J8H61-67902 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA (M501n) J8H60-67901 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA (M501n; China) J8H60-67902 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA kit (M506n/dn /E50045n/dn) F2A68-67915 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA kit (M506x /E50045dw) F2A68-67916 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA kit (M507x/dng /E50145) 1PV87-60001 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA kit (M527/E52545) F2A76-67910 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Formatter PCA kit (M528/E52645) 1PV64-60002 Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1336 Chapter 6 Parts and diagrams

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Gear, multipurpose RM2-5700-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Hinge, cartridge door left RC4-3010-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Hinge, cartridge door left RC4-3010-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Hinge, left document feeder (M527/E52545/M528/E52645) COM39-60064 Document feeder and image scanner assembly (MFP only) on page 1314 Hinge, right document feeder (M527/E52545/M528/E52645) COM39-60065 Document feeder and image scanner assembly (MFP only) on page 1314 Holder, transfer roller left RC4-3134-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Holder, transfer roller right RC4-3133-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Image scanner assembly kit (M527/E52545/M528/E52645) F2A76-67909 Document feeder and image scanner assembly (MFP only) on page 1314 Jewel, HP logo (2pc; M507/E50145) 7121-8684 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Keyboard UK (M527/E52545/M528/E52645) B5L47-67020 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard US (M527/E52545/M528/E52645) B5L47-67019 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (ES, PT) 5851-6023 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (FR, IT, RU, DE, ES: UK Kybd) 5851-6019 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (FR-CN, ES-LA, ES: US Keyboard) 5851-6020 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (FR-SW, DE-SW, DA: UK Keyboard) 5851-6021 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (JA-KG, JA-KT) 5851-6024 Document feeder and image scanner assembly (MFP only) on page 1314 Keyboard overlay kit (ZHTW, ZHCN) 5851-6022 Document feeder and image scanner assembly (MFP only) on page 1314 Alphabetical parts list 1337

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Laser/scanner assembly (M501/M506/E50045/M527/E52545) RM2-5528-000CN Internal assemblies (1 of 4) on page 1322 Laser/scanner assembly (M507/E50145/M528/E52645) RM2-2891-000CN Internal assemblies (1 of 4) on page 1322 Link, pressure release (cartridge door) RC4-4479-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Link, pressure release (cartridge door) RC4-4479-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Low-voltage power supply (LVPS) 110V-127V (M501/M506/E50045/

M507/E50145)

RM2-7941-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Low-voltage power supply (LVPS) 220V-240V (M501/M506/

E50045/M507/E50145)

RM2-7942-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Low-voltage power supply (LVPS) 220V-240V (M527/E52545/

M528/E52645)

RM2-7952-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Low-voltage power supply (LVPS) 110V-127V (M527/E52545/M528/

E52645)

RM2-7951-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Memory PCA (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

RM2-7955-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Microswitch (SW2) RK2-0534-000CN Internal assemblies (1 of 4) on page 1322 Motor, main M1 RM2-8684-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Near-field communications (NFC) HP JetDirect 3000W NFC accessory (M528/E52645) J8030-61001 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Near-field communications (NFC) PCA (M527/E52545) B5L24-60001 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Paper feed drive assembly RM2-5715-000CN Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Plate, name (E50145dn) 1PU51-40001 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Plate, name (E52645c) 1PS55-40001 Covers (M527/E52545/M528/ E52645) on page 1320 Plate, name (E52645dn) 1PS54-40001 Covers (M527/E52545/M528/ E52645) on page 1320 Plate, name (M501) J8H60-40001 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Plate, name (M506/E50045) F2A68-40002 Covers (M501/M506/E50045/ M507/E50145) on page 1317 1338 Chapter 6 Parts and diagrams

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Plate, name (M507) 1PV87-40001 Covers (M501/M506/E50045/ M507/E50145) on page 1317 Plate, name (M527/E52545) F2A74-40001 Covers (M527/E52545/M528/ E52645) on page 1320 Plate, name (M528c/z) 1PV66-40001 Covers (M527/E52545/M528/ E52645) on page 1320 Plate, name (M528dn/f) 1PV64-40001 Covers (M527/E52545/M528/ E52645) on page 1320 Plug/cap, fax port (M527/E52545) 5851-1885 Covers (M527/E52545/M528/ E52645) on page 1320 Power supply, high-voltage (HVPS) (M501/M506/E50045/M527/

E52545)

RM2-7945-000CN Internal assemblies (1 of 4) on page 1322 Power supply, high-voltage (HVPS) (M507/E50145/M528/E52645) RM3-7424-000CN Internal assemblies (1 of 4) on page 1322 Registration assembly (M501/M506/E50045/M527/E52545) RM2-5671-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Registration assembly (M507/E50145/M528/E52645) RM2-2577-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Roller and pad, Tray 1 pickup and separation pad kit F2A68-67914 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Roller, Tray 2-3 kit (M501) J8H60-67903 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Roller, Tray 2-x kit (M506/E50045/M507/E50145/M527/E52545/

M528/E52645)

F2A68-67913 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Roller, separation (Tray 2/3) RM2-5745-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Roller, transfer kit F2A68-67910 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Scan-control board (SCB) kit (M527/E52545) B5L47-67903 Document feeder and image scanner assembly (MFP only) on page 1314 Scan-control board (SCB) kit (M528/E52645) B5L47-67901 Document feeder and image scanner assembly (MFP only) on page 1314 Shaft, support RC4-3002-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Shaft, support RC4-3002-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Solenoid assembly RM1-5421-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Alphabetical parts list 1339

Table 6-13 Alphabetical parts list (continued)

Description Part number Table and page

Spring, compression (included in the multipurpose tray roller and separation pad kit) RU8-2935-000CN Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Stapler unit (M527/E52545/M528/E52645) B5L46-60102 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Sticker, stapler cartridge replacement (M527/M528/E52645) B5L24-00035 Covers (M527/E52545/M528/ E52645) on page 1320 Switch, lever assembly RM2-5701-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Switch, power PCA assembly RM2-8597-000CN Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Tray, paper delivery output bin (M501/M506/E50045) RC4-4439-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Tray, paper delivery output bin (M507/E50145) RC4-4141-000CN Covers (M501/M506/E50045/ M507/E50145) on page 1317 Tray, paper delivery output bin (M527/E52545/M528/E52645) RC4-4141-000CN Covers (M527/E52545/M528/ E52645) on page 1320 Wireless embedded PCA (M506z/E50045z/M507z/E50145z/

M527/E52545M528/E52645)

1150-7968 Parts and diagrams: Internal assemblies (3 of 4) on page 1326 1340 Chapter 6 Parts and diagrams

Numerical parts list

Table 6-14 Numerical parts list

Part number Description Table and page

1150-7968 Wireless embedded PCA (M506z/E50045z/M507z/E50145z/

M527/E52545M528/E52645)

Parts and diagrams: Internal assemblies (3 of 4) on page 1326 1PS54-40001 Plate, name (E52645dn) Covers (M527/E52545/M528/ E52645) on page 1320 1PS55-40001 Plate, name (E52645c) Covers (M527/E52545/M528/ E52645) on page 1320 1PU51-40001 Plate, name (E50145dn) Covers (M501/M506/E50045/ M507/E50145) on page 1317 1PV64-40001 Plate, name (M528dn/f) Covers (M527/E52545/M528/ E52645) on page 1320 1PV64-60002 Formatter PCA kit (M528/E52645) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV66-40001 Plate, name (M528c/z) Covers (M527/E52545/M528/ E52645) on page 1320 1PV86-60004 Formatter (M507x/dng) China/India Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV86-60007 Formatter (M507dn) China/India Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV86-60008 Formatter (M507n) China/India Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV87-40001 Plate, name (M507) Covers (M501/M506/E50045/ M507/E50145) on page 1317 1PV87-60001 Formatter PCA kit (M507x/dng /E50145) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV87-60002 Formatter (M507dn) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 1PV87-60003 Formatter (M507n) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 2EH31-67901 Fax PCA; HP analog fax 700 accessory (M528/E52645) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 5851-1885 Plug/cap, fax port (M527/E52545) Covers (M527/E52545/M528/ E52645) on page 1320 5851-5605 Cradle, fax PCA (M527/E52545) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 Numerical parts list 1341

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

5851-5935 Cable, 18-pin control panel (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 5851-5936 Cable, HDMI control panel (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 5851-5938 Cable, HIP USB control panel (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 5851-5939 Cable, WU USB control panel (M527/E52545) Document feeder and image scanner assembly (MFP only) on page 1314 5851-5997 Cable, fax PCA (M527/E52545) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 5851-6019 Keyboard overlay kit (FR, IT, RU, DE, ES: UK Kybd) Document feeder and image scanner assembly (MFP only) on page 1314 5851-6020 Keyboard overlay kit (FR-CN, ES-LA, ES: US Keyboard) Document feeder and image scanner assembly (MFP only) on page 1314 5851-6021 Keyboard overlay kit (FR-SW, DE-SW, DA: UK Keyboard) Document feeder and image scanner assembly (MFP only) on page 1314 5851-6022 Keyboard overlay kit (ZHTW, ZHCN) Document feeder and image scanner assembly (MFP only) on page 1314 5851-6023 Keyboard overlay kit (ES, PT) Document feeder and image scanner assembly (MFP only) on page 1314 5851-6024 Keyboard overlay kit (JA-KG, JA-KT) Document feeder and image scanner assembly (MFP only) on page 1314 7121-8684 Jewel, HP logo (2pc; M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317 B5L24-00035 Sticker, stapler cartridge replacement (M527/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 B5L24-60001 Near-field communications (NFC) PCA (M527/E52545) Parts and diagrams: Internal assemblies (3 of 4) on page 1326 B5L46-40002 Cover, keyboard (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L46-40011 Cover, rear image scanner (M527/E52545) Document feeder and image scanner assembly (MFP only) on page 1314 B5L46-40021 Cover, HIP (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 1342 Chapter 6 Parts and diagrams

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

B5L46-40028 Cover, USB (M527/E52545) Document feeder and image scanner assembly (MFP only) on page 1314 B5L46-60102 Stapler unit (M527/E52545/M528/E52645) Parts and diagrams: Internal assemblies (3 of 4) on page 1326 B5L46-60116 Cable, stapler (M527/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L46-60117 Bezel, control panel (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67018 Control panel kit (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67019 Keyboard US (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67020 Keyboard UK (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67901 Scan-control board (SCB) kit (M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67903 Scan-control board (SCB) kit (M527/E52545) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67906 Document feeder kit (M527/E52545/M528/E52645 Enterprise) Document feeder and image scanner assembly (MFP only) on page 1314 B5L47-67907 Document feeder kit (M527/E52545/M528/E52645 Flow) Document feeder and image scanner assembly (MFP only) on page 1314 CC456-60002 Fax PCA (M527/E52545) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 COM39-60064 Hinge, left document feeder (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 COM39-60065 Hinge, right document feeder (M527/E52545/M528/E52645) Document feeder and image scanner assembly (MFP only) on page 1314 F2A68-40002 Plate, name (M506/E50045) Covers (M501/M506/E50045/ M507/E50145) on page 1317 F2A68-67910 Roller, transfer kit Parts and diagrams: Internal assemblies (3 of 4) on page 1326 F2A68-67913 Roller, Tray 2-x kit (M506/E50045/M507/E50145/M527/E52545/

M528/E52645)

Parts and diagrams: Internal assemblies (3 of 4) on page 1326 Numerical parts list 1343

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

F2A68-67914 Roller and pad, Tray 1 pickup and separation pad kit Parts and diagrams: Internal assemblies (3 of 4) on page 1326
F2A68-67915 Formatter PCA kit (M506n/dn /E50045n/dn) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 F2A68-67916
Formatter PCA kit (M506x /E50045dw) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 F2A68-67919 Door, cartridge kit
(M506n/dn/E50045n/dn) Covers (M501/M506/E50045/ M507/E50145) on page 1317 F2A68-67920 Door, cartridge kit (M506x/E50045x)
Covers (M501/M506/E50045/ M507/E50145) on page 1317 F2A72-67901 1x550-sheet paper feeder (whole unit) Parts and diagrams: 1x550-
sheet paper feeder on page 1330 F2A74-40001 Plate, name (M527/E52545) Covers (M527/E52545/M528/ E52645) on page 1320
F2A76-40003 Cover, stationary stapler, inner (M527c/f/z/E52545c/f/z/ M528c/f/z/E52645c/f/z) Covers (M527/E52545/M528/ E52645) on page
1320 F2A76-40004 Door, stapler flap (M527c/f/z/E52545c/f/z) Covers (M527/E52545/M528/ E52645) on page 1320 F2A76-40005 Cover,
stapler blank (M527dn/E5245dn) Covers (M527/E52545/M528/ E52645) on page 1320 F2A76-40007 Bracket, WiFi PCA
(M506z/E50045/M507z/E50145z/M527/

E52545/M528/E52645)

Parts and diagrams: Internal assemblies (3 of 4) on page 1326 F2A76-50004 Cable, HDMI PAB to SCAM (M527/E52545/M528/E52645)
Document feeder and image scanner assembly (MFP only) on page 1314 F2A76-60112 Cable, WiFi PCA
(M506z/E50045z/M507z/E50145z/M527/E52545/

M528/E52645)

Parts and diagrams: Internal assemblies (3 of 4) on page 1326 F2A76-60113 Cable, stapler 6-pin (M527/E52545/M528/E52645) Parts and
diagrams: Internal assemblies (3 of 4) on page 1326 F2A76-67909 Image scanner assembly kit (M527/E52545/M528/E52645) Document
feeder and image scanner assembly (MFP only) on page 1314 F2A76-67910 Formatter PCA kit (M527/E52545) Parts and diagrams: Internal
assemblies (4 of 4) on page 1328 F2A76-67912 Door, cartridge kit (M527/E52545) Covers (M527/E52545/M528/ E52645) on page 1320
G1W41-67907 Control panel kit (M506x/E50045x) Covers (M501/M506/E50045/ M507/E50145) on page 1317 1344 Chapter 6 Parts and
diagrams

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

J8030-61001 Near-field communications (NFC) HP JetDirect 3000W NFC accessory (M528/E52645) Parts and diagrams: Internal assemblies
(3 of 4) on page 1326 J8H60-40001 Plate, name (M501) Covers (M501/M506/E50045/ M507/E50145) on page 1317 J8H60-67901 Formatter
PCA (M501n) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 J8H60-67902 Formatter PCA (M501n; China) Parts and
diagrams: Internal assemblies (4 of 4) on page 1328 J8H60-67903 Roller, Tray 2-3 kit (M501) Parts and diagrams: Internal assemblies (3 of 4)
on page 1326 J8H60-67904 Control panel (M501) Covers (M501/M506/E50045/ M507/E50145) on page 1317 J8H61-67901 Formatter PCA
(M501dn) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 J8H61-67902 Formatter PCA (M501dn; China) Parts and diagrams:
Internal assemblies (4 of 4) on page 1328 K0Q15-60106 Control panel E50145 Covers (M501/M506/E50045/ M507/E50145) on page 1317
K0Q15-67901 Control panel kit (M507x/E50145x) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-3002-000CN Shaft,
support Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-3002-000CN Shaft, support Covers (M527/E52545/M528/ E52645)
on page 1320 RC4-3010-000CN Hinge, cartridge door left Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-3010-000CN
Hinge, cartridge door left Covers (M527/E52545/M528/ E52645) on page 1320 RC4-3133-000CN Holder, transfer roller right Parts and
diagrams: Internal assemblies (3 of 4) on page 1326 RC4-3134-000CN Holder, transfer roller left Parts and diagrams: Internal assemblies (3
of 4) on page 1326 RC4-3219-000CN Cover, full detect sensor Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-3219-000CN
Cover, full detect sensor Covers (M527/E52545/M528/ E52645) on page 1320 RC4-4137-000CN Cover, right (M507/E50145) Covers
(M501/M506/E50045/ M507/E50145) on page 1317 Numerical parts list 1345

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

RC4-4141-000CN Tray, paper delivery output bin (M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317
RC4-4141-000CN Tray, paper delivery output bin (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320
RC4-4142-000CN Cover, HIP (M506/E50045/M507/E50145 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317
RC4-4147-000CN Cover, top left (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 RC4-4149-000CN
Cover, USB (M506/E50045/M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-4150-000CN Cover, top rear
(M527/E52545) Covers (M527/E52545/M528/ E52645) on page 1320 RC4-4200-000CN Cover, formatter (M501) Covers
(M501/M506/E50045/ M507/E50145) on page 1317 RC4-4433-000CN Cover, I/O (M506/E50045/M507/E50145) Covers
(M501/M506/E50045/ M507/E50145) on page 1317 RC4-4433-000CN Cover, I/O (M527/E52545) Covers (M527/E52545/M528/ E52645) on
page 1320 RC4-4437-000CN Cover, right (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320
RC4-4437-000CN Cover, right (M501/M506/E50045) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-4439-000CN Tray,
paper delivery output bin (M501/M506/E50045) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-4479-000CN Link, pressure

release (cartridge door) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RC4-4479-000CN Link, pressure release (cartridge door) Covers (M527/E52545/M528/ E52645) on page 1320 RC5-5148-000CN Cover, WiFi Covers (M501/M506/E50045/ M507/E50145) on page 1317 RK2-0534-000CN Microswitch (SW2) Internal assemblies (1 of 4) on page 1322 RK2-6259-000CN Cable, flat-flexible Internal assemblies (1 of 4) on page 1322 RK2-6260-000CN Cable, flat-flexible Internal assemblies (1 of 4) on page 1322 RK2-6261-000CN Cable, flat flexible (M506/E50045/M507/E50145/M527/E52545/

M528/E52645)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RK2-6526-000CN Cable, flat flexible (M501) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RK2-7067-000CN Cable, USB (M506/E50045) Internal assemblies (1 of 4) on page 1322 1346 Chapter 6 Parts and diagrams

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

RK2-7067-000CN Cable, USB (M507/E50145) Internal assemblies (1 of 4) on page 1322 RK2-7104-000CN Cable, HIP (M506/E50045 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RK2-8068-000CN Fan (FM1) Internal assemblies (1 of 4) on page 1322 RK2-8068-000CN Fan (FM2) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RK2-8657-000CN Cable, flat flexible (FFC) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RK3-0503-000CN Cable, flat flexible (FFC) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RK3-0526-000CN Cable, HIP (M507/E50145 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RL2-0885-000CN Case, formatter PCA (M506/E50045/M507/E50145) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RL2-0888-000CN Case, formatter (M501) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RL2-0895-000CN Case, formatter (M527/E52545/M528/E52645) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM1-5421-000CN Solenoid assembly Parts and diagrams: Internal assemblies (3 of 4) on page 1326 RM2-2577-000CN Registration assembly (M507/E50145/M528/E52645) Parts and diagrams: Internal assemblies (3 of 4) on page 1326 RM2-2585-000CN Fixing (fuser) assembly 110V-127V (M501/M506/E50045/M527/

E52545)

Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-2585-000CN Fixing (fuser) assembly 110V-127V (M507/E50145/M528/E52645) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-2586-000CN Fixing (fuser) assembly 220V-240V (M501/M506/E50045/M527/

E52545)

Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-2586-000CN Fixing (fuser) assembly 220V-240V (M507/E50145/M528/E52645) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-2587-000CN Cover, top (M507/E50145 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-2596-000CN Cable, TAG assembly (M507/E50145/M528/E52645) Internal assemblies (1 of 4) on page 1322 Numerical parts list 1347

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

RM2-2607-000CN Cover, top (M507/E50145 simplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-2610-000CN Control panel (507n/dn) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-2891-000CN Laser/scanner assembly (M507/E50145/M528/E52645) Internal assemblies (1 of 4) on page 1322 RM2-5528-000CN Laser/scanner assembly (M501/M506/E50045/M527/E52545) Internal assemblies (1 of 4) on page 1322 RM2-5671-000CN Registration assembly (M501/M506/E50045/M527/E52545) Parts and diagrams: Internal assemblies (3 of 4) on page 1326 RM2-5677-000CN Door, cartridge (M501/M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5686-000CN Cover, top (M506/E50045 duplex MF models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5687-000CN Cover, top (M506/E50045 simplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5689-000CN Film bias assembly Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-5690-000CN Cassette (Tray 2) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-5691-000CN Door, cartridge (M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 RM2-5699-000CN Cover, top (M506/E50045 duplex LCD models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5700-000CN Gear, multipurpose Parts and diagrams: Internal assemblies (3 of 4) on page 1326 RM2-5701-000CN Switch, lever assembly Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-5702-000CN Cable, TAG assembly (M501/M506/E50045/M527/E52545) Internal assemblies (1 of 4) on page 1322 RM2-5711-000CN Door, rear (M501/M506/E50045/M507/E50145 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5711-000CN Door, rear (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 RM2-5712-000CN Door, rear (M501/M506/E50045/M507/E50145 simplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5713-000CN Cover, left (M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5713-000CN Cover, left (M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 1348 Chapter 6 Parts and diagrams

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

RM2-5715-000CN Paper feed drive assembly Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-5717-000CN Cover, formatter (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 RM2-5718-000CN Cover, top (M527/E52545/M528/E52645) Covers (M527/E52545/M528/ E52645) on page 1320 RM2-5725-000CN Cover, formatter (M506/E50045/M507/E50145) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5726-000CN Cover, top (M501 duplex models) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5727-000CN Cover, left (M501/M506/E50045) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5727-000CN Cover, left (M527/E52545) Covers (M527/E52545/M528/ E52645) on page 1320 RM2-5735-000CN Cover, top (M501) Covers (M501/M506/E50045/ M507/E50145) on page 1317 RM2-5745-000CN Roller, separation (Tray 2/3) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-7941-000CN Low-voltage power supply (LVPS) 110V-127V (M501/M506/E50045/

M507/E50145)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7942-000CN Low-voltage power supply (LVPS) 220V-240V (M501/M506/

E50045/M507/E50145)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7945-000CN Power supply, high-voltage (HVPS) (M501/M506/E50045/M527/

E52545)

Internal assemblies (1 of 4) on page 1322 RM2-7948-000CN Fixing (fuser) power supply (FPS) 110V-127V (includes tray connector) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7949-000CN Fixing (fuser) power supply (FPS) 220V-240V (includes tray connector) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7951-000CN Low-voltage power supply (LVPS) 110V-127V (M527/E52545/M528/

E52645)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7952-000CN Low-voltage power supply (LVPS) 220V-240V (M527/E52545/

M528/E52645)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-7955-000CN Memory PCA (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-8514-000CN Clutch, paper re-pickup assembly (duplex LCD and MF models) Parts and diagrams: Internal assemblies (2 of 4) on page 1324 Numerical parts list 1349

Table 6-14 Numerical parts list (continued)

Part number Description Table and page

RM2-8597-000CN Switch, power PCA assembly Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-8612-000CN DC controller PC board (PCA) For duplex models - (M506/M527/

E52545/E50045)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-8614-000CN DC controller PC board (PCA) For simplex models -(M506/

E50045)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM2-8684-000CN Motor, main M1 Parts and diagrams: Internal assemblies (2 of 4) on page 1324 RM2-8711-030CN DC controller PC board (PCA) - M501dn/ M501n Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM3-7424-000CN Power supply, high-voltage (HVPS) (M507/E50145/M528/E52645) Internal assemblies (1 of 4) on page 1322 RM3-7475-010CN DC controller PC board (PCA) For duplex models - (M507/M528/

E52645/E50145)

Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RM3-7476-000CN DC controller PC board (PCA) For simplex models - (M507/E50145) Parts and diagrams: Internal assemblies (4 of 4) on page 1328 RU8-2935-000CN Spring, compression (included in the multipurpose tray roller and separation pad kit) Parts and diagrams: Internal assemblies (3 of 4) on page 1326 1350 Chapter 6 Parts and diagrams

Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 A Review the certificates of volatility for the printers. Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 1351

Figure A-1 Certificate of Volatility (1 of 2; M501)

Hewlett-Packard Certificate of Volatility

Model: HP LaserJet Pro M501 Part Number: J8H60A=M501n J8H61A=M501dn Address:

HP Development Company

11311 Chinden Blvd

Boise, ID 83714

Volatile Memory

Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (SRAM, DRAM, etc): Size: 256MB User Modifiable: Function: Used for temporary storage during the processing of jobs and for applications running on the OS. Steps to clear memory:

When the printer is powered

OFF, the memory is erased. Yes No Type (SRAM, DRAM, etc): Size: User Modifiable: Function:

Used for temporary storage

during the processing of jobs and for applications running on the OS. Steps to clear memory:

When the printer is powered

OFF, the memory is erased. 256MB Yes No . Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Non-Volatile Memory

Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: 2GB Yes No Device Firmware Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Mass Storage

Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No USB Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)? Yes No If Yes please describe below The front USB host can accept print jobs, scan uploads, photos and can be used to upload printer firmware. Can any data other than scan upload be sent to the USB device)? Yes No If Yes please describe below Rear USB host when configured will accept stored jobs, encrypted files stored and deleted by user. 1352 Appendix A Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645

Figure A-2 Certificate of Volatility (2 of 2; M501)

RF/Rfid

Does the item use RF or RFID for receive or transmit of any data including remote diagnostics. (e.g. Cellular phone, Bluetooth) Yes No If Yes please describe below Purpose: Wireless Information string Frequency: Bandwidth: Modulation: Effective Radiate Power (ERP): Specifications:

Other Transmission Capabilities

Does the device employ any other methods of non-wired access to transmit or receive any data whatsoever (e.g. anything other than standard hard wired TCP/IP, direct USB, or parallel connections)? Yes No If Yes please describe below: Purpose: Frequency: Bandwidth: Modulation:

Effective Radiate Power (ERP): Specifications:

Other Capabilities

Does the device employ any other method of communications such as a Modem to transmit or receive any data whatsoever? Yes No If Yes please describe below: Purpose:

Specifications

Figure A-3 Certificate of Volatility (1 of 2; M506)

HP Certificate of Volatility

Model: Part Number: Address: LaserJet Enterprise M506 M506n = F2A68A M506dn = F2A69A M506x = F2A70A

HP Development Company

11311 Chinden Blvd

Boise, ID 83714

Volatile Memory

Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: DRAM 512MB Yes No Operation system and print buffer

There are no steps to clear this

data. Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Non-Volatile Memory

Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: EEPROM 32KB Yes No Store customer setting data for backup/restore

There are no steps to clear this

data. Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: SPI 4MB Yes No BIOS There are no steps to clear this data. Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory:

None Yes No

Mass Storage

Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: eMMC 4GB Yes No OS and user data Firmware update Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: HDD 320GB Yes No OS and user data Firmware update USB Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)?

Yes No If Yes please describe below

Walk-up USB print

Can any data other than scan upload be sent to the USB device)?

Yes No If Yes please describe below

Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 1353

Figure A-4 Certificate of Volatility (2 of 2; M506)

RF/RFID

Does the item use RF or RFID for receive or transmit of any data including remote diagnostics. (e.g. Cellular phone, Bluetooth) Yes No If Yes please describe below Purpose Frequency: Bandwidth: Modulation: Effective Radiate Power (ERP): Specifications:

Other Transmission Capabilities

Does the device employ any other methods of non-wired access to transmit or receive any data whatsoever (e.g. anything other than standard hard wired TCP/IP, direct USB, or parallel connections)? Yes No If Yes please describe below: Purpose: Wireless direct print. Frequency: 2.4Ghz Bandwidth: Modulation: Effective Radiate Power (ERP: Specifications: 802.11 b/g/n

Other Capabilities

Does the device employ any other method of communications such as a Modem to transmit or receive any data whatsoever? Yes No If Yes please describe below: Purpose: NFC; to support tap to print only Specifications: NFC Tag Type 4 ISO 14443B

Author Information

Name: Title: Email: Business Unit:

Security Technical

Marketing Engineer

IPG Date Prepared: 06/29/15 1354 Appendix A Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645

Figure A-5 Certificate of Volatility (1 of 2; M527)

HP Certificate of Volatility

Model: Part Number: Address: LaserJet Enterprise M527 M527dn = F2A76A M527f = F2A77A M527z = F2A78A

HP Development Company

11311 Chinden Blvd

Boise, ID 83714

Volatile Memory

Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: DRAM 1792MB Yes No Operation system and print buffer

There are no steps to clear this

data. Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Non-Volatile Memory

Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: EEPROM 32KB Yes No Store customer setting data for backup/restore

There are no steps to clear this

data. Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: SPI 4MB Yes No BIOS There are no steps to clear this data. Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory:

None Yes No

Mass Storage

Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: eMMC 16GB Yes No OS and user data Firmware update Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: HDD 320GB Yes No OS and user data Firmware update USB Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)?

Yes No If Yes please describe below

Walk-up USB print

Can any data other than scan upload be sent to the USB device)?

Yes No If Yes please describe below

Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 1355

Figure A-6 Certificate of Volatility (2 of 2; M527)

RF/RFID

Does the item use RF or RFID for receive or transmit of any data including remote diagnostics. (e.g. Cellular phone, Bluetooth) Yes No If Yes please describe below Purpose Frequency:) Bandwidth: Modulation: Effective Radiate Power (ERP): Specifications:

Other Transmission Capabilities

Does the device employ any other methods of non-wired access to transmit or receive any data whatsoever (e.g. anything other than standard hard wired TCP/IP, direct USB, or parallel connections)? Yes No If Yes please describe below: Purpose: Wireless direct print. Frequency: 2.4Ghz Bandwidth: Modulation: Effective Radiate Power (ERP: Specifications: 802.11 b/g/n

Other Capabilities

Does the device employ any other method of communications such as a Modem to transmit or receive any data whatsoever? Yes No If Yes please describe below: Purpose: NFC; to support tap to print only Specifications: NFC Tag Type 4 ISO 14443B

Author Information

Name: Title: Email: Business Unit:

Security Technical

Marketing Engineer

IPG Date Prepared: 06/29/15 1356 Appendix A Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645

Figure A-7 Certificate of Volatility (1 of 2; M507/E50145)

Hewlett-Packard Certificate of Volatility

Model:

HP LaserJet Enterprise

M507 series

HP LaserJet Managed

Enterprise E50145 series Part Number:

Enterprise

1PV86A=M507n Managed 1PU51A=E50145dn 1PV87A=M507dn 1PV88A=M507x 1PV89A=M507dng Address:

Hewlett Packard Company

11311 Chinden Blvd

Boise, ID 83714

Volatile Memory

Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (SRAM, DRAM, etc):

DDR3 - DRAM

Size: 1GB User Modifiable: Function: Operation system and print/scan buffer Steps to clear memory:

When the printer is powered off

the memory is erased. Yes No Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No . Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Non-Volatile Memory

Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: IOD EEPROM 32KB Yes No Store customer setting data for backup/restore

There are no steps to clear this

data. Type (Flash, EEPROM, etc):

SPI Flash

Size: User Modifiable: Function: Steps to clear memory: 4MB Yes No Contains the boot code and factory product configuration data required for the device to function. User modifications are limited to downloading digitally signed HP firmware images.

There are no steps to clear this

data Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Mass Storage

Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: HDD 320GB Yes No OS and user data Firmware update Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: EMMC 8GB Yes No OS and user data Firmware update USB Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)?

Yes No If Yes please describe below

Print jobs, HP digitally signed firmware upgrades, 3rd party application loading. USB ports can be disabled. Can any data other than scan upload be sent to the USB device)?

Yes No If Yes please describe below

Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 1357

Figure A-8 Certificate of Volatility (2 of 2; M507/E50145) 1358 Appendix A Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645

Figure A-9 Certificate of Volatility (1 of 2; M528/E52645)

Hewlett-Packard Certificate of Volatility

Model:

HP LaserJet Enterprise

M528 series

HP LaserJet Managed

Enterprise E52645 series Part Number:

Enterprise

1PV64A=M528dn Managed 1PS54A=E52645dn 1PV65A=M528f 1PS55A=E52645c 1PV66A=M528c 1PV67A=M528z Address:

Hewlett Packard Company

11311 Chinden Blvd

Boise, ID 83714

Volatile Memory

Does the device contain volatile memory (Memory whose contents are lost when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (SRAM, DRAM, etc):

DDR3 - DRAM

Size: 1GB User Modifiable: Function: Operation system and print/scan buffer Steps to clear memory:

When the printer is powered off

the memory is erased. Yes No Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No . Type (SRAM, DRAM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Non-Volatile Memory

Does the device contain non-volatile memory (Memory whose contents are retained when power is removed)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: IOD EEPROM 32KB Yes No Store customer setting data for backup/restore

There are no steps to clear this

data. Type (Flash, EEPROM, etc):

SPI Flash

Size: User Modifiable: Function: Steps to clear memory: 4MB Yes No Contains the boot code and factory product configuration data required for the device to function. User modifications are limited to downloading digitally signed HP firmware images.

There are no steps to clear this

data Type (Flash, EEPROM, etc): Size: User Modifiable: Function: Steps to clear memory: Yes No

Mass Storage

Does the device contain mass storage memory (Hard Disk Drive, Tape Backup)? Yes No If Yes please describe the type, size, function, and steps to clear the memory below Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: HDD 320GB Yes No OS and user data Firmware update Type (HDD, Tape, etc): Size: User Modifiable: Function: Steps to clear memory: EMMC 8GB Yes No OS and user data Firmware update USB Does the item accept USB input and if so, for what purpose (i.e Print Jobs, device firmware updates, scan upload)?

Yes No If Yes please describe below

Print jobs, HP digitally signed firmware upgrades, 3rd party application loading. USB ports can be disabled. Can any data other than scan upload be sent to the USB device)?

Yes No If Yes please describe below

Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645 1359

Figure A-10 Certificate of Volatility (2 of 2; M528/E52645) Diagnostic service logs can be uploaded. Print files can be printed via a USB thumb drive.

RF/RFID

Does the item use RF or RFID for receive or transmit of any data including remote diagnostics. (e.g. Cellular phone, Bluetooth) Yes No If Yes please describe below Purpose: Frequency: Bandwidth: Modulation: Effective Radiate Power (ERP): Specifications:

Other Transmission Capabilities

Does the device employ any other methods of non-wired access to transmit or receive any data whatsoever (e.g. anything other than standard hard wired TCP/IP, direct USB, or parallel connections)? Yes No If Yes please describe below: Purpose: WiFi Direct Print Frequency: 2.4 GHz, 5 GHz Bandwidth: 2401 - 2495 MHz; depending on selected channel in 2.4GHz band. 5180 - 5825 MHz; depending on selected channel in 5GHz band. Modulation: Effective Radiate Power (ERP): Specifications: 802.11 b/g/n

Other Transmission Capabilities

Does the device employ any other methods of non-wired access to transmit or receive any data whatsoever (e.g. anything other than standard hard wired TCP/IP, direct USB, or parallel connections)? Yes No If Yes please describe below: Purpose: Device Beaconsing, Secure Print Apps Frequency: 2.4 GHz Bandwidth: 2400-2483.5 MHz; depending on selected channel. Modulation: Effective Radiate Power (ERP): Specifications: BTLE4.0 compliant

Other Capabilities

Does the device employ any other method of communications such as a Modem to transmit or receive any data whatsoever? Yes No If Yes please describe below: Purpose: Specifications: Vendor Engineer/SME Representative Information Date completed: Fax/Email 12/31/19 david.m.vittoe@hp.com 1360 Appendix A Certificate of Volatility: HP LaserJet Pro M501, HP LaserJet Enterprise M506, M507, M527, M528, HP LaserJet Managd Enterprise E50145, E52645

Index Symbols/Numerics 1x550-sheet paper feeder (4 of 4), parts 1330 1x550-sheet paper feeder controller PCA connections, diagrams 136, 164 2ndary service menu (M501) 425, 426 550-sheet paper feeder paper path 62 550-sheet paper feeder, removing and replacing 1252 550-sheet tray clearing jams 403

76.00.24 270

A accessories 1309 accessories installed, information 136, 175, 180 accessories, 550-sheet paper feeder remove and replace 1252 accessories, FAX remove and replace 1267 accessories, internal USB ports

(M506/E50045)

remove and replace 1285 accessories, internal USB ports

(M507/E50145)

remove and replace 1291 accessories, internal USB ports

(M527/E52545/M528/E52645)

remove and replace 1274 accessories, toner part numbers 1309 accessories) remove and replace 1252 acoustic specifications 5, 14 anti-theft feature JetIntelligence 49 toner cartridge 49 assemblies base printer, remove and replace 527 assembly locations 1 authentication JetIntelligence 49 toner cartridge 49 authorized service providers, parts 1309 auto on / auto off mode

M501 22

auto on / auto off mode (M501) setup and operation 22 automatic document feeder scanning and image capture

(M527/E52545/M528/E52645

only) 69 B backup error 32.WX.YZ error 136, 269 reset error 136, 269 restore error 136, 269 basic printer operation 18 bias generation high-voltage power supply 34 bin, output locating 1, 2 blank pages troubleshooting 418 block diagram cross section 136, 158 external plug and port locations 136, 165 printed circuit assembly (PCA) connector locations 136, 160 sensors and switches 136, 155 browser requirements

HP Embedded Web

Server 136, 182 C cables USB, troubleshooting 418 Calibrate/Cleaning menu (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645), control panel 261, 262 Calibrate/Cleaning menu (M506/

M507/E50145, M527/M528/

E52645), control panel 136 cartridge dynamic security 48 life detection 47 memory chip 47 presence detection 47 toner level detection 47 cartridge door assembly, removing and replacing 561 cartridges, toner part numbers 1309 cassette presence detection trays 3-5 65 caution 15, 448 certificate of volatility 5, 1351

Channel partners

WISE 15, 75, 448, 1307

checklist problems 79 checklist (M501) problems 77 checklists pre-troubleshooting 106 circuit diagrams 136, 172 clean the paper path
cleaning page printing 372 cleaning glass (M527/M528/

E52645) 372

mode (M501) 425 paper path 280, 372 printer 372 Index 1361
rollers document feeder (M527/

M528/E52645) 372

tray 1 rollers and separation pad 372, 376 tray 2-X rollers 372, 383 cleaning page 136, 261, 262 clutches DC controller 28 image-formation
system 53 cold reset 428 component test (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645)

special mode test 152 component test (M506/M507,

M527/M528)

special mode test 136 component test (M506/M507/

E50145, M527/M528/E52645)

special mode test 136 components DC controller 26 engine-control system 26 fuser 35 paper feeder 65 paper handling 50 toner cartridge 46
components (M506/M507, M527/ M528) diagnostic tests 136 components (M506/M507/E50145,

M527/M528/E52645)

diagnostic tests 136, 152 configuration pages information 136, 175, 180 printing 136, 175 connections 1x550-sheet paper feeder controller
PCA 136, 164 DC controller 136, 160 connector error 65.WX.YZ error 136, 269 control functions fuser 35 control panel 23 button test 425, 426
connections diagram 136, 160

CPMD 136

display test 425, 426 LED test 425, 426 locating 1, 2 menus 136, 185 control panel (M501, 507n/dn, and E50145n/dn), removing and
replacing 530 control panel (M506x/E50045x/ M507x/E50145x), removing and replacing 504 control panel (M527/E52545/ M528/E52645),
removing and replacing 492 control panel diagnostic flowcharts (M506x and

M527) 106

control panel diagnostic flowcharts (M506x/M507x,

M527/E52545/M528/

E52645) 112, 130

control panel menus 194 control-panel cover (M527/E52545/ M528/E52645), removing and replacing 534 control-panel menus (M501) 136,
185 control-panel menus (M506/M507/

E50145, M527/M528/

E52645) 136

conventions used 15, 448 cooling areas and fans 28 counts 428 copy scan 428 document feeder 428 document feeder duplex 428 document feeder roller clean 428 document feeder roller interval 428 document feeder simplex 428 engine cycles 428 fax scan 428 flatbed cycle 428 page, reset 428

See also pages counts

refurbish cycle 428 reset after replacing formatter 428 send scan 428 covers remove and replace 528 covers MFP, parts 1319 covers SFP, parts 1316 covers, cartridge door remove and replace 561 covers, control-panel cover (M527/ E52545/M528/E52645) remove and replace 534 covers, formatter remove and replace 528 covers, left cover remove and replace 582 covers, rear door remove and replace 567 covers, right cover remove and replace 570 covers, stapler door or stapler blank cover (M527/E52545/ M528/E52645) remove and replace 592 covers, stapler stationary (inner) cover (M527/E52545/M528/ E52645) remove and replace 596 covers, top cover (M501/M506/ E50045/M507/E50145) remove and replace 633 covers, top cover (M527/E52545/ M528/E52645) remove and replace 603 covers, top-left cover (M527/ E52545/M528/E52645) remove and replace 537 covers, top-rear cover (M527/ E52545/M528/E52645) remove and replace 540

CPU 24

cross section block diagram 136, 158 CSR control panel (M501, 507n/dn, and E50145n/dn) 530 control panel (M506x/E50045x/ M507x/E50145x) 504 control panel (M527/E52545/

M528/E52645) 492

keyboard (527c/z, E52545c/z, M528c/z, and E52645c/z) 519 white backing (M527/E52545/

M528/E52645) 513

CSR part numbers 1312 current settings pages 83 customer self-repair (CSR) A parts and accessories 456 customer self-repair kits 1312 D date codes for firmware 136, 175, 180 product first used 428

DC controller

clutches 28 1362 Index

components 26 connections, diagrams 136, 160 fans 28 motors 27 sensors 29 solenoids 28 switches 29

DC controller communication error

55.WX.YZ error 136, 269

DC controller firmware error

70.WX.YZ error 136, 270 DC controller, removing and replacing 967 DC motors 27 DCC, removing and replacing 967 decoding message 136 default settings, restoring

NVRAM initialization

(M501) 425, 427

defaults restoring 425 restoring (M501) 425 defeating interlocks 136, 140 determine problem source 106 determine the installed revision of firmware (M501) 439 determine the installed revision of firmware (M506/E50045/M507/

E50145, M527/E52545/M528/

E52645) 441

development process 44 diagnostics engine 136, 140 networks 136 diagnostics (M506/M507, M527/ M528) component 136

LED 136

diagnostics (M506/M507/E50145,

M527/M528/E52645)

component 136, 152

LED 136, 137

diagrams 1313 block 136, 155 circuit 136, 172

DC controller

connections 136, 160 formatter connectors

(M501) 136, 161

formatter connectors

(M506) 136

formatter connectors (M506/

E50045/M507/E50145) 162

formatter connectors (M527/

E52545/M528/E52645) 163

formatter connectors (M527/

M528/E52645) 136

main assemblies (printer base) 136, 168 motor and fans 136, 168, 170 printed circuit assemblies (PCAs; printer base) 136, 168, 171 rollers and pads (printer base) 136, 168, 169 timing 136, 172 digital sending error (firmware) 44.WX.YZ error 136, 269 dimensions, printer M501 5, 6 dimensions, printer M506/E50045/

M507/E50145 8

dimensions, printer M506/

M507 5, 6

dimensions, printer M527/E52545/

M528/E52645 10

dimensions, printer M527/

M528 5, 6

DIMM

(M506/E50045/M507/E50145/

M527/E52545/M528/E52645)

removing and replacing 476 document feeder automatic document feeder

(M527/E52545/M528/E52645

only) 69 jams 396 paper-feeding problems (M527/

M528) 392

paper-feeding problems

(MFP) 393

document feeder (M527/E52545/ M528/E52645), removing and replacing 547 document feeder and scanner whole units, parts 1314
document feeder count document feeder pages 428 document feeder error 31.WX.YZ error 136, 269 document feeder kit interval 428
document feeder maintenance kit

(M527/E52545/M528/E52645)

removing and replacing 1258 document feeder rollers (M527/

M528/E52645)

cleaning 372 doors remove and replace 528 drum cleaning 46 dual in-line memory module (DIMM)

(M506/E50045/M507/E50145/

M527/E52545/M528/E52645)

removing and replacing 476 duplex printing accessory connections diagram 136, 160 duplexer clearing jams 411 duplexer error 69.WX.YZ
error 136, 270 duplexing unit motors 27 dynamic security toner cartridge 48 dynamic security enabled printers 48 E EconoMode setting 280
electrical specifications 5, 14 electrostatic discharge 452 email problems get help from WISE 447

Embedded Jetdirect error

80.WX.YZ error 136, 270 embedded Multi-Media Card (eMMC), removing and replacing 464 Embedded Web Server (EWS) features 136, 182
embedded web server (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 441,

443 engine diagnostics 136, 140 test page 136, 140 engine error (LaserJet) 46.WX.YZ error 136, 269 63.WX.YZ error 136, 269 engine error
(PageWide) 61.WX.YZ error 136, 269 engine power supply connections diagram 136, 160 engine-control system components 26 envelope
feeder connections diagram 136, 160 error fault 136 Index 1363

error log (M501) information 136, 175 event log 102 clear 428 clear using LCD control panel 102, 105 clear using touchscreen control panel
102, 104 information 180 event log (M506/M507, M527/ M528) information 175 event log (M506/M507/E50145,

M527/M528/E52645)

information 136 event log error (firmware) 42.WX.YZ error 136, 269 exhaust fans 28 exploded views, parts and diagrams 1313 Explorer,
versions supported

HP Embedded Web

Server 136, 182 external panels remove and replace 528 external plug and port locations block diagram 136, 165 F factory defaults, restoring

NVRAM initialization

(M501) 425, 427

failure detection laser/scanner 38 motors 27 failure detection (low-voltage power supply 33 fan (FM1), removing and replacing 862 fan (FM2), removing and replacing 874 fan error 58.WX.YZ error 136, 269 fans connections diagram 136, 160 DC controller 28 exhaust 28 intake 28 fasteners used in this printer 453 FAX remove and replace 1267 fax printed-circuit board (M527c/f/z, E52545c/f/c, M528c/f/z, and E52645c/f/z) removing and replacing 1267 fax problems get help from WISE 447 field replaceable units base printer 724 firmware date codes 136, 175, 180 firmware communication error 49.WX.YZ error 136, 269 firmware install error 99.WX.YZ error 136, 270 hard disk error 136, 270 remote firmware upgrade error 136, 270 firmware version 425, 426 firmware, downloading new (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 441

firmware, downloading new

M501) 439

flatbed scanning and image capture

(M527/E52545/M528/E52645

only) 68 flowcharts troubleshooting 106, 107 formatter connections diagram 136, 160 locating 3 resets after replacing 428 formatter ; removing and replacing 528 formatter case, removing and replacing 818 formatter connectors (M501) diagrams 136, 161 formatter connectors (M506) diagrams 136 formatter connectors (M506/

E50045/M507/E50145)

diagrams 162 formatter connectors (M527/

E52545/M528/E52645)

diagrams 163 formatter connectors (M527/

M528/E52645)

diagrams 136 formatter control system 21 formatter lights 136, 137 formatter, removing and replacing 771 FRUs, remove and replace base printer 724 fuser 34 clearing jams 409 components 35 connections diagram 136, 160 control functions 35 control-circuit function 34

See also fusing and delivery

unit identification 37 life detection 37 temperature protection 37 fuser error 41.WX.YZ error 136, 269 laser scanner error 136, 269 paper path error 136, 269 fuser error (LaserJet) 50.WX.YZ error 136, 269 fuser power supply (FPS), removing and replacing 920 fuser test page print 136, 181 fuser test page (M506/M507/

E50145, M527/M528/E52645)

print 136 fuser, removing and replacing 757 fusing process 45 G glass (M527/M528/E52645), cleaning 372 guide, print-quality troubleshooting 293 H hard disk partition error 98.WX.YZ error 136, 270 hard-disk drive, HDD) removing and replacing 469 hardware integration pocket (HIP) is not functioning 106, 112, 130, 134 HDD, remove and replace 469 heartbeat LED 136-138 heaters fuser 35 high-voltage power supply (HVPS) bias generation 34 circuits 34 operations 33 high-voltage power supply, removing and replacing 1012 1364 Index

home button is unresponsive 106, 112, 130, 133 HP Device Toolbox, using

(M501) 136, 182

HP embedded Jetdirect page 177

HP embedded Jetdirect page

(M506/M507, M527/M528) 175

[HP embedded Jetdirect page](#)

[\(M506/M507/E50145, M527/](#)

[M528/E52645\) 136](#)

HP Embedded Web Server (EWS) features 136, 182 HP EWS, using (M501) 136, 182

[HP internal users](#)

[WISE 15, 75, 448, 1307](#)

[HP Jetdirect print server](#)

configuration page 136, 175, 177 lights 136, 137

[NVRAM initialization](#)

[\(M501\) 425, 427](#)

HVPS (high-voltage power supply) bias generation 34 circuits 34 operations 33 HVPS, removing and replacing 1012 I/O interfaces 24 image capture system scanning (M527/E52545/M528/ E52645 only) 68 image defects, product specific 293, 296 image defects, repetitive ruler 293, 296 image quality check toner cartridge status 280 check toner-cartridge status 282 tray 1 rollers and separation pad, clean 372, 376 tray 2-X rollers, clean 372, 383 image quality issues examples and solutions 293 image-formation process development process 44 drum cleaning 46 fusing process 45 laser-beam exposure 43 primary charging 43 primary transfer process 44 separation process 45 image-formation system clutches 53 motors 53 solenoids 53 image-information process 39 individual component diagnostics 136 initial rotation period 19 initialization

[NVRAM \(M501\) 425, 427](#)

input accessory error 67.WX.YZ error 136, 270 input/output error 40.WX.YZ error 136, 269 input/output interfaces 24 installation date calculation 428 verify for optional accessories 136, 175 installing internal USB ports (M506/

[E50045\) 1285](#)

internal USB ports (M507/

[E50145\) 1291](#)

internal USB ports (M527/

[E52545/M528/](#)

[E52645\) 1274](#)

intake fans 28 integrated scanner assembly

[\(M527/E52545/M528/E52645\),](#)

removing and replacing 694 interlocks defeating 136, 140 internal assemblies (1 of 4), parts 1321 internal assemblies (2 of 4), parts 1323 internal assemblies (3 of 4), parts 1325 internal assemblies (4 of 4), parts 1327 internal assemblies base printer 527 internal diagnostics error 90.WX.YZ error 136, 270 video display error 136, 270 internal parts base printer, remove and replace 527 internal USB ports (M506/E50045) installing 1285 internal USB ports (M507/E50145) installing 1291 internal USB ports (M527/E52545/

[M528/E52645\)](#)

installing 1274 Internet Explorer, versions supported

HP Embedded Web

Server 136, 182 IPv4 information 136, 175, 177, 178 IPv6 information 136, 175, 177, 178 J jam error (LaserJet) 13.WX.YZ error 136, 268 jam error (PageWide) 13.WX.YZ error 136, 268 jams 550-sheet trays 403 auto-navigation 396 causes of 396 detection in trays 3-5 66 document feeder 396 duplexer 411 fuser 409 output bin 411 rear door 409 recovery 416 sensor locations 395 sensors 395 toner cartridge area 407 Tray 1 400 Tray 2 403 jams (M506/E50045/M507/E50145,

M527/E52545/M528/E52645)

diagnostic test for 143 jams (M506/M507, M527/M528) diagnostic test for 136 jams (M506/M507/E50145, M527/

M528/E52645)

diagnostic test for 136

Jetdirect print server

See HP Jetdirect print server

lights 136, 137

NVRAM initialization

(M501) 425, 427

JetIntelligence

anti-theft feature 49 authentication 49 toner cartridge 48 job accounting error (firmware) 48.WX.YZ error 136, 269 job management error (firmware) 136, 269 job pipeline error (firmware) 136, 269 Index 1365

job parser error (firmware) 47.WX.YZ error 136, 269 printer calibration error 136, 269 K keyboard 23 locating 2 keyboard (M527c/z, E52545c/z, M528c/z, and E52645c/z), removing and replacing 519 keypad locating 1 kit, embedded Multi-Media Card (eMMC) 464 kits, customer self-repair 1312 L laser scanner error (LaserJet) 51.WX.YZ error 136, 269 52.WX.YZ error 136, 269 laser-beam exposure 43 laser/scanner failure detection 38 operations 38 safety 39 laser/scanner assembly connections diagram 136, 160 laser/scanner assembly, removing and replacing 780 last rotation period 19 latent image formation 39 LEDs (M501) formatter lights 136 LEDs (M506/M507, M527/M528)

See lights

LEDs (M506/M507/E50145, M527/

M528/E52645)

See lights

LEDs, troubleshooting (M501) 136 left cover, removing and replacing 582 lights formatter 136, 137 lights (M501) formatter 136 lights (M506/M507, M527/M528) troubleshooting with 136 lights (M506/M507/E50145, M527/

M528/E52645)

troubleshooting with 136, 137 link speed settings 136 location setting 425, 426 low-voltage power supply (LVPS) converted DC voltages 31 failure detection 33 operations 33 protection for components 32 stops and interruptions 31 low-voltage power supply, removing and replacing 1025 LVPS removing and replacing 1025 LVPS (low-voltage power supply) converted DC voltages 31 failure detection 33 operations 33 protection for components 32 stops and interruptions 31 M M1 removing and replacing 1073 M501 auto on / auto off mode 22 main assemblies (printer base) block diagram 136, 168 Main Motor M1, removing and replacing 1073 memory

NVRAM initialization

(M501) 425, 427

toner cartridge 47

Memory Enhancement technology

(MEt) 25 memory error 82.WX.YZ error 136, 270 EMMC error 136, 270 hard disk error 136, 270 menu Administration menu (M506/

M507/E50145, M527/M528/

E52645) 136

Backup/Restore menu (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 261

Backup/Restore menu (M506/

M507/E50145, M527/M528/

E52645) 136

Calibrate/Cleaning menu

(M506/E50045/M507/

E50145, M527/E52545/M528/

E52645) 261, 262

Calibrate/Cleaning menu

(M506/M507/E50145, M527/

M528/E52645) 136

control panel, access 136, 185 Copy Settings menu (M527/

M528/E52645) 136

Copy/Print (M527/E52545/

M528/E52645) 203

Display Settings menu (M506/

M507/E50145, M527/M528/

E52645) 136

Fax menu (M527/E52545/M528/

E52645) 235

Fax Settings menu (M527/

M528/E52645) 136

General menu 196 General Settings menu (M506/

M507/E50145, M527/M528/

E52645) 136

HP Web Services (M501) 136, 185 Manage Supplies menu 246 Manage Supplies menu (M506/

M507/E50145, M527/M528/

E52645) 136

Manage Trays menu (M506/

M507/E50145, M527/M528/

E52645) 136

Network Settings menu (M506/

M507/E50145, M527/M528/

E52645) 136

Network Setup (M501) 136, 192 Networking 249 Print (M506/E50045/M507/

E50145) 203

Print Options menu (M506/

M507/E50145, M527/M528/

E52645) 136

Print Settings menu (M506/

M507/E50145, M527/M528/

E52645) 136

Quick Forms (M501) 136, 193 Reports (M501) 136, 185 Reports menu 194 Reports menu (M506/M507/

E50145, M527/M528/

E52645) 136

Scan/Digital Send Settings menu (M527/E52545/M528/

E52645) 225

Scan/Digital Send Settings menu (M527/M528/

E52645) 136

Service (M501) 136, 191 Service menu (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645) 261, 263

1366 Index

Service menu (M506/M507/

E50145, M527/M528/

E52645) 136

Settings menu 196 Support Tools menu 261 System Setup (M501) 136, 186 troubleshooting menu 263 troubleshooting menu (M506/

M507/E50145, M527/M528/

E52645) 136

USB Firmware Upgrade menu

(M506/E50045/M507/

E50145, M527/E52545/M528/

E52645) 261, 262

USB Firmware Upgrade menu

(M506/M507/E50145, M527/

M528/E52645) 136

menu map 82 menu map (M501) 78 menus, control panel Calibrate/Cleaning (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 261,

262 Calibrate/Cleaning (M506/

M507/E50145, M527/M528/

E52645) 136

motor and fans block diagram 136, 168, 170 motor control trays 3-5 64 motor error (LaserJet) 59.WX.YZ error 136, 269 motors connections diagram 136, 160 DC controller 27 failure detection 27 image-formation system 53 paper feeder 65 stepping 27 movement of paper through printer

See paper handling

multiple feed prevention trays 3-5 65 N

Near Field Communication error

81.WX.YZ error 136, 270 Bluetooth error 136, 270 external I/O card error 136, 270 internal EIO error 136, 270 wireless error 136, 270 near field communication PCA (M506x/E50045x/M527z/ E52545z), removing and replacing 734 Netscape Navigator, versions supported

HP Embedded Web

Server 136, 182 network configuring (M501) 136, 192 Network Setup menu (M501) 136, 192 networks diagnostics 136

HP embedded Jetdirect

configuration page 136, 175, 177 link speed settings 136 wireless page 136, 175, 178 NFC (M527z/E52545z), removing and replacing 734 no control panel sound 106, 112, 130, 132 note 15, 448 NVRAM initialization (M501) 425, 427 O on/off button locating 1, 2 operation Sleep delay (M501) 22 Sleep mode (M506/M507/

E50145, M527/M528/

E52645) 21

operation sequence 19 operations laser/scanner 38 toner cartridge memory 47 orderable parts 1309 output accessory error 66.WX.YZ error 136, 270 output bin clearing jams 411 locating 1, 2 removing and replacing 657 output bin, removing and replacing 657 over-current protection 32 over-voltage protection 32 OXPd/Web kit error 45.WX.YZ error 136, 269 P page error 21.WX.YZ error 136, 268 pages blank 418 not printing 418 printing slowly 418 pages count 428

See also counts

reset 428 panels, external remove and replace 528 paper default size reset 428 jam detection 66 jams 396 selecting 280, 283 paper (M506/M507, M527/M528) stop in path for testing 136 paper (M506/M507/E50145, M527/

M528/E52645)

stop in path for testing 136, 150 Paper delivery assembly, removing and replacing 1186 paper delivery tray (output bin), removing and replacing 657 Paper feed drive assembly, removing and replacing 1130 paper feeder electrical components 65 paper handling components 50 overview 50 solve problems 390 paper handling error (LaserJet) 56.WX.YZ error 136, 269 paper jams document feeder 396 paper movement operation 50 paper path 550-sheet paper feeder 62 printer 50 paper path (M506/E50045/M507/

E50145, M527/E52545/M528/

E52645)

diagnostic test 143 test, sensors 144 paper path (M506/M507, M527/ M528) diagnostic test 136 stop movement for testing 136 Index 1367 paper path (M506/M507/E50145,

M527/M528/E52645)

diagnostic test 136 stop movement for testing 136, 150 paper-path (M506/M507, M527/ M528) test, sensors 136 paper-path (M506/M507/E50145,

M527/M528/E52645)

test, sensors 136 parts 1309, 1313 parts and diagrams, using 1313 parts internal base printer, remove and replace 527 parts list and diagrams, how to use 1313 parts, 1x550-sheet paper feeder 1330 parts, covers MFP 1319 parts, covers SFP 1316 parts, document feeder and scanner whole units 1314 parts, internal assemblies (1 of 4) 1321 parts, internal assemblies (2 of 4) 1323 parts, internal assemblies (3 of 4) 1325 parts, internal assemblies (4 of 4) 1327 parts, order by authorized service providers 1309 parts, orderable 1309 parts, ordering 1309 password Service menu PIN 428 periods of the operation sequence 19 personal identification number (PIN) service menu 428 P.J.L (printer job language) 22 P.M.L (printer management language) 23 post service tests print quality test 455 power consumption 5, 14 power connection locating 3 power subsystem 106, 109 power supply 30 connections diagram 136, 160

See also high-voltage power

supply

See also low-voltage power

supply troubleshooting 106, 109 power switch locating 1, 2 power-on troubleshooting overview 106, 109 power-save mode

See sleep settings

powersave (M501) 425 pre-boot menu options 84 pre-troubleshooting checklist 106 primary charging process 43 print bar error (PageWide) 62.WX.YZ error 136, 269 print quality test pages 136, 174 print stop test timing stops 151 Print Test Page 136, 196 print-quality troubleshooting 136, 293, 296, 300 AC banding 293, 296, 300, 304, 309 cartridge fine pitch banding 293, 296, 300, 321, 332, 334 dark streaks (early in toner cartridge life) 293, 296, 300, 304 density change 293, 296, 300, 321, 328, 329 developer defect 293, 296, 300, 321, 323 fine-pitch banding 293, 296, 300, 304, 305 fuser blisters 293, 296, 300, 321, 345 fuser contamination 293, 296, 300, 358 graininess/fixing mottle 293, 296, 300 hot fuser offset 293, 296, 300, 321, 345, 346 image placement - margins and skew 293, 296, 300, 358, 360 impulse band (leading edge) 293, 296, 300, 304, 314, 321, 337 impulse band (trailing edge) 293, 296, 300, 304, 316, 318 IPG repeating defect 293, 296, 300, 321, 332, 335 leading edge - mid-page toner scatter 293, 296, 300, 321, 328 OPC gear slip 293, 296, 300, 321, 325 OPC sharp bands (version 1) 293, 296, 300, 304, 311 OPC sharp bands (version 2) 293, 296, 300, 304, 312 OPC wide-pitch banding 293, 296, 300, 321, 325, 327 output curl 293, 296, 300, 358, 363 output stacking 293, 296, 300, 358, 367 paper handling - jams 293, 296, 300, 358, 370 paper handling - misprints 293, 296, 300, 358, 369 paper handling - multifeeds 293, 296, 300, 358, 369 poor edge fixing - outside the image assurance area 293, 296, 300, 321, 345, 350 poor edge fixing - within the image assurance area 293, 296, 300, 321, 345, 348 rain-toner attached to the

OPC 293, 296, 300, 321

random missing toner 293, 296, 300, 321, 324 right to left fade and banding 293, 296, 300, 321, 332 sticky output 293, 296, 300, 358, 366 toner in the leading edge margin (fuser slap) 293, 296, 300, 321, 337, 340 transfer issue - random voids 293, 296, 300, 321, 328, 331 uneven Density - across the page 293, 296, 300, 321, 354 vertical streaks - high temperature/humidity 293, 296, 300, 302 1368 Index water drop (condensation) 293, 296, 300, 321, 354, 356 wide-pitch banding 293, 296, 300, 304, 307, 321, 337, 342 printed circuit assemblies (PCAs; printer base) block diagram 136, 168, 171 printed circuit assembly (PCA) connector locations block diagram 136, 160 printer cold reset 428 printer cold reset (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645) 432, 434

printer dimensions

M506/M507, M527/M528,

accessories 5, 6 printer job language (P.J.L) 22 printer management language

(P.M.L) 23

printer memory error 20.WX.YZ error 136, 268 printer resets 428 printer resets (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645) 432

printer space requirements 5, 13 printing period in operation sequence 19 stop for testing 136, 150 troubleshooting 418 problem-solving networks 136 Process Cleaning Page 136, 261, 262 product number locating 3 location 3 Q Quick Forms menu (M501) 136, 193 R real-time

clock error 11.WX.YZ error 136, 268 rear door clearing jams 409 locating 3 rear door assembly, removing and replacing 567 removal and replacement 448 considerations 451 removal and replacement procedures 456 removal and replacement strategy 451 introduction 451 remove and replace accessories 1252 external panels, covers, and doors 528 trays (printer base) 1247 remove and replace, formatter cover 528 remove and replace, FRUs base printer 724 remove and replace, HDD 469 remove and replace, internal parts and assemblies base printer 527 removing and replacing 550-sheet paper feeder 1252 cartridge door assembly 561 control panel (M501, 507n/dn, and E50145n/dn) 530 control panel (M506x/E50045x/ M507x/E50145x) 504 control panel (M527/E52545/

M528/E52645) 492

control-panel cover (M527/

E52545/M528/E52645) 534

DC controller 967

DCC 967

document feeder (M527/

E52545/M528/E52645) 547

document feeder maintenance kit (M527/E52545/M528/

E52645 1258

dual in-line memory module

(DIMM) (M506/E50045/

M507/E50145/M527/E52545/

M528/E52645) 476

embedded Multi-Media Card (eMMC) 464 fan (FM1) 862 fan (FM2) 874 fax printed-circuit board (M527c/f/z, E52545c/f/c, M528c/f/z, and E52645c/f/z) 1267 formatter 771 formatter case 818 fuser 757 fuser power supply (FPS) 920 hard-disk drive, HDD 469 high-voltage power supply 1012

HVPS 1012

integrated scanner assembly

(M527/E52545/M528/

E52645) 694

keyboard (527c/z, E52545c/z, M528c/z, and E52645c/z) 519 laser/scanner assembly 780 left cover 582 low-voltage power supply 1025

LVPS 1025

M1 1073

Main Motor M1 1073 near field communication PCA (M527z/E52545z) 734 NFC (M527z/E52545z) 734 output bin 657 Paper delivery assembly 1186 paper delivery tray (output bin) 657

Paper feed drive

assembly 1130 rear door assembly 567 right cover assembly 570 scanner control board (M527/

E52545/M528/E52645) 724

SCB (M527/E52545/M528/

E52645) 724

SSA (M527/E52545/M528/

E52645) 694

staple cartridge (M527/

M528) 460

stapler door or stapler blank cover (M527/E52545/M528/

E52645) 592

stapler stationary (inner) cover

(M527/E52545/M528/

E52645) 596

stapler unit (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) 763 toner cartridge 456 top cover (M501/M506/E50045/

M507/E50145) 633

top cover (M527/E52545/M528/

E52645) 603

top-left cover (M527/E52545/

M528/E52645) 537

top-rear cover (M527/E52545/

M528/E52645) 540

transfer roller 485 Tray 2 1247 Index 1369

Tray 3 1249 trusted platform module (TPM)

(M507/E50145/M528/

E52645) 1297

white backing (M527/E52545/

M528/E52645) 513

WiFi PCA (M506x/ E50045x) 738 WiFi PCA (M507x/E50145x) 751 wireless PCA (M506x/ E50045x) 738 wireless PCA (M507x/ E50145x) 751 wireless PCA (M527z/E52545z/ M528z/E52645z) 754 repetitive image defect ruler 293, 296 reports configuration page 136, 185 default info page 136, 185 demo page 136, 185 error 425, 426 menu map 136, 185 network summary 136, 185 PCL 6 font list 136, 185 PCL font list 136, 185 print quality page 136, 185 PS font list 136, 185 service 425, 426 service page 136, 185 supplies status page 136, 185 usage page 136, 185 required tools 453 resets

NVRAM initialization

(M501) 425, 427

restore factory settings 428 restore factory settings (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 432

restore the service ID 428 restore the service ID (M506/

E50045/M507/E50145, M527/

E52545/M528/E52645) 432,

433 restoring defaults (M501) 425 factory defaults 425 restoring default settings

NVRAM initialization

(M501) 425, 427

revision history iii right cover assembly, removing and replacing 570 rollers document feeder maintenance kit (M527/E52545/M528/ E52645), removing and replacing 1258 transfer roller, removing and replacing 485 rollers and pads (printer base) block diagram 136, 168, 169 S safety laser/scanner 39 scanner (M527/E52545/M528/

E52645)

tests 153 scanner (M527/M528) tests 136 scanner (M527/M528/E52645) glass cleaning 372 tests 136 scanner control board (M527/

E52545/M528/E52645),

removing and replacing 724 scanner error 30.WX.YZ error 136, 269 scanner settings 428 scanner tests 154 scanning image capture (M527/E52545/ M528/E52645 only) 68

SCB (M527/E52545/M528/E52645)

removing and replacing 724

SCB (M527/E52545/M528/E52645),

removing and replacing 724 secondary service menu

(M501) 425, 426

security error 33.WX.YZ error 136, 269 security settings information 136, 175, 177, 178 sensor error 54.WX.YZ error 136, 269 58.WX.YZ error 136, 269 sensors block diagram 136, 155 connections diagram 136, 160 DC controller 29 image-formation system 39 paper feeder 65 paper handling 52 scanner tests 154 sensors (M506/E50045/M507/

E50145, M527/E52545/M528/

E52645)

diagnostic tests 144 tests, manual sensor 146 tests, manual tray/bin 148 sensors (M506/M507, M527/M528) diagnostic tests 136 tests, diagnostic sensor and paper path 136 tests, manual sensor 136 tests, manual tray/bin 136 sensors (M506/M507/E50145,

M527/M528/E52645)

diagnostic tests 136 tests, diagnostic sensor and paper path 136, 143 tests, manual sensor 136 tests, manual tray/bin 136 separation process 45 serial number 428 locating 3 service and support

WISE 15, 75, 448, 1307

service approach 455 after performing service 455 before performing service 455

Service ID

convert to date 428 restore 428 service menu 425 personal identification number

(PIN) 428

secondary (M501) 425, 426 solve problems 428 Service menu (M501) 136, 191 Service menu options 428 service menu settings cleaning mode (M501) 425 powersave (M501) 425 restoring defaults (M501) 425 service menu settings

(M501) 425

service mode functions service menu 428 solve problems 428 service mode functions

(M501) 425

service page (M501) 78 settings restore factory 428 restore factory (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645) 432

1370 Index

sleep delay (M501) operation 22 sleep mode (M506/M507/E50145,

M527/M528/E52645)

operation 21 sleep settings voltage too high during 32 sleep settings (M501) 22 sleep settings (M506/M507/

E50145, M527/M528/

E52645) 21

solenoids DC controller 28 image-formation system 53 solve connectivity problems 422 solve performance problems 418 factors affecting print performance 418 print speeds 419 printer does not print 420 printer prints slowly 420 solve problems 75 output is curled or wrinkled 391 paper does not feed automatically 392, 394 paper does not feed from Tray

2-X 391

paper handling 390 printer does not pick up paper 392 printer does not pick up paper or misfeeds 392 printer feeds incorrect page size 390 printer picks up multiple sheets of paper 392 printer pulls from incorrect tray 390 printer will not duplex or duplexes incorrectly 390 service

menu 428 service mode functions 428 solving direct-connect problems 422 space requirements, printer 5, 13 specifications electrical and acoustic 5, 14 space requirements 5, 13 SSA removing and replacing 694

SSA (M527/E52545/M528/E52645),

removing and replacing 694 standby period 19 staple cartridge (M527/M528) removing and replacing 460 staple cartridge (M527/M528), removing and replacing 460 stapler door or stapler blank cover

(M527/E52545/M528/E52645),

removing and replacing 592 stapler stationary (inner) cover

(M527/E52545/M528/E52645),

removing and replacing 596 stapler unit (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z) removing and replacing 763 stapler unit (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z), removing and replacing 763 stepping motors 27 stop printing for test (M506/M507,

M527/M528) 136

stop printing for test (M506/M507/

E50145, M527/M528/

E52645) 136, 150

sub-voltage low-voltage power supply circuit 31 supplies 1309 supplies error (LaserJet) 10.WX.YZ error 136, 268 supplies error (PageWide) 17.WX.YZ error 136, 268 switches block diagram 136, 155 connections diagram 136, 160 DC controller 29 paper feeder 65 paper handling 52 system error (LaserJet) 62.WX.YZ error 136, 269 system requirements

HP Embedded Web

Server 136, 182 System Setup menu (M501) 136, 186 T TCP/IP information 136, 175, 177, 178 temperature fuser heater protection 37 test pages fuser 136, 181 test pages (M506/M507/E50145,

M527/M528/E52645)

fuser 136 tests component tests list and descriptions 136, 152 engine 136, 140 networks 136 scanner (M527/E52545/M528/

E52645) 153

scanner (M527/M528) 136 scanner (M527/M528/

E52645) 136

tests (M506/E50045/M507/

E50145, M527/E52545/M528/

E52645)

disable cartridge check 142 manual sensor tests 146 paper path 143 paper path sensors 144 tray/bin manual sensor 148 tests (M506/M507, M527/M528) disable cartridge check 136 manual sensor tests 136 paper path 136 paper path and sensor diagnostic 136 paper-path sensors 136 tray/bin manual sensor 136 tests (M506/M507/E50145, M527/

M528/E52645)

disable cartridge check 136 manual sensor tests 136 paper path 136 paper path and sensor diagnostic 136, 143 paper-path sensors 136 tray/bin manual sensor 136 tests (M527/E52545/M528/

E52645)

scanner tests 153 tests (M527/M528) scanner tests 136 tests (M527/M528/E52645) scanner tests 136 theory of operations 15 thermistors fuser 35 thermostats fuser 35 timing chart 136, 172 timing stops print stop test 151 tip 15, 448 Index 1371

toner image formation, use during 39 toner cartridge anti-theft feature 49 authentication 49 dynamic security 48 JetIntelligence 48 life detection 47 memory chip 47 presence detection 47 toner level detection 47 toner cartridge (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645)

diagnostic test 142 toner cartridge (M506/M507,

M527/M528)

diagnostic test 136 toner cartridge (M506/M507/

E50145, M527/M528/E52645)

diagnostic test 136 toner cartridge area clearing jams 407 toner cartridge, removing and replacing 456 toner cartridges 46 components 46 error conditions 46 operations 46 toner cartridges, part numbers 1309 top cover (M501/M506/E50045/ M507/E50145), removing and replacing 633 top cover (M527/E52545/M528/ E52645), removing and replacing 603 top-left cover (M527/E52545/ M528/E52645), removing and replacing 537 top-rear cover (M527/E52545/ M528/E52645), removing and replacing 540 touchscreen blank, white, or dim (no image) 106, 112, 130 touchscreen control panel 23 touchscreen has an unresponsive zone 106, 112, 130, 131

TPM (M507/E50145/M528/E52645)

removing and replacing 1297 transfer processes 44 transfer roller, removing and replacing 485 tray lift operation 65 Tray 1 clearing jams 400 tray 1 rollers and separation pad cleaning 372, 376 Tray 2 clearing jams 403 tray 2-X rollers cleaning 372, 383 Tray 2, removing and replacing 1247 Tray 3, removing and replacing 1249 tray motor error (LaserJet) 60.WX.YZ error 136, 269 tray selection - use requested tray 136 trays locating 1, 2 trays (printer base) remove and replace 1247 trays 3-5 cassette lift operation 65 jam detection 66 motor control 64 multiple feed prevention 65 tray presence detection 65 troubleshooting 75 blank pages 418 check toner cartridge status 280 check toner-cartridge status 282 checklist 79, 106 clean the paper path 372 configuration pages for 136, 175 control panel checks 112 direct-connect problems 422 flowchart 106, 107 jams 395, 396 network problems 422

NVRAM initialization

(M501) 425, 427

pages not printing 418 pages printing slowly 418 power 106, 109 process 106 service menu 428 service mode functions 428 USB cables 418 wired network 422 troubleshooting (M501) checklist 77 control panel checks 106 LED diagnostics 136 troubleshooting (M506/M507,

M527/M528)

lights, using 136 troubleshooting (M506/M507/

E50145, M527/M528/E52645)

lights, using 136, 137 troubleshooting (M506/M527) control panel checks 106 trusted platform module (TPM)

(M507/E50145/M528/E52645)

removing and replacing 1297 U understand lights on the formatter formatter lights 137 understand lights on the formatter

(M506/M507, M527/M528)

formatter lights 136 understand lights on the formatter (M506/M507/E50145,

M527/M528/E52645)

formatter lights 136 understand the lights on the formatter heartbeat LED 137, 138 HP Jetdirect LEDs 137 understand the lights on the formatter (M506/M507, M527/ M528) heartbeat LED 136 HP Jetdirect LEDs 136 understand the lights on the formatter (M506/M507/E50145,

M527/M528/E52645)

heartbeat LED 136 HP Jetdirect LEDs 136 upgrade firmware (M506/E50045/

M507/E50145, M527/E52545/

M528/E52645) 441, 443

upgrades, downloading product firmware (M506/E50045/M507/

E50145, M527/E52545/M528/

E52645) 441

upgrades, downloading product firmware M501) 439

USB flash drive

firmware upgrade, control panel

(M506/E50045/M507/

E50145, M527/E52545/M528/

E52645) 441, 443, 445

firmware upgrade, pre-boot menu (M506/E50045/M507/ 1372 Index

E50145, M527/E52545/M528/

E52645) 441, 443, 444

USB port troubleshooting 418 Use Requested Tray 136 W waiting period 19 warning 15, 448 warranty date information 428

Web browser requirements

HP Embedded Web

Server 136, 182

Web-based Interactive Search

Engine (WISE)

HP internal users and Channel

partners 15, 75, 448, 1307 weight, printer M5015, 6 weight, printer M506/E50045/

M507/E501458

weight, printer M506/M5075, 6 weight, printer M527/E52545/

M528/E52645 10

weight, printer M527/M5285, 6 white backing (M527/E52545/ M528/E52645), removing and replacing 513 WiFi PCA (M506x/E50045x) removing and replacing 738 WiFi PCA (M507x/E50145x) removing and replacing 751 WiFi PCA (M527z/E52545z/M528z/ E52645z) removing and replacing 754 wireless configuration page 136, 175, 178 wireless page 178 wireless page (M506/M507, M527/

M528) 175

wireless page (M506/M507/

E50145, M527/M528/

E52645) 136

wireless PCA (M506x/E50045x), removing and replacing 738 wireless PCA (M507x/E50145x), removing and replacing 751 wireless PCA (WiFi) (M527z/ E52545z/M528z/E52645z), removing and replacing 754 WISE email problems 447 fax problems 447

HP internal users and Channel

partners 15, 75, 448, 1307 Index 1373