

Service Parts Catalog - Parte 2

HP LaserJet Series

TechGuide IA — Consulta Inteligente de Manuais HP

b. Insert the HDD cradle mounting tab in the slot in the sheet-metal (callout 1), and then rotate the connector end (callout 2) of the HDD toward the formatter. Figure 5-24 Install the HDD 2 1 c. Make sure that the locking connector (callout 1) latches and that the standoff (callout 2) engages with the slot in the formatter (it might be necessary to pinch the retainer to engage it with the slot). Figure 5-25 Install the HDD 1 2 5. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). 474 Chapter 5 Removal and replacement

Figure 5-26 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. Figure 5-27 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

6. Reverse the removal steps to install the assembly. Also use the following special installation instructions.

Reinstall the printer firmware

a. Go to www.hp.com/go/futuresmart. b. Select Upgrade now. c. Find your Enterprise printer model. d. Select the link to open the firmware download page. Removal and replacement: Hard-disk drive (HDD) 475
e. Select OS Independent from the list of operating systems. f. Under the Firmware section, find the file for multiple operating systems. g. Select Download. Reinstallation tip: To view installation instructions, go to <http://www.hp.com/go/futuresmart>. Select Upgrade now, and then select How to perform a firmware update. Removal and replacement: Dual in-line memory module (DIMM) Learn how to remove and replace the dual in-line memory module (DIMM). To view a short video of this procedure, click the link below. View a video of how to remove and replace the DIMM. Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. CAUTION: This part contains components that are electrostatic discharge (ESD) sensitive. To reduce the possibility of ESD damage, always touch the sheet-metal chassis to ground yourself before touching an ESD sensitive part. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-5 Part information

Part number Part description

E5K48-67902 HP 1GB DDR3 x32 144-pin 800MHz SODIMM (M527/E52545/M528/E52645) 5851-6581 HP 2GB DDR3 x32 144-pin 800MHz SODIMM (M527/E52545/M528/E52645) G6W84-67902 HP 1GB 90-pin DDR3 x32 Slim DIMM (M506/E50045/M507/E50145) 2NR03-67901 1GB 90-Pin DDR3 Slim DIMM TAA-Compliant (M506/E50045/M507/E50145) 2NR09-67901 2GB 144-Pin DDR3 DIMM TAA-Compliant (M527/E52545/M528/E52645)

Required tools

No special tools are required to remove or install this assembly. 476 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-28 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Removal and replacement: Dual in-line memory module (DIMM) 477

Figure 5-29 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the hard-disk drive (HDD models). CAUTION: ESD sensitive part. a. Release the locking connector (callout 1), and then pinch the retainer (callout 2) to release it. Figure 5-30 Release the HDD 1 2 478 Chapter 5 Removal and replacement
b. Rotate the connector end of the HDD out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-31 Remove the HDD 1 2 3. Remove the dual in-line memory module (DIMM). CAUTION: ESD sensitive part. NOTE: The M506/E50045/M507/E50145 printers use a Slim dual in-line memory module (DIMM). a. M506/E50045/M507/E50145 only: Locate the DIMM

component on the formatter, and then pull it straight off of the formatter to remove it. Figure 5-32 Remove the DIMM (M506/E50045/M507/E50145) Removal and replacement: Dual in-line memory module (DIMM) 479

b. M527/E52545/M528/E52645 only: Do the following. i. Locate the DIMM component on the formatter, release two locking arms (callout 1), and then let the bottom edge of the DIMM rotate away from the holder (callout 2). Figure 5-33 Release the DIMM (M527/E52545/M528/E52645) 1 2 ii. Pull the DIMM down and away from the holder to remove it. Figure 5-34 Remove the DIMM (M527/E52545/M528/E52645) 4. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 480 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 5. Install the dual in-line memory module (DIMM). CAUTION: ESD sensitive part. NOTE: The M506/E50045/M507/E50145 printers use a Slim dual in-line memory module (DIMM). a. M506/E50045/M507/E50145 only: Push the DIMM straight on the connector to install it. Figure 5-35 Install the DIMM (M506/E50045/M507/E50145) Removal and replacement: Dual in-line memory module (DIMM) 481

b. M527/E52545/M528/E52645 only: Do the following. i. Insert the top edge of the DIMM in the holder. Reinstallation tip: The DIMM is keyed and can only be inserted in the holder one way. Figure 5-36 Insert the DIMM (M527/E52545/M528/E52645) ii. Rotate the bottom edge of the DIMM toward the holder (callout 1), and then make sure that the two locking arms snap into place (callout 2). Figure 5-37 Install the DIMM (M527/E52545/M528/E52645) 2 1 6. Install the HDD (HDD models). CAUTION: ESD sensitive part. 482 Chapter 5 Removal and replacement

a. Before proceeding, take note of the location of the slot (callout 1) in the sheet-metal where the HDD cradle mounting tab (callout 2) must be installed. CAUTION: This portion of the sheet-metal is a knock-out plate (callout 1). Do not push on it with sufficient force to detach it when installing the HDD. Figure 5-38 Locate the slot in the sheet-metal 1 2 b. Insert the HDD cradle mounting tab in the slot in the sheet-metal (callout 1), and then rotate the connector end (callout 2) of the HDD toward the formatter. Figure 5-39 Install the HDD 2 1 Removal and replacement: Dual in-line memory module (DIMM) 483

c. Make sure that the locking connector (callout 1) latches and that the standoff (callout 2) engages with the slot in the formatter (it might be necessary to pinch the retainer to engage it with the slot). Figure 5-40 Install the HDD 1 2 7. Install the formatter cover. ■ Do one of the following: ● M501: Slide it toward the front of the printer to install it (callout 1), and then install one screw (callout 2). Figure 5-41 Install the formatter cover (M501) 1 2 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide it toward the front of the printer to install it. 484 Chapter 5 Removal and replacement

Figure 5-42 Install the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

Removal and replacement: Transfer roller Learn how to remove and replace the transfer roller. To view a short video of this procedure, click the link below. View a video of how to remove and replace the transfer roller. Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-6 Part information

Part number Part description

F2A68-67910 Transfer roller with instruction guide

Required tools

No special tools are required to remove or install this assembly. Removal and replacement: Transfer roller 485

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the toner cartridge. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Press the cartridge-door-release button. Figure 5-43 Press the cartridge-door-release button b. Open the toner-cartridge door. Figure 5-44 Open the toner-cartridge door 486 Chapter 5 Removal and replacement

c. Remove the toner cartridge from the printer. Figure 5-45 Remove the toner cartridge 2. Remove the transfer roller. a. Push in on the two white tabs on the right-side retainer clip to release them. NOTE: The right end of the roller slightly springs up when the tabs are released. Figure 5-46 Release the retainer clip b. Grasp the silver shaft end of the roller or the white retainer clip, raise the right-end of the roller up, and then slide the roller to the right to release the left-end of the roller shaft. CAUTION: The retainer clip is not captive. Do not drop it into the product when handling the roller. Removal and replacement: Transfer roller 487

Figure 5-47 Release the roller 1 2 c. Remove the transfer roller from the printer. Figure 5-48 Remove the roller 488 Chapter 5 Removal and replacement

d. Remove the clip from the right end of the transfer roller. Set the clip aside, it will be installed on the replacement roller. Figure 5-49 Remove the retainer clip 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Transfer roller 489

4. Install the transfer roller. CAUTION: Do not touch the spongy portion of the replacement roller. Skin oils on the roller can cause paper handling problems. HP recommends washing your hands before handling the assembly. a. From the discarded transfer roller, install the clip on either end of the replacement transfer roller. CAUTION: Avoid touching the black spongy part of the roller. Skin oils deposited on the rollers might cause print quality problems. HP recommends washing your hands before handling the roller. Figure 5-50 Install the holder 490 Chapter 5 Removal and replacement

b. Place the left (shaft) end of the roller in the retainer clip (callout 1), lower the right end (with the clip) into place making sure that the clip and spring are aligned (callout 2), and then push down (callout 3) on the clip until it snaps in place. Figure 5-51 Install the roller and retainer clip 1 2 3 5. Install the toner cartridge. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Align the toner cartridge with the tracks inside the printer, and install the toner cartridge until it is firmly seated. Figure 5-52 Install the toner cartridge Removal and replacement: Transfer roller 491

b. Close the toner-cartridge door. Figure 5-53 Close the toner-cartridge door Removal and replacement: Control panel (MFP) Learn how to remove and replace the control panel. To view a short video of this procedure, click the link below. View a video of how to remove and replace the control panel. Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-7 Part information

Part number	Part description
B5L47-67018	Control panel (M527/E52545/M528/E52645) with instruction guide

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length 492 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the control panel. a. Open the document feeder. NOTE: If the control panel is not fully tilted forward, tilt it forward now until it stops.

Figure 5-54 Open the document feeder 2 1 b. Beginning at the right side of the control-panel cover, carefully release five tabs along the top edge of the cover. NOTE: The thin black-plastic cover will separate from the white-plastic control-panel base. Removal and replacement: Control panel (MFP) 493

Figure 5-55 Release five tabs c. Continue to rotate the top edge of the cover away from the printer, and then remove the cover. Figure 5-56 Remove the cover 494 Chapter 5 Removal and replacement

d. M527/E52545/M528c/z, and E52645c/z only: Open the connector latch to release the keyboard flat cable. Figure 5-57 Disconnect the FFC (M527/E52545/M528c/z, and E52645c/z) e. Disconnect one HDMI cable (callout 1) and one connector (callout 2). Figure 5-58 Disconnect connectors 1 2 f. Remove the USB cable (callout 1) from the holder. NOTE: M527z/E52545z only: Release four tabs (callout 2), and then remove the near-field communication (NFC) printed circuit board. Removal and replacement: Control panel (MFP) 495

Figure 5-59 Remove USB cable and NFC PCA 1 2 g. Remove three screws (callout 1). TIP: The screwdriver (supplied with the kit) has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. 496 Chapter 5 Removal and replacement

Figure 5-60 Remove three screws 1 h. Lift the front of the control panel off of the printer (callout 1), and then slide it toward the front of the printer (callout 2) to remove it. Figure 5-61 Remove the control panel 2 1 2. Unpack the replacement assembly. Removal and replacement: Control panel (MFP) 497

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 3. Install the control panel. a. Tilt the replacement control panel away from the base plate. Figure 5-62 Open the control panel 498 Chapter 5 Removal and replacement

b. M527/E52545/M528c/z, and E52645c/z only: Make sure to feed the keyboard flat cable (callout 1) passes through the opening (callout 2) in the control-panel base when installing the control panel. Figure 5-63 Check the keyboard flat cable (M527/E52545/M528c/z, and E52645c/z) 1 2 c. Locate the four hooks on the printer and matching slots in the control-panel base (callout 1). The hooks fit into the slots (callout 2) when the assembly is installed. NOTE: Make sure that the grounding clip (callout 3) is on top of the assembly base when it is installed. Figure 5-64 Locate the hooks and slots 3 2 1 Removal and replacement: Control panel (MFP) 499

d. Position the rear edge of the control panel in the printer (callout 1), and then lower the front edge down (callout 2) to install it. NOTE: If the control panel is difficult to install, make sure that the hooks, slots, and grounding clip are correctly engaged. See previous steps. Figure 5-65 Install the control-panel 2 1 e. Install three screws (callout 1), make sure that the grounding clip is correctly installed (callout 2). TIP: The screwdriver (supplied with the kit) has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. 500 Chapter 5 Removal and replacement

Figure 5-66 Install three screws 1 2 f. Connect one HDMI cable (callout 1) and one connector (callout 2). Figure 5-67 Connect the connectors 1 2 Removal and replacement: Control panel (MFP) 501

g. Install the USB cable (callout 1) in the holder. NOTE: M527z/E52545z only: Install the near-field communication (NFC) printed circuit board under the four tabs (callout 2). Figure 5-68 Install the USB cable and NFC PCA 1 2 h. M527/E52545/M528c/z, and E52645c/z only: Position the keyboard flat cable in the connector, and then close the connector latch. IMPORTANT: Slightly tug on the cable to make sure that it is fully captured in the connector. NOTE: When the connector latch is closed, and the cable is correctly installed, the white line on the cable is parallel to the connector latch. 502 Chapter 5 Removal and replacement

Figure 5-69 Connect the flat cable (M527/E52545/M528c/z, and E52645c/z) i. Position the control-panel cover on the printer. Figure 5-70 Position the control-panel cover on the printer Removal and replacement: Control panel (MFP) 503

j. Beginning at the left side of the control-panel cover, carefully engage five tabs along the top edge of the cover. Figure 5-71 Engage five tabs

k. Close the document feeder. NOTE: Adjust the control panel to the desired angle. Reinstallation tip: If the keyboard is unresponsive after turning the printer on, check the flat cable installed in a previous step. Reinstall the cable if necessary. Figure 5-72 Close the document feeder Removal and replacement: Control panel (M506x/E50045x/M507x/E50145x) Learn how to remove and replace the control panel. To view a short video of this procedure, click the link below. View a video of how to remove and replace the control panel. 504 Chapter 5 Removal and replacement

Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-8 Part information

Part number Part description

G1W41-67907 Control panel (M506x//M506xm/E50045dw/E50045x) with instruction guide K0Q15-67901 Control panel (M507x/E50145x) with instruction guide

Required tools

NOTE: A reversible-shaft screwdriver is supplied with this kit. ● Small flat-blade screwdriver ● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the control panel (M506x/E50045x/M507x/E50145x). Removal and replacement: Control panel (M506x/E50045x/M507x/E50145x) 505

a. Tilt the control panel to the fully raised position. Figure 5-73 Tilt the control panel up b. Use the small flat-blade screwdriver supplied in the kit to release the control-panel screws cover, and then remove the cover. TIP: The screwdriver has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. Figure 5-74 Remove the cover 506 Chapter 5 Removal and replacement

c. Use the small Phillips screwdriver supplied in the kit to remove two screws (callout 1). IMPORTANT: Store the screws in a secure place where they cannot fall down into the printer. Figure 5-75 Remove two screws 1 d. Turn the control panel over (callout 1), to gain access to the bottom side. Figure 5-76 Turn the control panel over 1 Removal and replacement: Control panel (M506x/E50045x/M507x/E50145x) 507

e. M506/E50045 only: Disconnect one HDMI cable (callout 1), one connector (callout 2), and then remove the control panel. Figure 5-77 Remove the control panel (M506/E50045) 1 2 f. M507/E50154 only: If the formatter cover has not been removed, remove it now. Disconnect one flat-flexible cable (FFC). CAUTION: ESD sensitive part. NOTE: This connector is a zero-insertion force (ZIF) connector. Open the locking clip. The clip is easily dislodged and lost. Figure 5-78 Disconnect one FFC (M507/E50145) 508 Chapter 5 Removal and replacement

g. M507/E50145 only: Pass the FFC through the opening in the cover, and then remove the control panel. CAUTION: ESD sensitive part. Figure 5-79 Remove the control panel (M507/E50145) 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Control panel (M506x/E50045x/M507x/E50145x) 509

3. Install the control panel (M506x/E50045x/M507x/E50145x). a. M506/E50045 only: Connect one HDMI cable (callout 1) and one connector (callout 2). Figure 5-80 Connect the cables (M506/E50045) 1 2 b. M507/E50145 only: Pass the FFC through the opening in the cover. CAUTION: ESD sensitive part. Figure 5-81 Install the FFC (M507/E50145) c. M507/E50145 only: Connect one FFC. CAUTION: ESD sensitive part. NOTE: Reinstall the formatter cover. 510 Chapter 5 Removal and replacement

Figure 5-82 Connect one FFC (M507/E50145) d. Install the tabs (callout 1) on the front of the control panel in the slots (callout 2) on the printer top cover. Figure 5-83 Install the control panel 2 1 Removal and replacement: Control panel (M506x/E50045x/M507x/E50145x) 511

e. Rotate the control-panel base down onto the printer. Figure 5-84 Rotate the control-panel base down f. Use the small Phillips screwdriver supplied in the kit to install two screws (callout 1). Figure 5-85 Install two screws 1 g. Position the screw cover mounting feet into the slots in the top cover (callout 1), and then rotate the cover down (callout 2) to install it. NOTE: Press down on the cover firmly to make sure that the tabs (callout 3) snap into place. 512 Chapter 5 Removal and replacement

Figure 5-86 Install the cover 3 2 1 Removal and replacement: White backing (MFP) Learn how to remove and replace the white backing. To view a short video of this procedure, click the link below. View a video of how to remove and replace the white backing. Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-9 Part information

Part number Part description

5851-6570 White backing kit (with instruction guide)1 1 This kit includes the white backing retention clips.

Required tools

No special tools are required to remove or install this assembly. Removal and replacement: White backing (MFP) 513

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the white backing (M527/E52545/M528/E52645). a. Open the document feeder. Figure 5-87 Open the document feeder b. Remove the white backing and retention clips (attached to the document feeder behind the white backing). TIP: Use the edge of a coin to loosen the clips. 514 Chapter 5 Removal and replacement

Figure 5-88 Remove the white backing 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 3. Install the white backing (M527/E52545/M528/E52645). a. Verify that the springs are positioned correctly on the replacement retention clips. NOTE: Replacement retention clips are supplied in the kit. Removal and replacement: White backing (MFP) 515

Figure 5-89 Check the retention clip spring b. Install the replacement clips (callout 1) in the openings (callout 2) in the document feeder. NOTE: Make sure that the springs are correctly installed. See the previous step. Figure 5-90 Install the retention clip 1 2 c. Press the clip to make sure it is securely installed. NOTE: An audible click indicates when the clip is correctly installed. 516 Chapter 5 Removal and replacement

Figure 5-91 Press the retention clip d. Remove the protective film off of each adhesive square. Figure 5-92 White backing adhesive squares e. Position the replacement white backing on the image scanner glass. NOTE: Make sure that the corner with the embossed arrow on the white backing is positioned against the corner with the arrow on the scanner. Removal and replacement: White backing (MFP) 517

Figure 5-93 Install the white backing f. Close the document feeder. Figure 5-94 Close the document feeder g. Open the document feeder and press on the white backing at the location of each retention clip to ensure that the backing is securely attached to the adhesive on the clips. 518 Chapter 5 Removal and replacement

Figure 5-95 Check the white backing h. Close the document feeder. Figure 5-96 Close the document feeder Removal and replacement: Keyboard assembly (M527c/z, E52545c/z, M528c/z, and E52645c/z) This document provides the procedures to remove and replace the keyboard assembly. To view a short video of this procedure, click the link below. View a video of how to remove and replace the keyboard assembly. Mean time to repair: 5 minutes Service level: CSR A

Before performing service

Turn the printer power off

Removal and replacement: Keyboard assembly (M527c/z, E52545c/z, M528c/z, and E52645c/z) 519

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-10 Part information

Part number Part description

B5L47-67019 Keyboard assembly (US) kit (527c/z, E52545c/z, M528c/z, and E52645c/z) with instruction guide B5L47-67020 Keyboard assembly (UK) kit (527c/z, E52545c/z, M528c/z, and E52645c/z) with instruction guide

Required tools

No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use the physical keyboard (in the same way the virtual touchscreen keyboard is used) to make sure that it is correctly functioning. 1. Remove the keyboard. 520 Chapter 5 Removal and replacement

a. Tilt up the control panel (callout 1) and open the document feeder (callout 2). Figure 5-97 Tilt up the control panel and open the document feeder 2 1 b. Beginning at the right side of the control-panel cover, carefully release five tabs along the top edge of the cover. NOTE: The thin black-plastic cover will separate from the white plastic control-panel base. Figure 5-98 Remove the control-panel cover Removal and replacement: Keyboard assembly (M527c/z, E52545c/z, M528c/z, and E52645c/z) 521

c. Continue to rotate the top edge of the cover away from the printer, and then remove the cover. Figure 5-99 Remove the cover d. Open the connector latch to release the keyboard flat cable. Figure 5-100 Release the keyboard flat cable 522 Chapter 5 Removal and replacement

e. Slide the keyboard tray out until it stops. Figure 5-101 Slide the tray out f. Push up on the keyboard tray to release two tabs on the bottom of the tray, and then slide the tray toward you to disengage the tabs. Figure 5-102 Disengage the tabs Removal and replacement: Keyboard assembly (M527c/z, E52545c/z, M528c/z, and E52645c/z) 523

g. Slide the keyboard tray all the way out of the printer to remove it. Figure 5-103 Remove the keyboard 2. Unpack the replacement assembly.

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly.

Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 3. Install the keyboard. 524 Chapter 5 Removal and replacement

a. Position the flat cable (callout 1) on the keyboard into the keyboard slot (callout 2). Figure 5-104 Install the FFC 2 1 b. Slide the keyboard tray into the slot. Figure 5-105 Install the keyboard Removal and replacement: Keyboard assembly (M527c/z, E52545c/z, M528c/z, and E52645c/z) 525

c. If the flat cable (callout 1) is not in the opening (callout 2) in the control panel base, carefully reach in and thread the flat cable through the opening. Figure 5-106 Check the flat cable 2 1 d. Position the keyboard flat cable in the connector, and then close the connector latch. IMPORTANT: Slightly tug on the cable to make sure that it is fully captured in the connector. NOTE: When the connector latch is closed and the cable is correctly installed, the white line on the cable is parallel to the connector latch. Figure 5-107 Close the flat cable latch 526 Chapter 5 Removal and replacement

e. Position the control-panel cover on the printer. Figure 5-108 Install the control-panel cover f. Beginning at the left side of the control-panel cover, carefully push down along the top edge of the cover to engage five tabs. NOTE: If the keyboard is unresponsive after turning the printer on, check the flat cable installed earlier. Reinstall the cable if necessary. Figure 5-109 Engage five tabs Removal and replacement: Internal parts and assemblies (base printer) Learn how to remove and replace the base printer internal parts and assemblies. Removal and replacement: Internal parts and assemblies (base printer) 527

Removal and replacement: External panels, covers, and doors (base printer) Learn how to remove and replace the printer external panels, covers, and doors. Removal and replacement: Formatter cover Learn how to remove and replace the formatter cover. To view a short video of this procedure, click the link below. M501 View a video of how to remove and replace the formatter cover (M501).

M506/E50045/M507/E50145

View a video of how to remove and replace the formatter cover (M506/E50045/M507/E50145).

M527/E52545/M528/E52645

View a video of how to remove and replace the formatter cover (M527/E52545/M528/E52645). Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-11 Part information

Part number Part description

RC4-4200-000CN Formatter cover (M501) RM2-5725-000CN Formatter cover (M506/E50045/M507/E50145) RM2-5717-000CN Formatter cover (M527/E52545/M528/E52645)

Required tools

No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on. 528 Chapter 5 Removal and replacement

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-110 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-111 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Unpack the replacement assembly. Removal and replacement: Formatter cover 529

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly.

Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Control panel (M501, 507n/dn, and E50145n/dn) Learn how to remove and replace the control panel. To view a short video of this procedure, click the link below. View a video of how to remove and replace the control panel. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-12 Part information

Part number Part description

J8H60-67904 Control panel (M501) 530 Chapter 5 Removal and replacement

Table 5-12 Part information (continued)

Part number Part description

RM2-2610-000CN Control panel (507n/dn) K0Q15-60106 Control panel E50145

Required tools

● Small flat-blade screwdriver

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Access the menus by using the printer control panel, and then print a configuration page to make sure that the printer is functioning correctly. 1. Remove the control panel. a. Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-112 Remove the formatter cover 1 2 Removal and replacement: Control panel (M501, 507n/dn, and E50145n/dn) 531

b. Disconnect one flat cable (callout 1). Figure 5-113 Disconnect one flat cable 1 c. Locate two tabs (callout 1) along the rear edge of the control panel. Figure 5-114 Locate two tabs 1 d. Release the two tabs, and then rotate the rear edge of the control panel up and away from the printer. TIP: Use a small flat-blade screw driver to release the two tabs. 532 Chapter 5 Removal and replacement

Figure 5-115 Release the control panel e. Pass the flat cable attached to the control panel through the opening in the printer chassis, and then remove the control panel. Figure 5-116 Remove the control panel 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Control panel (M501, 507n/dn, and E50145n/dn) 533

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Control-panel cover (MFP) Learn how to remove and replace the control-panel cable cover (M527/E52545/M528/E52645). To view a short video of this procedure, click the link below. View a video of how to remove and replace the control panel cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-13 Part information

Part number Part description

B5L46-60117 Control-panel cover (M527/E52545) B5L47-67018 Control-panel cover (M528/E52645)

Required tools

● No special tools are required to remove or install this assembly. 534 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the control-panel cover. a. If the document feeder is not open, open it now. NOTE: If the control panel is not fully tilted forward, tilt it forward now until it stops. Figure 5-117 Open the document feeder 2 1 Removal and replacement: Control-panel cover (MFP) 535

b. Beginning at the right side of the control-panel cover, carefully release five tabs along the top edge of the cover. Figure 5-118 Release five tabs c. Continue to rotate the top edge of the cover away from the printer, and then remove the cover. Figure 5-119 Remove the cover 2. Unpack the replacement assembly. 536 Chapter 5 Removal and replacement

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Top-left cover (MFP) Learn how to remove and replace the top-left cover. To view a short video of this procedure, click the link below. View a video of

how to remove and replace the top-left cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-14 Part information

Part number Part description

RC4-4147-000CN Cover, top left Removal and replacement: Top-left cover (MFP) 537

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the top-left cover (M527/E52545M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-120 Release two tabs 1 538 Chapter 5 Removal and replacement

b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-121 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-122 Slide the cover Removal and replacement: Top-left cover (MFP) 539

d. Remove the cover. Figure 5-123 Remove the cover 2. Unpack the replacement assembly. a. Dispose of the defective part. **NOTE:** HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. **CAUTION:** Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. **IMPORTANT:** Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. **NOTE:** When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Top-rear cover (MFP) Learn how to remove and replace the top-rear cover. 540 Chapter 5 Removal and replacement

To view a short video of this procedure, click the link below. View a video of how to remove and replace the top-rear cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-15 Part information

Part number Part description

RC4-3002-000CN Cover, top rear

Required tools

- No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Removal and replacement: Top-rear cover (MFP) 541

Figure 5-124 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-125 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the top-left cover (M527/E52545/M528/E52645). 542 Chapter 5 Removal and replacement

a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-126 Release two tabs 1 b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-127 Release two tabs Removal and replacement: Top-rear cover (MFP) 543

c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-128 Slide the cover d. Remove the cover. Figure 5-129 Remove the cover 3. Remove the top-rear cover (M527/E52545/M528/E52645). 544 Chapter 5 Removal and replacement

a. Remove one screw (callout 1), and then open the rear door. Figure 5-130 Remove one screw 1 b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-131 Rotate the cover Removal and replacement: Top-rear cover (MFP) 545

c. Continue to rotate the cover away from the printer to release one boss. Figure 5-132 Release one boss d. Remove the cover. Figure 5-133 Remove the cover 4. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 546 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Document feeder (MFP) Learn how to remove and replace the document feeder. To view a short video of this procedure, click the link below. View a video of how to remove and replace the document feeder. Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-16 Part information

Part number Part description

B5L47-67906 ADF whole unit Enterprise (document feeder; kit with instruction guide; includes white backing kit) B5L47-67907 ADF whole unit Workflow (document feeder; kit with instruction guide (includes white backing kit) Removal and replacement: Document feeder (MFP) 547

Required tools

● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length ● Small flat-blade screwdriver

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use the document feeder to make a copy to make sure that it is properly functioning. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-134 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 548 Chapter 5 Removal and replacement

Figure 5-135 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the top-left cover (M527/E52545/M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-136 Release two tabs 1 Removal and replacement: Document feeder (MFP) 549
- b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-137 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-138 Slide the cover 550 Chapter 5 Removal and replacement
- d. Remove the cover. Figure 5-139 Remove the cover 3. Remove the top-rear cover (M527/E52545/M528/E52645). a. Remove one screw (callout 1), and then open the rear door. Figure 5-140 Remove one screw 1 Removal and replacement: Document feeder (MFP) 551
- b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-141 Rotate the cover c. Continue to rotate the cover away from the printer to release one boss. Figure 5-142 Release one boss 552 Chapter 5 Removal and replacement
- d. Remove the cover. Figure 5-143 Remove the cover 4. Remove the document feeder. a. Remove one screw (callout 1), and then remove the cable cover (callout 2). Figure 5-144 Remove the cover 1 2 Removal and replacement: Document feeder (MFP) 553
- b. Disconnect one flat-flexible cable (FFC; callout 1), remove one ground screw (callout 2), and then disconnect five connectors (callout 3). Figure 5-145 Disconnect the FFC, ground cable, and connectors 1 2 3 c. Open the document feeder. Figure 5-146 Open the document feeder 554 Chapter 5 Removal and replacement
- d. Tilt the document feeder back until it stops (callout 1), and then lift it up until it stops (callout 2). Figure 5-147 Raise the document feeder 1 2
- e. Support the document feeder, and then use a small flat-blade screwdriver to release two tabs on the document feeder hinges. NOTE: The tabs are located on the front side (scanner flatbed glass) of the hinges. Use the figure below to locate the tabs. Figure 5-148 Release two tabs
- f. Lift the document feeder up to remove it. NOTE: While removing the document feeder, carefully pass the wire harnesses and the FFC through the opening in the scanner. Removal and replacement: Document feeder (MFP) 555
- Figure 5-149 Remove the document feeder 5. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 6. Reverse the removal steps to install the assembly. Also use the following special installation instructions.

Install a replacement white backing

- a. Verify that the springs are positioned correctly on the replacement retention clips. 556 Chapter 5 Removal and replacement
- Figure 5-150 Check the retention clip spring b. Install the clip (callout 1) in the opening (callout 2) in the document feeder. NOTE: Make sure that the springs are correctly installed. See the previous step. Figure 5-151 Install the retention clip 1 2 c. Press the clip to make sure it is securely installed. Removal and replacement: Document feeder (MFP) 557
- Figure 5-152 Press the retention clip d. Remove the protective film off of each adhesive square. Figure 5-153 White backing adhesive squares
- e. Position the replacement white backing on the image scanner glass. NOTE: Make sure that the corner with the embossed arrow on the white backing is positioned against the corner with the arrow on the scanner. 558 Chapter 5 Removal and replacement
- Figure 5-154 Install the white backing f. Close the document feeder. Figure 5-155 Close the document feeder g. Open the document feeder and press on the white backing at the location of each retention clip to ensure that the backing is securely attached to the adhesive on the clips. Removal and replacement: Document feeder (MFP) 559
- Figure 5-156 Check the white backing h. Close the document feeder. Figure 5-157 Close the document feeder Reset the firmware counter. a. From the HOME screen on the control panel, scroll to and touch the Device Maintenance button. b. Scroll to and touch the Service button. c. On the sign-in screen, select the Service Access Code option from the drop-down list. d. Enter the following service access code for this printer: ● 10052715 e. Scroll to and touch the Cycle Counts item. f. Reset the following items: 560 Chapter 5 Removal and replacement
- Document Feeder Kit Intervals; set to zero ● ADF Count; set to zero Removal and replacement: Cartridge door assembly Learn how to remove and replace the cartridge door assembly. To view a short video of this procedure, click the link below. View a video of how to remove and replace the cartridge door. Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-17 Part information

Part number Part description

F2A76-67912 Cartridge door assembly kit (M527/E52545; all) with instruction guide (includes nameplate) RM2-5691-000CN Cartridge door assembly (M528/E52645) F2A68-67919 Cartridge door assembly kit (M506n/dn/E50045n/dn) with instruction guide (includes nameplate) F2A68-67920 Cartridge door assembly kit (M506x/M50045x) with instruction guide RM2-5677-000CN Cartridge door assembly (M501 and M507/E50145) J8H60-40001 Nameplate, LaserJet Pro M501 RC4-3010-000CN Hinge, cartridge door left RC4-4479-000CN Link, pressure release

Required tools

- Small flat-blade screwdriver

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on. Removal and replacement: Cartridge door assembly 561

Post service test

Make sure that the toner-cartridge door correctly opens and closes. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-158 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-159 Release and remove the tray 562 Chapter 5 Removal and replacement

2. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Figure 5-160 Release the support shaft 1 2 Removal and replacement: Cartridge door assembly 563

b. Remove the support shaft. Figure 5-161 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Figure 5-162 Remove the guide 2 1 564 Chapter 5 Removal and replacement

d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-163 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Figure 5-164 Release the door 3 1 2 Removal and replacement: Cartridge door assembly 565

f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-165 Release the left-side retainer arm g. Remove the door. Figure 5-166 Remove the door 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 566 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Rear door assembly Learn how to remove and replace the rear door assembly. To view a short video of this procedure, click the link below. View a video of how to remove and replace the rear door assembly. Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-18 Part information

Part number Part description

RM2-5726-000CN Rear door assembly (M501/M506/E50045/M507/E50145/M527/E52545/M528/ E52645 duplex models) RM2-5712-000CN Rear door assembly (M501/M506/E50045/M507/E50145 simplex models) Removal and replacement: Rear door assembly 567

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the rear door assembly. a. At the rear of the printer, remove two screws (callout 1). Figure 5-167 Remove two screws 1 568 Chapter 5 Removal and replacement

b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-168 Rotate the bottom of the cover c. Pull down on the assembly to remove it. Figure 5-169 Remove the cover 2. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Rear door assembly 569

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Right cover

Learn how to remove and replace the right cover

To view a short video of this procedure, click the link below. View a video of how to remove and replace the right cover. Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-19 Part information

Part number Part description

RC4-4437-000CN Right cover

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length 570 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-170 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Removal and replacement: Right cover 571

Figure 5-171 Release and remove the tray 2. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-172 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 572 Chapter 5 Removal and replacement

Figure 5-173 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

3. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Figure 5-174 Release the support shaft 1 2 Removal and replacement: Right cover 573

b. Remove the support shaft. Figure 5-175 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Figure 5-176 Remove the guide 2 1 574 Chapter 5 Removal and replacement

d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-177 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Figure 5-178 Release the door 3 1 2 Removal and replacement: Right cover 575

f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-179 Release the left-side retainer arm g. Remove the door. Figure 5-180 Remove the door 4. Remove the rear door assembly. 576 Chapter 5 Removal and replacement

a. At the rear of the printer, remove two screws (callout 1). Figure 5-181 Remove two screws 1 b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-182 Rotate the bottom of the cover Removal and replacement: Right cover 577

c. Pull down on the assembly to remove it. Figure 5-183 Remove the cover 5. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-184 Locate the tabs and bosses 578 Chapter 5 Removal and replacement

b. Remove two screws (callout 1). Figure 5-185 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-186 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Removal and replacement: Right cover 579

Figure 5-187 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-188 Release one tab 580 Chapter 5 Removal and replacement

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-189 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-190 Remove the cover 2 1 3 Removal and replacement: Right cover 581

6. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Left cover

Learn how to remove and replace the left cover

To view a short video of this procedure, click the link below. View a video of how to remove and replace the left cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. 582 Chapter 5 Removal and replacement

Table 5-20 Part information

Part number Part description

RM2-5727-000CN Left cover

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-191 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Removal and replacement: Left cover 583

Figure 5-192 Release and remove the tray 2. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Figure 5-193 Release the support shaft 1 2 584 Chapter 5 Removal and replacement

b. Remove the support shaft. Figure 5-194 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Figure 5-195 Remove the guide 2 1 Removal and replacement: Left cover 585

d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-196 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Figure 5-197 Release the door 3 1 2 586 Chapter 5 Removal and replacement

f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-198 Release the left-side retainer arm g. Remove the door. Figure 5-199 Remove the door 3. Remove the rear door assembly. Removal and replacement: Left cover 587

a. At the rear of the printer, remove two screws (callout 1). Figure 5-200 Remove two screws 1 b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-201 Rotate the bottom of the cover 588 Chapter 5 Removal and replacement

c. Pull down on the assembly to remove it. Figure 5-202 Remove the cover 4. Remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-203 Locate of the tabs and bosses Removal and replacement: Left cover 589

b. Remove one screw (callout 1). Figure 5-204 Remove one screw 1 c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-205 Release one boss and three tabs 2 1 590 Chapter 5 Removal and replacement

d. At the bottom edge of the cover, release two tabs. Figure 5-206 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. Figure 5-207 Remove the cover 1 2 5. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Left cover 591

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Stapler door or stapler blank cover (M527/E52545/M528/E52645) Learn how to remove and replace the stapler door or stapler blank cover. To view a short video of this procedure, click the link below. View a video of how to

remove and replace the stapler door or stapler blank cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-21 Part information

Part number Part description

F2A76-40004 Stapler door (stapler models) F2A76-40005 Stapler blank cover (non-stapler models)

Required tools

- Small flat-blade screwdriver 592 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Staple two pages together. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-208 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Removal and replacement: Stapler door or stapler blank cover (M527/E52545/M528/E52645) 593

Figure 5-209 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-210 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. 594 Chapter 5 Removal and replacement

Figure 5-211 Release the upper hinge or remove the cover c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge.

Figure 5-212 Release the lower hinge Removal and replacement: Stapler door or stapler blank cover (M527/E52545/M528/E52645) 595

d. Stapler models: Remove the door. Figure 5-213 Remove the door 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly.

Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Stapler stationary (inner) cover (M527/E52545/M528/E52645) Learn how to remove and replace the cassette stapler stationary (inner) cover. 596 Chapter 5 Removal and replacement

To view a short video of this procedure, click the link below. View a video of how to remove and replace the stapler stationary (inner) cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-22 Part information

Part number Part description

F2A76-40003 Stapler stationary (inner) cover (stapler models only)

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Removal and replacement: Stapler stationary (inner) cover (M527/E52545/M528/E52645) 597

Figure 5-214 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-215 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). 598 Chapter 5 Removal and replacement

Figure 5-216 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Figure 5-217 Release the upper hinge or remove the cover Removal and replacement: Stapler stationary (inner) cover (M527/E52545/M528/E52645) 599

c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-218 Release the lower hinge d. Stapler models: Remove the door. Figure 5-219 Remove the door 3. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. 600 Chapter 5 Removal and replacement

Figure 5-220 Locate the tabs 1 2 b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-221 Release one tab Removal and replacement: Stapler stationary (inner) cover (M527/E52545/M528/E52645) 601

c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-222 Release one tab d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-223 Remove the cover 1 2 4. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 602 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Top cover (MFP) Learn how to remove and replace the top cover. To view a short video of this procedure, click the link below. View a video of how to remove and replace the top cover. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

- Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-23 Part information

Part number Part description

RM2-5718-000CN Top cover (M527/E52545/M528/E52645)

Required tools

● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length ● Small flat-blade screwdriver Removal and replacement: Top cover (MFP) 603

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-224 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. 604 Chapter 5 Removal and replacement

Figure 5-225 Release and remove the tray 2. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-226 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Removal and replacement: Top cover (MFP) 605

Figure 5-227 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

3. Remove the fax PCA (M527/E52545/M528/E52645 fax models). CAUTION: ESD-sensitive part. a. Disconnect three connectors (callout 1). Figure 5-228 Disconnect three connectors 1 606 Chapter 5 Removal and replacement

b. Pinch the retainer to release it. Figure 5-229 Release the fax PCA c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-230 Remove the fax PCA 1 2 4. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). Removal and replacement: Top cover (MFP) 607

a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-231 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Figure 5-232 Release the upper hinge or remove the cover 608 Chapter 5 Removal and replacement

c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-233 Release the lower hinge d. Stapler models: Remove the door. Figure 5-234 Remove the door 5. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. Removal and replacement: Top cover (MFP) 609

Figure 5-235 Locate the tabs 1 2 b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-236 Release one tab 610 Chapter 5 Removal and replacement

c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-237 Release one tab d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-238 Remove the cover 1 2 6. Remove the top-left cover (M527/E52545/M528/E52645). Removal and replacement: Top cover (MFP) 611

a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-239 Release two tabs 1 b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-240 Release two tabs 612 Chapter 5 Removal and replacement

c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-241 Slide the cover d. Remove the cover. Figure 5-242 Remove the cover 7. Remove the top-rear cover (M527/E52545/M528/E52645). Removal and replacement: Top cover (MFP) 613

a. Remove one screw (callout 1), and then open the rear door. Figure 5-243 Remove one screw 1 b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-244 Rotate the cover 614 Chapter 5 Removal and replacement

c. Continue to rotate the cover away from the printer to release one boss. Figure 5-245 Release one boss d. Remove the cover. Figure 5-246 Remove the cover 8. Remove the rear door assembly. Removal and replacement: Top cover (MFP) 615

a. At the rear of the printer, remove two screws (callout 1). Figure 5-247 Remove two screws 1 b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-248 Rotate the bottom of the cover 616 Chapter 5 Removal and replacement

c. Pull down on the assembly to remove it. Figure 5-249 Remove the cover 9. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Removal and replacement: Top cover (MFP) 617

Figure 5-250 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-251 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. 618 Chapter 5 Removal and replacement

Figure 5-252 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-253 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Removal and replacement: Top cover (MFP) 619

Figure 5-254 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-255 Release the left-side retainer arm 620 Chapter 5 Removal and replacement

g. Remove the door. Figure 5-256 Remove the door 10. Remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-257 Locate of the tabs and bosses Removal and replacement: Top cover (MFP) 621

b. Remove one screw (callout 1). Figure 5-258 Remove one screw 1 c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-259 Release one boss and three tabs 2 1 622 Chapter 5 Removal and replacement

d. At the bottom edge of the cover, release two tabs. Figure 5-260 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. Figure 5-261 Remove the cover 1 2 11. Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645). NOTE: The ISA includes the document feeder, sub-scanner assembly (SSA), and the scanner control board (SCB). Removal and replacement: Top cover (MFP) 623

a. Remove one screw (callout 1). IMPORTANT: This screw fastens the ISA ground plate to the printer chassis. Do not lose this screw. Figure 5-262 Remove one screw 1 b. Disconnect three connectors (callout 1), pass the wire harnesses and cables through the opening in the cover (callout 2), and then release them from the retainers (callout 3). NOTE: One cable (callout 4) does not need to pass through the opening in the cover. TIP: It might be easier if the WiFi PCA and holder (not all models; callout 5) is detached from the printer, and then moved out of the way. Figure 5-263 Disconnect cables and connectors 4 1 2 3 5 624 Chapter 5 Removal and replacement

c. Disconnect three connectors (callout 1), and then remove six screws (callout 2). Figure 5-264 Disconnect connectors and remove screws 1 2 d. Slightly slide the ISA towards the back of the printer to release it. Figure 5-265 Slide the ISA towards the back of the printer Removal and replacement: Top cover (MFP) 625

e. Remove the ISA. Figure 5-266 Remove the ISA 12. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-267 Locate the tabs and bosses 626 Chapter 5 Removal and replacement

b. Remove two screws (callout 1). Figure 5-268 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-269 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Removal and replacement: Top cover (MFP) 627

Figure 5-270 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-271 Release one tab 628 Chapter 5 Removal and replacement

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-272 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-273 Remove the cover 2 1 3 Removal and replacement: Top cover (MFP) 629

13. Remove the top cover (M527/E52545/M528/E52645). a. At the front right of the printer, remove one screw (callout 1), and then remove the sheet-metal plate (callout 2). Figure 5-274 Remove one screw and the plate 1 2 b. At the top rear of the printer, remove three screws (callout 1). Figure 5-275 Remove three screws 1 c. At the top front of the printer, remove three screws (callout 1). NOTE: The screw (callout 2) on the lower-right portion of the cover is a different color than the other two screws, and is surrounded by sheet-metal. It might appear that this screw does not need to be removed. Remove this screw. 630 Chapter 5 Removal and replacement

Figure 5-276 Remove three screws 1 2 d. At the front left of the printer, release one boss. Figure 5-277 Release one boss e. Rotate the front of the cover up and away from the printer. CAUTION: As the cover is rotated up, carefully pass the cables and wire harnesses the hole in the cover (callout 1). Removal and replacement: Top cover (MFP) 631

Figure 5-278 Rotate the front of the cover up 1 f. Remove the cover. Figure 5-279 Remove the cover 14. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 632 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Top cover (SFP) Learn how to remove and replace the top cover (M501/M506/E50045/M507/E50145). To view a short video of this procedure, click the link below. M501 View a video of how to remove and replace the top cover (M501).

M506/E50045

View a video of how to remove and replace the top cover (M506/E50045).

M507/E50145

View a video of how to remove and replace the top cover (M507/E50145). Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Removal and replacement: Top cover (SFP) 633

Table 5-24 Part information

Part number Part description

RM2-5735-000CN Top cover (M501) RM2-5687-000CN Top cover (M506/E50045/M507/E50145; simplex) RM2-5728-000CN Top cover (M506/E50045/M507/E50145; duplex LCD) RM2-5686-000CN Top cover (M506/E50045/M507/E50145; duplex MF)

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-280 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. 634 Chapter 5 Removal and replacement

Figure 5-281 Release and remove the tray 2. Remove the control panel (M506x/E50045x/M507x/E50145x). a. Tilt the control panel to the fully raised position. Figure 5-282 Tilt the control panel up b. Use the small flat-blade screwdriver supplied in the kit to release the control-panel screws cover, and then remove the cover. TIP: The screwdriver has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. Removal and replacement: Top cover (SFP) 635

Figure 5-283 Remove the cover c. Use the small Phillips screwdriver supplied in the kit to remove two screws (callout 1). IMPORTANT: Store the screws in a secure place where they cannot fall down into the printer. Figure 5-284 Remove two screws 1 636 Chapter 5 Removal and replacement

d. Turn the control panel over (callout 1), to gain access to the bottom side. Figure 5-285 Turn the control panel over 1 e. M506/E50045 only: Disconnect one HDMI cable (callout 1), one connector (callout 2), and then remove the control panel. Figure 5-286 Remove the control panel (M506/E50045) 1 2 f. M507/E50145 only: If the formatter cover has not been removed, remove it now. Disconnect one flat-flexible cable (FFC). CAUTION: ESD sensitive part. NOTE: This connector is a zero-insertion force (ZIF) connector. Open the locking clip. The clip is easily dislodged and lost. Removal and replacement: Top cover (SFP) 637

Figure 5-287 Disconnect one FFC (M507/E50145) g. M507/E50145 only: Pass the FFC through the opening in the cover, and then remove the control panel. CAUTION: ESD sensitive part. Figure 5-288 Remove the control panel (M507/E50145) 3. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). 638 Chapter 5 Removal and replacement

Figure 5-289 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-290 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

4. Remove the control panel (M501). Removal and replacement: Top cover (SFP) 639

a. Disconnect one flat cable (callout 1). Figure 5-291 Disconnect one flat cable 1 b. Locate two tabs (callout 1) along the rear edge of the control panel. Figure 5-292 Locate two tabs 1 c. Release the two tabs, and then rotate the rear edge of the control panel up and away from the printer. TIP: Use a small flat-blade screw driver to release the two tabs. 640 Chapter 5 Removal and replacement

Figure 5-293 Release the control panel d. Pass the flat cable attached to the control panel thorough the opening in the printer chassis, and then remove the control panel. Figure 5-294 Remove the control panel 5. Remove the rear door assembly. Removal and replacement: Top cover (SFP) 641

a. At the rear of the printer, remove two screws (callout 1). Figure 5-295 Remove two screws 1 b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-296 Rotate the bottom of the cover 642 Chapter 5 Removal and replacement

c. Pull down on the assembly to remove it. Figure 5-297 Remove the cover 6. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Removal and replacement: Top cover (SFP) 643

Figure 5-298 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-299 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. 644 Chapter 5 Removal and replacement

Figure 5-300 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-301 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Removal and replacement: Top cover (SFP) 645

Figure 5-302 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-303 Release the left-side retainer arm 646 Chapter 5 Removal and replacement

g. Remove the door. Figure 5-304 Remove the door 7. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-305 Locate the tabs and bosses Removal and replacement: Top cover (SFP) 647

b. Remove two screws (callout 1). Figure 5-306 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-307 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. 648 Chapter 5 Removal and replacement

Figure 5-308 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-309 Release one tab Removal and replacement: Top cover (SFP) 649

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-310 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-311 Remove the cover 2 1 3 650 Chapter 5 Removal and replacement

8. Remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-312 Locate of the tabs and bosses b. Remove one screw (callout 1). Figure 5-313 Remove one screw 1 Removal and replacement: Top cover (SFP) 651

c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-314 Release one boss and three tabs 2 1 d. At the bottom edge of the cover, release two tabs. Figure 5-315 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer

(callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. 652 Chapter 5 Removal and replacement

Figure 5-316 Remove the cover 1 2 9. Remove the top cover (M501/M506/E50045/M507/E50145). The M506x/E50045x is shown in this procedure. However, the steps are correct for all M506/ E50045/M507/E50145 models and the M501 printer. a. Remove two screws (callout 1). Figure 5-317 Remove two screws 1 b. M506/E50045/ only: Release one cable retainer from the chassis. TIP: Depress the tab on the retainer to release it. Removal and replacement: Top cover (SFP) 653

Figure 5-318 Release one cable retainer c. M507/E50145 only: Disconnect two connectors. Figure 5-319 Disconnect two connectors 654 Chapter 5 Removal and replacement

d. Release one boss. Figure 5-320 Release one boss e. M506/E50045/ only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M506x/E50045x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-321 Remove the cover (M506/E50045) 1 Removal and replacement: Top cover (SFP) 655

f. M507/E50145only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M507x/E50145x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). IMPORTANT: If the top cover is being replaced, make sure to transfer the WiFi PCA from the discarded cover to the replacement cover. NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-322 Remove the cover (M507/E50145) 1 10. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. 656 Chapter 5 Removal and replacement

c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Paper delivery tray (output bin) Learn how to remove and replace the paper delivery tray (output bin). To view a short video of this procedure, click the link below. View a video of how to remove and replace the paper delivery tray (output bin). Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-25 Part information

Part number Part description

RC4-4439-000CN Paper delivery tray (output bin)

Required tools

● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length ● Small flat-blade screwdriver

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the control panel (M506x/E50045x/M507x/E50145x). Removal and replacement: Paper delivery tray (output bin) 657

a. Tilt the control panel to the fully raised position. Figure 5-323 Tilt the control panel up b. Use the small flat-blade screwdriver supplied in the kit to release the control-panel screws cover, and then remove the cover. TIP: The screwdriver has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. Figure 5-324 Remove the cover 658 Chapter 5 Removal and replacement

c. Use the small Phillips screwdriver supplied in the kit to remove two screws (callout 1). IMPORTANT: Store the screws in a secure place where they cannot fall down into the printer. Figure 5-325 Remove two screws 1 d. Turn the control panel over (callout 1), to gain access to the bottom side. Figure 5-326 Turn the control panel over 1 Removal and replacement: Paper delivery tray (output bin) 659

e. M506/E50045 only: Disconnect one HDMI cable (callout 1), one connector (callout 2), and then remove the control panel. Figure 5-327 Remove the control panel (M506/E50045) 1 2 f. M507/E50154 only: If the formatter cover has not been removed, remove it now. Disconnect one flat-flexible cable (FFC). CAUTION: ESD sensitive part. NOTE: This connector is a zero-insertion force (ZIF) connector. Open the locking clip. The clip is easily dislodged and lost. Figure 5-328 Disconnect one FFC (M507/E50145) 660 Chapter 5 Removal and replacement

g. M507/E50145 only: Pass the FFC through the opening in the cover, and then remove the control panel. CAUTION: ESD sensitive part. Figure 5-329 Remove the control panel (M507/E50145) 2. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-330 Pull the tray out until it stops Removal and replacement: Paper delivery tray (output bin) 661

b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-331 Release and remove the tray 3. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-332 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 662 Chapter 5 Removal and replacement

Figure 5-333 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

4. Remove the fax PCA (M527/E52545/M528/E52645 fax models). CAUTION: ESD-sensitive part. a. Disconnect three connectors (callout 1). Figure 5-334 Disconnect three connectors 1 Removal and replacement: Paper delivery tray (output bin) 663

b. Pinch the retainer to release it. Figure 5-335 Release the fax PCA c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-336 Remove the fax PCA 1 2 5. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). 664 Chapter 5 Removal and replacement

a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-337 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Figure 5-338 Release the upper hinge or remove the cover Removal and replacement: Paper delivery tray (output bin) 665

c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-339 Release the lower hinge d. Stapler models: Remove the door. Figure 5-340 Remove the door 6. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. 666 Chapter 5 Removal and replacement

Figure 5-341 Locate the tabs 1 2 b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-342 Release one tab Removal and replacement: Paper delivery tray (output bin) 667

c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-343 Release one tab d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-344 Remove the cover 1 2 7. Remove the top-left cover (M527/E52545/M528/E52645). 668 Chapter 5 Removal and replacement

a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-345 Release two tabs 1 b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-346 Release two tabs Removal and replacement: Paper delivery tray (output bin) 669

c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-347 Slide the cover d. Remove the cover. Figure 5-348 Remove the cover 8. Remove the top-rear cover (M527/E52545/M528/E52645). 670 Chapter 5 Removal and replacement

a. Remove one screw (callout 1), and then open the rear door. Figure 5-349 Remove one screw 1 b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-350 Rotate the cover Removal and replacement: Paper delivery tray (output bin) 671

c. Continue to rotate the cover away from the printer to release one boss. Figure 5-351 Release one boss d. Remove the cover. Figure 5-352 Remove the cover 9. Remove the rear door assembly. 672 Chapter 5 Removal and replacement

a. At the rear of the printer, remove two screws (callout 1). Figure 5-353 Remove two screws 1 b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-354 Rotate the bottom of the cover Removal and replacement: Paper delivery tray (output bin) 673

c. Pull down on the assembly to remove it. Figure 5-355 Remove the cover 10. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. 674 Chapter 5 Removal and replacement

Figure 5-356 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-357 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Removal and replacement: Paper delivery tray (output bin) 675

Figure 5-358 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-359 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt

to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. 676 Chapter 5 Removal and replacement

Figure 5-360 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-361 Release the left-side retainer arm Removal and replacement: Paper delivery tray (output bin) 677

g. Remove the door. Figure 5-362 Remove the door 11. Remove the right cover. **IMPORTANT:** The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-363 Locate the tabs and bosses 678 Chapter 5 Removal and replacement

b. Remove two screws (callout 1). Figure 5-364 Remove two screws 1 c. At the rear of the printer, release one boss. **CAUTION:** It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-365 Release one boss d. At the bottom edge of the cover, release two bosses. **CAUTION:** It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Removal and replacement: Paper delivery tray (output bin) 679

Figure 5-366 Release two bosses e. Near the formatter, release one tab. **CAUTION:** It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. **TIP:** Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-367 Release one tab 680 Chapter 5 Removal and replacement

f. At the top rear edge of the cover, release one tab. **CAUTION:** It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. **TIP:** Use a small flat-blade screw driver to easily release this tab. Figure 5-368 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. **CAUTION:** It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-369 Remove the cover 2 1 3 Removal and replacement: Paper delivery tray (output bin) 681

12. Remove the left cover. **IMPORTANT:** The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. **NOTE:** An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-370 Locate of the tabs and bosses b. Remove one screw (callout 1). Figure 5-371 Remove one screw 1 682 Chapter 5 Removal and replacement

c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-372 Release one boss and three tabs 2 1 d. At the bottom edge of the cover, release two tabs. Figure 5-373 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. **NOTE:** If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. Removal and replacement: Paper delivery tray (output bin) 683

Figure 5-374 Remove the cover 1 2 13. Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645). **NOTE:** The ISA includes the document feeder, sub-scanner assembly (SSA), and the scanner control board (SCB). a. Remove one screw (callout 1). **IMPORTANT:** This screw fastens the ISA ground plate to the printer chassis. Do not lose this screw. Figure 5-375 Remove one screw 1 684 Chapter 5 Removal and replacement

b. Disconnect three connectors (callout 1), pass the wire harnesses and cables through the opening in the cover (callout 2), and then release them from the retainers (callout 3). **NOTE:** One cable (callout 4) does not need to pass through the opening in the cover. **TIP:** It might be easier if the WiFi PCA and holder (not all models; callout 5) is detached from the printer, and then moved out of the way. Figure 5-376 Disconnect cables and connectors 4 1 2 3 5 c. Disconnect three connectors (callout 1), and then remove six screws (callout 2). Figure 5-377 Disconnect connectors and remove screws 1 2 Removal and replacement: Paper delivery tray (output bin) 685

d. Slightly slide the ISA towards the back of the printer to release it. Figure 5-378 Slide the ISA towards the back of the printer e. Remove the ISA. Figure 5-379 Remove the ISA 14. Remove the top cover (M527/E52545/M528/E52645). 686 Chapter 5 Removal and replacement

a. At the front right of the printer, remove one screw (callout 1), and then remove the sheet-metal plate (callout 2). Figure 5-380 Remove one screw and the plate 1 2 b. At the top rear of the printer, remove three screws (callout 1). Figure 5-381 Remove three screws 1 c. At the top front of the printer, remove three screws (callout 1). **NOTE:** The screw (callout 2) on the lower-right portion of the cover is a different color than the other two screws, and is surrounded by sheet-metal. It might appear that this screw does not need to be removed. Remove this screw. Removal and replacement: Paper delivery tray (output bin) 687

Figure 5-382 Remove three screws 1 2 d. At the front left of the printer, release one boss. Figure 5-383 Release one boss e. Rotate the front of the cover up and away from the printer. **CAUTION:** As the cover is rotated up, carefully pass the cables and wire harnesses the hole in the cover (callout 1). 688 Chapter 5 Removal and replacement

Figure 5-384 Rotate the front of the cover up 1 f. Remove the cover. Figure 5-385 Remove the cover 15. Remove the top cover (M501/M506/E50045/M507/E50145). The M506x/E50045x is shown in this procedure. However, the steps are correct for all M506/E50045/M507/E50145 models and the M501 printer. Removal and replacement: Paper delivery tray (output bin) 689

a. Remove two screws (callout 1). Figure 5-386 Remove two screws 1 b. M506/E50045/ only: Release one cable retainer from the chassis. **TIP:** Depress the tab on the retainer to release it. Figure 5-387 Release one cable retainer 690 Chapter 5 Removal and replacement

c. M507/E50145 only: Disconnect two connectors. Figure 5-388 Disconnect two connectors d. Release one boss. Figure 5-389 Release one boss e. M506/E50045/ only: Rotate the front of the cover up and away from the printer, and then remove the cover. **CAUTION:** M506x/E50045x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). **NOTE:** LCD control panel models only: Disconnect the control panel before removing the cover. Removal and replacement: Paper delivery tray (output bin) 691

Figure 5-390 Remove the cover (M506/E50045) 1 f. M507/E50145only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M507x/E50145x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). IMPORTANT: If the top cover is being replaced, make sure to transfer the WiFi PCA from the discarded cover to the replacement cover. NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-391 Remove the cover (M507/E50145) 1 692 Chapter 5 Removal and replacement

16. Remove the paper delivery tray (output bin). NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. a. Release two tabs (callout 1), and then slide the cover toward the front of the printer (callout 2). Figure 5-392 Release two tabs 1 2 1 b. Remove the bin. Figure 5-393 Remove the bin 17. Unpack the replacement assembly. Removal and replacement: Paper delivery tray (output bin) 693

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly.

Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement:

Sub-scanner assembly (SSA) (MFP) Learn how to remove and replace the sub-scanner assembly (SSA). To view a short video of this procedure, click the link below. View a video of how to remove and replace the sub-scanner assembly (SSA). Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-26 Part information

Part number Part description

F2A76-67909 Image scanner kit (M527/E52545/M528/E52645) with instruction guide (includes white backing kit) 694 Chapter 5 Removal and replacement

Required tools

● Small flat-blade screwdriver ● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Print a configuration page, and then make a copy using the flatbed glass to make sure that it is properly functioning. Print a configuration page, and then make a copy using the document feeder to make sure that it is properly functioning. 1. Remove the white backing (M527/E52545/M528/E52645). a. Open the document feeder. Figure 5-394 Open the document feeder b. Remove the white backing and retention clips (attached to the document feeder behind the white backing). TIP: Use the edge of a coin to loosen the clips. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 695

Figure 5-395 Remove the white backing 2. Remove the control panel. a. Open the document feeder. NOTE: If the control panel is not fully tilted forward, tilt it forward now until it stops. Figure 5-396 Open the document feeder 2 1 b. Beginning at the right side of the control-panel cover, carefully release five tabs along the top edge of the cover. NOTE: The thin black-plastic cover will separate from the white-plastic control-panel base. 696 Chapter 5 Removal and replacement

Figure 5-397 Release five tabs c. Continue to rotate the top edge of the cover away from the printer, and then remove the cover. Figure 5-398 Remove the cover Removal and replacement: Sub-scanner assembly (SSA) (MFP) 697

d. M527/E52545/M528c/z, and E52645c/z only: Open the connector latch to release the keyboard flat cable. Figure 5-399 Disconnect the FFC (M527/E52545/M528c/z, and E52645c/z) e. Disconnect one HDMI cable (callout 1) and one connector (callout 2). Figure 5-400 Disconnect connectors 1 2 f. Remove the USB cable (callout 1) from the holder. NOTE: M527z/E52545z only: Release four tabs (callout 2), and then remove the near-field communication (NFC) printed circuit board. 698 Chapter 5 Removal and replacement

Figure 5-401 Remove USB cable and NFC PCA 1 2 g. Remove three screws (callout 1). TIP: The screwdriver (supplied with the kit) has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. Removal and replacement:

Sub-scanner assembly (SSA) (MFP) 699

Figure 5-402 Remove three screws 1 h. Lift the front of the control panel off of the printer (callout 1), and then slide it toward the front of the printer (callout 2) to remove it. Figure 5-403 Remove the control panel 2 1 3. Remove the formatter cover. ■ Do one of the following: 700 Chapter 5 Removal and replacement

● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-404 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-405 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

4. Remove the fax PCA (M527/E52545/M528/E52645 fax models). CAUTION: ESD-sensitive part. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 701

a. Disconnect three connectors (callout 1). Figure 5-406 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-407 Release the fax PCA 702 Chapter 5 Removal and replacement

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-408 Remove the fax PCA 1 2 5. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-409 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 703

Figure 5-410 Release the upper hinge or remove the cover c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-411 Release the lower hinge 704 Chapter 5 Removal and replacement

d. Stapler models: Remove the door. Figure 5-412 Remove the door 6. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. Figure 5-413 Locate the tabs 1 2 Removal and replacement: Sub-scanner assembly (SSA) (MFP) 705

b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-414 Release one tab c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-415 Release one tab 706 Chapter 5 Removal and replacement

d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-416 Remove the cover 1 2 7. Remove the top-left cover (M527/E52545/M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-417 Release two tabs 1 Removal and replacement: Sub-scanner assembly (SSA) (MFP) 707

b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-418 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-419 Slide the cover 708 Chapter 5 Removal and replacement

d. Remove the cover. Figure 5-420 Remove the cover 8. Remove the top-rear cover (M527/E52545/M528/E52645). a. Remove one screw (callout 1), and then open the rear door. Figure 5-421 Remove one screw 1 Removal and replacement: Sub-scanner assembly (SSA) (MFP) 709

b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-422 Rotate the cover c. Continue to rotate the cover away from the printer to release one boss. Figure 5-423 Release one boss 710 Chapter 5 Removal and replacement

d. Remove the cover. Figure 5-424 Remove the cover 9. Remove the scanner control board (SCB). a. Disconnect all of the connectors from the SCB. Reinstallation tip: There are eight wire-harness connectors, two flat-flexible cables (FFCs), and one high definition multimedia interface (HDMI) cable connector. Figure 5-425 Disconnect all of the connectors Removal and replacement: Sub-scanner assembly (SSA) (MFP) 711

b. Remove three screws (callout 1). Figure 5-426 Remove three screws 1 c. Release one tab (callout 1), and then remove one ferrite from the holder (callout 2). NOTE: The ferrite does not need to be removed from the FFC. Simply let it slide down the FFC until it stops, and then let it hang out of the way. Figure 5-427 Remove one ferrite 1 2 712 Chapter 5 Removal and replacement

d. Release one tab (callout 1), and then remove one ferrite from the holder (callout 2). Figure 5-428 Remove one ferrite 2 1 e. Slide the ferrite down the FFC to remove it. Figure 5-429 Remove the ferrite from the FFC Removal and replacement: Sub-scanner assembly (SSA) (MFP) 713

f. Slide the SCB straight out of the printer. Figure 5-430 Slide the SCB out g. Remove the SCB. Reinstallation tip: For a replacement SCB, do the following 1. Remove two screws, and then remove the SCB cage top cover. 2. Install the top cover on the replacement SCB. Figure 5-431 Remove the SCB 10. Remove the sub-scanner assembly (SSA) (M527/E52545/M528/E52645). NOTE: The SCB is shown installed in the following steps, but was previously removed. The procedure for removing the document feeder (below) is correct for the printer. 714 Chapter 5 Removal and replacement

a. Remove one screw (callout 1), and then remove the cable cover (callout 2). Figure 5-432 Remove the cover 1 2 b. Disconnect one flat-flexible cable (FFC; callout 1), and then remove one ground screw (callout 2). Figure 5-433 Disconnect the FFC and the ground cable 1 2 Removal and replacement: Sub-scanner assembly (SSA) (MFP) 715

c. Tilt the document feeder back until it stops (callout 1), and then lift it up until it stops (callout 2). Figure 5-434 Raise the document feeder 1 2
d. Support the document feeder, and then use a small flat-blade screwdriver to release two tabs on the document feeder hinges. NOTE: The tabs are located on the front side (scanner flatbed glass) of the hinges. Use the figure to locate the tabs. Figure 5-435 Release two tabs e. Lift the document feeder up to remove it. NOTE: While removing the document feeder, carefully pass the wire harnesses and the FFC through the opening in the scanner. 716 Chapter 5 Removal and replacement

Figure 5-436 Remove the document feeder f. Remove one screw (callout 1), and then remove the control panel grounding clip (callout 2). NOTE: M527c/z, E52545c/z, M528c/z, and E52645c/z only: Remove the keyboard (callout 3). Figure 5-437 Remove one screw 1 3 2 g. Disconnect three connectors (callout 1), and then pass the wire harnesses and cables through the opening in the cover (callout 2). TIP: It might be easier if the WiFi PCA and holder (callout 3) is detached from the printer, and then moved out of the way. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 717

Figure 5-438 Disconnect cables and connectors 1 2 3 h. Remove four screws. Figure 5-439 Remove four screws 718 Chapter 5 Removal and replacement

i. Slide the SSA toward the front of the printer to release it. Figure 5-440 Release the SSA j. Remove the SSA. Figure 5-441 Remove the SSA 11. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Sub-scanner assembly (SSA) (MFP) 719

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 12. Reverse the removal steps to install the assembly. Also use the following special installation instructions.

Install a replacement white backing

a. Verify that the springs are positioned correctly on the replacement retention clips. Figure 5-442 Check the retention clip spring b. Install the clip (callout 1) in the opening (callout 2) in the document feeder. NOTE: Make sure that the springs are correctly installed. See the previous step. 720 Chapter 5 Removal and replacement

Figure 5-443 Install the retention clip 1 2 c. Press the clip to make sure it is securely installed. Figure 5-444 Press the retention clip d. Remove the protective film off of each adhesive square. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 721

Figure 5-445 White backing adhesive squares e. Position the replacement white backing on the image scanner glass. NOTE: Make sure that the corner with the embossed arrow on the white backing is positioned against the corner with the arrow on the scanner. Figure 5-446 Install the white backing f. Close the document feeder. 722 Chapter 5 Removal and replacement

Figure 5-447 Close the document feeder g. Open the document feeder and press on the white backing at the location of each retention clip to ensure that the backing is securely attached to the adhesive on the clips. Figure 5-448 Check the white backing h. Close the document feeder. Removal and replacement: Sub-scanner assembly (SSA) (MFP) 723

Figure 5-449 Close the document feeder Field replaceable units (FRUs) Learn how to remove and replace the printer FRU assemblies. Removal and replacement: Scanner control board (MFP) Learn how to remove and replace the scanner control board (SCB). To view a short video of this procedure, click the link below. View a video of how to remove and replace the SCB. Mean time to repair: 12 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-27 Part information

Part number Part description

B5L47-67903 Scanner control board kit with instruction guide

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length 724 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. Use the flatbed glass to make a copy of the configuration page. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-450 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Removal and replacement: Scanner control board (MFP) 725

Figure 5-451 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the top-left cover (M527/E52545/M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-452 Release two tabs 1 726 Chapter 5 Removal and replacement

b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-453 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-454 Slide the cover Removal and replacement: Scanner control board (MFP) 727

d. Remove the cover. Figure 5-455 Remove the cover 3. Remove the top-rear cover (M527/E52545/M528/E52645). a. Remove one screw (callout 1), and then open the rear door. Figure 5-456 Remove one screw 1 728 Chapter 5 Removal and replacement

b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-457 Rotate the cover c. Continue to rotate the cover away from the printer to release one boss. Figure 5-458 Release one boss Removal and replacement: Scanner control board (MFP) 729

d. Remove the cover. Figure 5-459 Remove the cover 4. Remove the scanner control board (SCB). a. Disconnect all of the connectors from the SCB. Reinstallation tip: There are eight wire-harness connectors, two flat-flexible cables (FFCs), and one high definition multimedia interface (HDMI) cable connector. Figure 5-460 Disconnect all of the connectors 730 Chapter 5 Removal and replacement

b. Remove three screws (callout 1). Figure 5-461 Remove three screws 1 c. Release one tab (callout 1), and then remove one ferrite from the holder (callout 2). NOTE: The ferrite does not need to be removed from the FFC. Simply let it slide down the FFC until it stops, and then let it hang out of the way. Figure 5-462 Remove one ferrite 1 2 Removal and replacement: Scanner control board (MFP) 731

d. Release one tab (callout 1), and then remove one ferrite from the holder (callout 2). Figure 5-463 Remove one ferrite 2 1 e. Slide the ferrite down the FFC to remove it. Figure 5-464 Remove the ferrite from the FFC 732 Chapter 5 Removal and replacement

f. Slide the SCB straight out of the printer. Figure 5-465 Slide the SCB out g. Remove the SCB. Reinstallation tip: For a replacement SCB, do the following 1. Remove two screws, and then remove the SCB cage top cover. 2. Install the top cover on the replacement SCB. Figure 5-466 Remove the SCB 5. Unpack the replacement assembly. Removal and replacement: Scanner control board (MFP) 733

a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Near field communication printed-circuit assembly (M527z/E52545z) Learn how to remove and replace the near field communication (NFC) printed-circuit assembly (PCA). To view a short video of this procedure, click the link below. View a video of how to remove and replace the NFC. Mean time to repair: 12 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. 734 Chapter 5 Removal and replacement

Table 5-28 Part information

Part number Part description

B5L24-60001 Near field communication (NFC) PCA (M527z/E52545z) NOTE: This NFC is also used for the M506x/E50045x printer.

Required tools

● No special tools are required to remove or install this assembly.

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use an NFC enabled device to print a job from the printer. 1. Remove the control-panel cover. a. If the document feeder is not open, open it now. NOTE: If the control panel is not fully tilted forward, tilt it forward now until it stops. Figure 5-467 Open the document feeder 2 1 Removal and replacement: Near field communication printed-circuit assembly (M527z/E52545z) 735

b. Beginning at the right side of the control-panel cover, carefully release five tabs along the top edge of the cover. Figure 5-468 Release five tabs c. Continue to rotate the top edge of the cover away from the printer, and then remove the cover. Figure 5-469 Remove the cover 2. Remove the NFC PCA. 736 Chapter 5 Removal and replacement

a. Release two tabs (callout 1). Figure 5-470 Release two tabs 1 b. Turn the NFC PCA over to access the bottom side, disconnect one connector (callout 1), and then remove the NFC PCA. Figure 5-471 Remove the NFC PCA 1 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Near field communication printed-circuit assembly (M527z/E52545z) 737

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) Learn how to remove and replace the wireless PCA. To view a short video of this procedure, click the link below. View a video of how to remove and replace the wireless PCA. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-29 Part information

Part number Part description

1150-7968 Wireless PCA (M506x/E50045x)

Required tools

● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length 738 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use a wireless device to print a job from the printer. 1. Remove the tray. a. Pull the tray straight out of the printer until it stops. Figure 5-472 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 739

Figure 5-473 Release and remove the tray 2. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-474 Remove the formatter cover (M501) 2 1 ●

M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 740 Chapter 5 Removal and replacement

Figure 5-475 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

3. Remove the rear door assembly. a. At the rear of the printer, remove two screws (callout 1). Figure 5-476 Remove two screws 1 Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 741

b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-477 Rotate the bottom of the cover c. Pull down on the assembly to remove it. Figure 5-478 Remove the cover 4. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. 742 Chapter 5 Removal and replacement

Figure 5-479 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-480 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 743

Figure 5-481 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-482 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. 744 Chapter 5 Removal and replacement

Figure 5-483 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-484 Release the left-side retainer arm Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 745

g. Remove the door. Figure 5-485 Remove the door 5. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-486 Locate the tabs and bosses 746 Chapter 5 Removal and replacement

b. Remove two screws (callout 1). Figure 5-487 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-488 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 747

Figure 5-489 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-490 Release one tab 748 Chapter 5 Removal and replacement

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-491 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-492 Remove the cover 2 1 3 Removal and replacement: Wireless printed-circuit board (WiFi) (M506x/E50045x) 749

6. Remove the wireless PCA (WiFi) (M506x/E50045x). ■ Disconnect one connector (callout 1) release one tab (callout 2), and then remove the WiFi PCA (callout 3). Figure 5-493 Remove the WiFi PCA 3 2 1 7. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly.

Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 750 Chapter 5 Removal and replacement

Removal and replacement: Wireless printed-circuit board (WiFi) (M507x/E50145x) Learn how to remove and replace the wireless PCA. To view a short video of this procedure, click the link below View a video of how to remove and replace the wireless PCA. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-30 Part information

Part number Part description

1150-7968 Wireless PCA (M507x/E50145x)

Required tools

- Small flat-blade screwdriver

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use a wireless device to print a job from the printer. 1. Remove the wireless PCA (WiFi) (M507x/E50145x). Removal and replacement: Wireless printed-circuit board (WiFi) (M507x/E50145x) 751

a. Open the cartridge door. Figure 5-494 Open the cartridge door b. Use a small flat-blade screwdriver to carefully release the WiFi PCA cover, and then remove the cover. Figure 5-495 Remove the cover c. Release two tabs, and then separate the WiFi PCA from the printer.

CAUTION: The PCA is still attached to the printer by a wire harness. Do not attempt to completely remove the PCA. 752 Chapter 5 Removal and replacement

Figure 5-496 Release the PCA d. Disconnect one connector, and then remove the WiFi PCA. Figure 5-497 Remove the WiFi PCA 2. Unpack the replacement assembly. a. Dispose of the defective part. **NOTE:** HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Wireless printed-circuit board (WiFi) (M507x/E50145x) 753

b. Unpack the replacement part from the packaging. **CAUTION:** Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. **IMPORTANT:** Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. **NOTE:** When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Wireless printed-circuit board (M527z/E52545z/M528z/E52645z) Learn how to remove and replace the wireless PCA. To view a short video of this procedure, click the link below. View a video of how to remove and replace the wireless PCA. Mean time to repair: 8 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-31 Part information

Part number part description

1150-7968 Wireless PCA (M527z/E52545z/M528z/E52645z)

Required tools

- No special tools are required to remove or install this assembly. 754 Chapter 5 Removal and replacement

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use a wireless device to print a job from the printer. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-498 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Removal and replacement: Wireless printed-circuit board (M527z/E52545z/M528z/E52645z) 755

Figure 5-499 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the wireless PCA (WiFi) (M527z/E52545z/M528z/E52645z). ■ Disconnect one connector (callout 1) release one tab (callout 2), and then remove the WiFi PCA (callout 3). Figure 5-500 Remove the WiFi PCA 3 2 1 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 756 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Fuser Learn how to remove and replace the fuser. To view a short video of this procedure, click the link below. View a video of how to remove and replace the fuser. Mean time to repair: 12 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Make sure the correct voltage fuser is installed in the printer. CAUTION: The fuser is hot. Wait at least 30 minutes after turning the printer power off before removing the fuser. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-32 Part information

Part number Part description

RM2-2585-000CN Fuser (110V/127V) RM2-2586-000CN Fuser (220V/240V) Removal and replacement: Fuser 757

Required tools

● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the rear door assembly. a. At the rear of the printer, remove two screws (callout 1). Figure 5-501 Remove two screws 1 758 Chapter 5 Removal and replacement

b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-502 Rotate the bottom of the cover c. Pull down on the assembly to remove it. Figure 5-503 Remove the cover 2. Remove the fuser. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. The formatter cover is shown off in the following figures. However, it does not need to be removed to remove the fuser. Removal and replacement: Fuser 759

a. Remove the connector cover. Figure 5-504 Remove the cover b. Disconnect two connectors (callout 1). Figure 5-505 Disconnect two connectors 1 760 Chapter 5 Removal and replacement

c. Disconnect one connector. Figure 5-506 Disconnect one connector d. Remove four screws (callout 1). Figure 5-507 Remove four screws 1 Removal and replacement: Fuser 761

e. Pull down on the fuser-shutter arm to release it from the fuser. Figure 5-508 Release the pressure-release arm f. Slide the fuser straight out of the printer. Figure 5-509 Remove the fuser 3. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> 762 Chapter 5 Removal and replacement

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Stapler unit (M527c/f/z, E52545c/z/f, M528c/f/z, and E52645c/f/z) Learn how to remove and replace the cassette stapler unit. To view a short video of this procedure, click the link below. View a video of how to remove and replace the stapler unit. Mean time to repair: 5 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-33 Part information

Part number Part description

B5L46-60102 Stapler unit (M527c/f/z, E52545c/f/z, M528c/f/z, and E52645c/f/z)

Required tools

● Small flat-blade screwdriver ● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length Removal and replacement: Stapler unit (M527c/f/z, E52545c/z/f, M528c/f/z, and E52645c/f/z) 763

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Use the convenience stapler to staple two pages together to test its operation. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Figure 5-510 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. 764 Chapter 5 Removal and replacement

Figure 5-511 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-512 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Removal and replacement: Stapler unit (M527c/f/z, E52545c/z/f, M528c/f/z, and E52645c/f/z) 765

Figure 5-513 Release the upper hinge or remove the cover c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge.

Figure 5-514 Release the lower hinge 766 Chapter 5 Removal and replacement

d. Stapler models: Remove the door. Figure 5-515 Remove the door 3. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. Figure 5-516 Locate the tabs 1 2 Removal and replacement: Stapler unit (M527c/f/z, E52545c/z/f, M528c/f/z, and E52645c/f/z) 767

b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-517 Release one tab c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-518 Release one tab 768 Chapter 5 Removal and replacement

d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-519 Remove the cover 1 2 4. Remove the stapler unit (M527/E52545/M528/E52645). a. Disconnect one connector (callout 1), and then remove one screw (callout 2). Figure 5-520 Disconnect one connector and remove one screw 2 1 Removal and replacement: Stapler unit (M527c/f/z, E52545c/z/f, M528c/f/z, and E52645c/f/z) 769

b. Remove the stapler unit. Figure 5-521 Remove the stapler unit 5. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. 770 Chapter 5 Removal and replacement

Removal and replacement: Formatter Learn how to remove and replace the formatter. NOTE: Never remove and then install a replacement DCC and formatter at the same time. Doing so will cause the printer to become unstable. If a replacement DCC and formatter must be installed, first remove and install the formatter. Test operate the printer, and then if necessary install a replacement DCC. To view a short video of this procedure, click the link below. M501 View a video of how to remove and replace the formatter (M501).

M506/E50045

View a video of how to remove and replace the formatter (M506/E50045).

M507/E50145

View a video of how to remove and replace the formatter (M507/E50145).

M527/E52545/M528/E52645

View a video of how to remove and replace the formatter (M527/E52545/M528/E52645). Mean time to repair: 10 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. IMPORTANT: Take note of all empty connectors on the PCA before disconnecting any wire harnesses or flat-flexible cables (FFCs). Some empty connectors might not be visible until other items—like the hard-disk drive—are removed, so pay close attention while removing the formatter and accessory items. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-34 Part information

Part number Part description

F2A76-67910 Formatter (M527/E52545) with instruction guide 1PV64-60002 Formatter (M528/E52645) with instruction guide 1PV64-60003 Formatter (M528/E52645 China) with instruction guide Removal and replacement: Formatter 771

Table 5-34 Part information (continued)

Part number Part description

1PV87-60001 Formatter (M507/E50145) with instruction guide 1PV87-60002 Formatter (M507dn) 1PV87-60003 Formatter (M507n)
1PV86-60004 Formatter (M507x) China/India 1PV86-60007 Formatter (M507dn) China/India 1PV86-60008 Formatter (M507n) China/India
F2A68-67915 Formatter (M506n/E50045n) with instruction guide F2A68-67916 Formatter (M506x/E50045x) with instruction guide
J8H60-67901 Formatter (M501n) J8H60-67902 Formatter (M501n; China) J8H61-67901 Formatter (M501dn) J8H61-67902 Formatter (M501dn; China)

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

- Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of

the printer to remove it (callout 2). 772 Chapter 5 Removal and replacement

Figure 5-522 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-523 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

2. Remove the fax PCA (M527/E52545/M528/E52645 fax models). CAUTION: ESD-sensitive part. Removal and replacement: Formatter 773

a. Disconnect three connectors (callout 1). Figure 5-524 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-525 Release the fax PCA 774 Chapter 5 Removal and replacement

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-526 Remove the fax PCA 1 2 3. Remove the hard-disk drive (HDD models). CAUTION: ESD sensitive part. a. Release the locking connector (callout 1), and then pinch the retainer (callout 2) to release it. Figure 5-527 Release the HDD 1 2 Removal and replacement: Formatter 775

b. Rotate the connector end of the HDD out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-528 Remove the HDD 1 2 4. Remove the embedded Multi-Media Card (eMMC models). CAUTION: ESD sensitive part. ■ Locate the eMMC component on the formatter, and then pull it straight off of the formatter to remove it. Figure 5-529 Remove the eMMC 776 Chapter 5 Removal and replacement

5. Remove the dual in-line memory module (DIMM). CAUTION: ESD sensitive part. NOTE: The M506/E50045/M507/E50145 printers use a Slim dual in-line memory module (DIMM). a. M506/E50045/M507/E50145 only: Locate the DIMM component on the formatter, and then pull it straight off of the formatter to remove it. Figure 5-530 Remove the DIMM (M506/E50045/M507/E50145) b. M527/E52545/M528/E52645 only: Do the following. i. Locate the DIMM component on the formatter, release two locking arms (callout 1), and then let the bottom edge of the DIMM rotate away from the holder (callout 2). Figure 5-531 Release the DIMM (M527/E52545/M528/E52645) 1 2 Removal and replacement: Formatter 777

ii. Pull the DIMM down and away from the holder to remove it. Figure 5-532 Remove the DIMM (M527/E52545/M528/E52645) 6. Remove the formatter. CAUTION: Never remove and then install a replacement DCC and formatter at the same time. Doing so will cause the printer to become unstable. If a replacement DCC and formatter must be installed, first remove and install the formatter. Test operate the printer, and then if necessary install a replacement DCC. IMPORTANT: Take note of all empty connectors on the PCA before disconnecting any wire harnesses or flat-flexible cables (FFCs). Some empty connectors might not be visible until other items—like the hard-disk drive—are removed, so pay close attention while removing the formatter and accessory items. 778 Chapter 5 Removal and replacement

a. M501: Disconnect all of the connectors and FFCs, remove four screws (callout 1), and then remove the formatter. Figure 5-533 Remove the formatter (M501) 1 b. M506/E50045/M507/E50145/M527/E52545/M528/E52645: Disconnect all of the connectors and FFCs, remove four screws (callout 1), and then remove the formatter. IMPORTANT: Take note of all empty connectors on the formatter before disconnecting any wire harnesses or flat-flexible cables (FFCs). Some empty connectors might not be visible until other items—like the hard-disk drive—are removed, so pay close attention while removing the formatter and accessories items. Figure 5-534 Remove the formatter (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

1 1 7. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> Removal and replacement: Formatter 779

b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Laser/scanner assembly Learn how to remove and replace the laser/scanner assembly. To view a short video of this procedure, click the link below. M501 View a video of how to remove and replace the laser/scanner (M501).

M506/E50045

View a video of how to remove and replace the laser/scanner (M506/E50045).

M507/E50145

View a video of how to remove and replace the laser/scanner (M507/E50145).

M527/E52545/M528/E52645

View a video of how to remove and replace the laser/scanner (M527/E52545/M528/E52645). Mean time to repair: 12 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. 780 Chapter 5 Removal and replacement

Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-35 Part information

Part number Part description

RM2-5528-000CN Laser/scanner assembly

Required tools

- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on.

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1.

Remove the control panel (M506x/E50045x/M507x/E50145x). a. Tilt the control panel to the fully raised position. Figure 5-535 Tilt the control panel up Removal and replacement: Laser/scanner assembly 781

b. Use the small flat-blade screwdriver supplied in the kit to release the control-panel screws cover, and then remove the cover. TIP: The screwdriver has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. Figure 5-536 Remove the cover c. Use the small Phillips screwdriver supplied in the kit to remove two screws (callout 1). **IMPORTANT:** Store the screws in a secure place where they cannot fall down into the printer. Figure 5-537 Remove two screws 1 782 Chapter 5 Removal and replacement

d. Turn the control panel over (callout 1), to gain access to the bottom side. Figure 5-538 Turn the control panel over 1 e. M506/E50045 only: Disconnect one HDMI cable (callout 1), one connector (callout 2), and then remove the control panel. Figure 5-539 Remove the control panel (M506/E50045) 1 2 f. M507/E50145 only: If the formatter cover has not been removed, remove it now. Disconnect one flat-flexible cable (FFC). **CAUTION:** ESD sensitive part. **NOTE:** This connector is a zero-insertion force (ZIF) connector. Open the locking clip. The clip is easily dislodged and lost. Removal and replacement: Laser/scanner assembly 783

Figure 5-540 Disconnect one FFC (M507/E50145) g. M507/E50145 only: Pass the FFC through the opening in the cover, and then remove the control panel. **CAUTION:** ESD sensitive part. Figure 5-541 Remove the control panel (M507/E50145) 2. Remove the tray. 784 Chapter 5 Removal and replacement

a. Pull the tray straight out of the printer until it stops. Figure 5-542 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. **NOTE:** If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-543 Release and remove the tray 3. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). Removal and replacement: Laser/scanner assembly 785

Figure 5-544 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-545 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

4. Remove the fax PCA (M527/E52545/M528/E52645 fax models). **CAUTION:** ESD-sensitive part. 786 Chapter 5 Removal and replacement

a. Disconnect three connectors (callout 1). Figure 5-546 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-547 Release the fax PCA Removal and replacement: Laser/scanner assembly 787

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-548 Remove the fax PCA 1 2 5. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-549 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. 788 Chapter 5 Removal and replacement

Figure 5-550 Release the upper hinge or remove the cover c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-551 Release the lower hinge Removal and replacement: Laser/scanner assembly 789

d. Stapler models: Remove the door. Figure 5-552 Remove the door 6. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. Figure 5-553 Locate the tabs 1 2 790 Chapter 5 Removal and replacement

b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-554 Release one tab c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-555 Release one tab Removal and replacement: Laser/scanner assembly 791

d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-556 Remove the cover 1 2 7. Remove the top-left cover (M527/E52545/M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-557 Release two tabs 1 792 Chapter 5 Removal and replacement

b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-558 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-559 Slide the cover Removal and replacement: Laser/scanner assembly 793

d. Remove the cover. Figure 5-560 Remove the cover 8. Remove the top-rear cover (M527/E52545/M528/E52645). a. Remove one screw (callout 1), and then open the rear door. Figure 5-561 Remove one screw 1 794 Chapter 5 Removal and replacement

b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-562 Rotate the cover c. Continue to rotate the cover away from the printer to release one boss. Figure 5-563 Release one boss Removal and replacement: Laser/scanner assembly 795

d. Remove the cover. Figure 5-564 Remove the cover 9. Remove the rear door assembly. a. At the rear of the printer, remove two screws (callout 1). Figure 5-565 Remove two screws 1 796 Chapter 5 Removal and replacement

b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-566 Rotate the bottom of the cover c. Pull down on the assembly to remove it. Figure 5-567 Remove the cover 10. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. Removal and replacement: Laser/scanner assembly 797

Figure 5-568 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-569 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. 798 Chapter 5 Removal and replacement

Figure 5-570 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-571 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. Removal and replacement: Laser/scanner assembly 799

Figure 5-572 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-573 Release the left-side retainer arm 800 Chapter 5 Removal and replacement

g. Remove the door. Figure 5-574 Remove the door 11. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-575 Locate the tabs and bosses Removal and replacement: Laser/scanner assembly 801

b. Remove two screws (callout 1). Figure 5-576 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-577 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. 802 Chapter 5 Removal and replacement

Figure 5-578 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-579 Release one tab Removal and replacement: Laser/scanner assembly 803

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-580 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-581 Remove the cover 2 1 3 804 Chapter 5 Removal and replacement

12. Remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover.

Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-582 Locate of the tabs and bosses b. Remove one screw (callout 1). Figure 5-583 Remove one screw 1 Removal and replacement: Laser/scanner assembly 805

c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-584 Release one boss and three tabs 2 1 d. At the bottom edge of the cover, release two tabs. Figure 5-585 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. 806 Chapter 5 Removal and replacement

Figure 5-586 Remove the cover 1 2 13. Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645). NOTE: The ISA includes the document feeder, sub-scanner assembly (SSA), and the scanner control board (SCB). a. Remove one screw (callout 1). IMPORTANT: This screw fastens the ISA ground plate to the printer chassis. Do not lose this screw. Figure 5-587 Remove one screw 1 Removal and replacement: Laser/scanner assembly 807

b. Disconnect three connectors (callout 1), pass the wire harnesses and cables through the opening in the cover (callout 2), and then release them from the retainers (callout 3). NOTE: One cable (callout 4) does not need to pass through the opening in the cover. TIP: It might be easier if the WiFi PCA and holder (not all models; callout 5) is detached from the printer, and then moved out of the way. Figure 5-588 Disconnect cables and connectors 4 1 2 3 5 c. Disconnect three connectors (callout 1), and then remove six screws (callout 2). Figure 5-589 Disconnect connectors and remove screws 1 2 808 Chapter 5 Removal and replacement

d. Slightly slide the ISA towards the back of the printer to release it. Figure 5-590 Slide the ISA towards the back of the printer e. Remove the ISA. Figure 5-591 Remove the ISA 14. Remove the top cover (M527/E52545/M528/E52645). Removal and replacement: Laser/scanner assembly 809

a. At the front right of the printer, remove one screw (callout 1), and then remove the sheet-metal plate (callout 2). Figure 5-592 Remove one screw and the plate 1 2 b. At the top rear of the printer, remove three screws (callout 1). Figure 5-593 Remove three screws 1 c. At the top front of the printer, remove three screws (callout 1). NOTE: The screw (callout 2) on the lower-right portion of the cover is a different color than the other two screws, and is surrounded by sheet-metal. It might appear that this screw does not need to be removed. Remove this screw. 810 Chapter 5 Removal and replacement

Figure 5-594 Remove three screws 1 2 d. At the front left of the printer, release one boss. Figure 5-595 Release one boss e. Rotate the front of the cover up and away from the printer. CAUTION: As the cover is rotated up, carefully pass the cables and wire harnesses the hole in the cover (callout 1). Removal and replacement: Laser/scanner assembly 811

Figure 5-596 Rotate the front of the cover up 1 f. Remove the cover. Figure 5-597 Remove the cover 15. Remove the top cover (M501/M506/E50045/M507/E50145). The M506x/E50045x is shown in this procedure. However, the steps are correct for all M506/E50045/M507/E50145 models and the M501 printer. 812 Chapter 5 Removal and replacement

a. Remove two screws (callout 1). Figure 5-598 Remove two screws 1 b. M506/E50045/ only: Release one cable retainer from the chassis. TIP: Depress the tab on the retainer to release it. Figure 5-599 Release one cable retainer Removal and replacement: Laser/scanner assembly 813

c. M507/E50145 only: Disconnect two connectors. Figure 5-600 Disconnect two connectors d. Release one boss. Figure 5-601 Release one boss e. M506/E50045/ only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M506x/E50045x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. 814 Chapter 5 Removal and replacement

Figure 5-602 Remove the cover (M506/E50045) 1 f. M507/E50145only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M507x/E50145x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). IMPORTANT: If the top cover is being replaced, make sure to transfer the WiFi PCA from the discarded cover to the replacement cover. NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-603 Remove the cover (M507/E50145) 1 Removal and replacement: Laser/scanner assembly 815

16. Remove the laser/scanner assembly. NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. a. Disconnect one flat-flexible cable (FFC; callout 1), release the FFC from the retainers (callout 2), and then move it out of the way. Figure 5-604 Disconnect one FFC 1 2 b. Remove the antistatic foam pad. Reinstallation tip: Set the antistatic foam pad aside. It must be installed on the replacement laser/scanner. Figure 5-605 Remove the antistatic foam pad 816 Chapter 5 Removal and replacement

c. Disconnect one connector. Figure 5-606 Disconnect one connector d. Remove four screws (callout 1). Figure 5-607 Remove four screws 1 Removal and replacement: Laser/scanner assembly 817

e. Disconnect one FFC, and then remove the laser/scanner. Figure 5-608 Remove the laser/scanner 17. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part.

<http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Formatter case Learn how to remove and replace the formatter case. 818 Chapter 5 Removal and replacement

To view a short video of this procedure, click the link below. M501 View a video of how to remove and replace the formatter case (M501).

M506/E50045

View a video of how to remove and replace the formatter case (M506/E50045).

M507/E50145

View a video of how to remove and replace the formatter case (M507/E50145).

M527/E52545/M528/E52645

View a video of how to remove and replace the formatter case (M527/E52545/M528/E52645). Mean time to repair: 7 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. **WARNING!** To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-36 Part information

Part number Part description

RL2-0895-000CN Case, formatter (M527/E52545/M528/E52645) RL2-0885-000CN Case, formatter (M506/E50045/M507/E50145)
RL2-0888-000CN Case, formatter (M501)

Required tools

● Small flat-blade screwdriver ● #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

■ Connect the power cable. ■ Use the power switch to turn the power on. Removal and replacement: Formatter case 819

Post service test

Make sure that the printer initializes to a Ready state. Print a configuration page to make sure that the printer is functioning correctly. 1. Remove the control panel (M506x/E50045x/M507x/E50145x). a. Tilt the control panel to the fully raised position. Figure 5-609 Tilt the control panel up b. Use the small flat-blade screwdriver supplied in the kit to release the control-panel screws cover, and then remove the cover. TIP: The screwdriver has a reversible shaft. Simply pull the shaft out of the handle, and then reinstall it with the desired end facing out. 820 Chapter 5 Removal and replacement

Figure 5-610 Remove the cover c. Use the small Phillips screwdriver supplied in the kit to remove two screws (callout 1). **IMPORTANT:** Store the screws in a secure place where they cannot fall down into the printer. Figure 5-611 Remove two screws 1 Removal and replacement: Formatter case 821

d. Turn the control panel over (callout 1), to gain access to the bottom side. Figure 5-612 Turn the control panel over 1 e. M506/E50045 only: Disconnect one HDMI cable (callout 1), one connector (callout 2), and then remove the control panel. Figure 5-613 Remove the control panel (M506/E50045) 1 2 f. M507/E50145 only: If the formatter cover has not been removed, remove it now. Disconnect one flat-flexible cable (FFC). **CAUTION:** ESD sensitive part. **NOTE:** This connector is a zero-insertion force (ZIF) connector. Open the locking clip. The clip is easily dislodged and lost. 822 Chapter 5 Removal and replacement

Figure 5-614 Disconnect one FFC (M507/E50145) g. M507/E50145 only: Pass the FFC through the opening in the cover, and then remove the control panel. **CAUTION:** ESD sensitive part. Figure 5-615 Remove the control panel (M507/E50145) 2. Remove the tray. Removal and replacement: Formatter case 823

a. Pull the tray straight out of the printer until it stops. Figure 5-616 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. **NOTE:** If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-617 Release and remove the tray 3. Remove the formatter cover. ■ Do one of the following: ● M501: Remove one screw (callout 1), and then slide the cover toward the rear of the printer to remove it (callout 2). 824 Chapter 5 Removal and replacement

Figure 5-618 Remove the formatter cover (M501) 2 1 ● M506/E50045/M507/E50145/M527/E52545/M528/E52645: Slide the cover toward the rear of the printer to remove it. Figure 5-619 Remove the formatter cover (M506/E50045/M507/E50145/M527/E52545/M528/

E52645)

4. Remove the hard-disk drive (HDD models). CAUTION: ESD sensitive part. Removal and replacement: Formatter case 825

a. Release the locking connector (callout 1), and then pinch the retainer (callout 2) to release it. Figure 5-620 Release the HDD 1 2 b. Rotate the connector end of the HDD out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-621 Remove the HDD 1 2 5. Remove the fax PCA (M527/E52545/M528/E52645 fax models). CAUTION: ESD-sensitive part. 826 Chapter 5 Removal and replacement

a. Disconnect three connectors (callout 1). Figure 5-622 Disconnect three connectors 1 b. Pinch the retainer to release it. Figure 5-623 Release the fax PCA Removal and replacement: Formatter case 827

c. Rotate the connector end of the fax PCA out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-624 Remove the fax PCA 1 2 6. Remove the hard-disk drive (HDD models). CAUTION: ESD sensitive part. a. Release the locking connector (callout 1), and then pinch the retainer (callout 2) to release it. Figure 5-625 Release the HDD 1 2 828 Chapter 5 Removal and replacement

b. Rotate the connector end of the HDD out and away from the formatter (callout 1), and then slide it as shown (callout 2) to remove it. Figure 5-626 Remove the HDD 1 2 7. Remove the stapler door or stapler blank cover (M527/E52545/M528/E52645). a. Do one of the following: ● Stapler models: Open the stapler door. ● Non-stapler models: Use a small flat-blade screw driver to release two tabs (callout 1), and then rotate the cover away from the printer (callout 2). Figure 5-627 Open the door or release the cover 2 1 b. Do one of the following: ● Stapler models: Use a small flat-blade screwdriver to release the upper hinge. ● Non-stapler models: Slide the cover toward the front of the printer to remove it. Removal and replacement: Formatter case 829

Figure 5-628 Release the upper hinge or remove the cover c. Stapler models: Use a small flat-blade screwdriver to release the lower hinge. Figure 5-629 Release the lower hinge 830 Chapter 5 Removal and replacement

d. Stapler models: Remove the door. Figure 5-630 Remove the door 8. Remove the stapler stationary (inner) cover (M527/E52545/M528/E52645). NOTE: Stapler models only. a. Before proceeding, take note of the locations of the upper tab (callout 1) and the lower tab (callout 2) on the stapler stationary (inner) cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs. Figure 5-631 Locate the tabs 1 2 Removal and replacement: Formatter case 831

b. Use a long-shaft small flat-blade screwdriver to release the lower tab. Figure 5-632 Release one tab c. Use a long-shaft small flat-blade screwdriver to release the upper tab. Figure 5-633 Release one tab 832 Chapter 5 Removal and replacement

d. With the tabs disengaged the front of the cover is released. Rotate the front of the cover away from the printer (callout 1) to release the rear of the cover (callout 2), and then remove it. Figure 5-634 Remove the cover 1 2 9. Remove the top-left cover (M527/E52545/M528/E52645). a. Open the toner-cartridge door, release two tabs (callout 1), and then rotate the rear edge of the cover away from the printer. Figure 5-635 Release two tabs 1 Removal and replacement: Formatter case 833

b. Continue to rotate the cover away from the printer to release two more tabs at the middle of the cover. Figure 5-636 Release two tabs c. Slide the cover toward the rear of the printer to release two bosses at the front of the cover. Figure 5-637 Slide the cover 834 Chapter 5 Removal and replacement

d. Remove the cover. Figure 5-638 Remove the cover 10. Remove the top-rear cover (M527/E52545/M528/E52645). a. Remove one screw (callout 1), and then open the rear door. Figure 5-639 Remove one screw 1 Removal and replacement: Formatter case 835

b. Rotate the exposed edge of the cover away from the printer (as shown). Figure 5-640 Rotate the cover c. Continue to rotate the cover away from the printer to release one boss. Figure 5-641 Release one boss 836 Chapter 5 Removal and replacement

d. Remove the cover. Figure 5-642 Remove the cover 11. Remove the rear door assembly. a. At the rear of the printer, remove two screws (callout 1). Figure 5-643 Remove two screws 1 Removal and replacement: Formatter case 837

b. Rotate the bottom edge of the assembly away from the printer to release it. Figure 5-644 Rotate the bottom of the cover c. Pull down on the assembly to remove it. Figure 5-645 Remove the cover 12. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. a. Release the support shaft (callout 1), and then slide it toward the center of the door (callout 2). TIP: It might be easier to release the support shaft by using a small flat-blade screwdriver. 838 Chapter 5 Removal and replacement

Figure 5-646 Release the support shaft 1 2 b. Remove the support shaft. Figure 5-647 Remove the support shaft c. Release one tab (callout 1), and then slide the guide out of the printer (callout 2). CAUTION: Be careful, the tab (callout 1) can be easily broken. Removal and replacement: Formatter case 839

Figure 5-648 Remove the guide 2 1 d. Use a small flat-blade screwdriver to gently pry the white-plastic door arm (callout 1) off of the gray-plastic pressure-release link (callout 2) to release the door arm. Figure 5-649 Release the pressure-release link 1 2 e. With the door in the partially closed position, slightly raise the left end (callout 1; raise it over the sheet-metal hinge boss), and then slide the door to the left (callout 2) to release the right hinge (callout 3). CAUTION: The door is still attached to the printer by the left-side retainer arm. Do not attempt to completely remove the door. Reinstallation tip: When reinstalling the door, there are two right-side hinge pins (not shown in callout 3). Keep a finger pressed on the left-side retainer arm so that it does not disengage from the door. 840 Chapter 5 Removal and replacement

Figure 5-650 Release the door 3 1 2 f. Rotate the door away from the printer until the keyed pin on the left-side retainer arm can disengage from the door. Figure 5-651 Release the left-side retainer arm Removal and replacement: Formatter case 841

g. Remove the door. Figure 5-652 Remove the door 13. Remove the right cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-653 Locate the tabs and bosses 842 Chapter 5 Removal and replacement

b. Remove two screws (callout 1). Figure 5-654 Remove two screws 1 c. At the rear of the printer, release one boss. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-655 Release one boss d. At the bottom edge of the cover, release two bosses. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Removal and replacement: Formatter case 843

Figure 5-656 Release two bosses e. Near the formatter, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Hold the bottom of the cover away from the printer, and then use a small flat-blade screw driver to easily release this tab. Figure 5-657 Release one tab 844 Chapter 5 Removal and replacement

f. At the top rear edge of the cover, release one tab. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. TIP: Use a small flat-blade screw driver to easily release this tab. Figure 5-658 Release one tab g. Rotate the rear of the cover away from the printer (callout 1), slide the cover toward the front of the printer (callout 2) to release two bosses (callout 3), and then remove the cover. CAUTION: It might be easier to remove the cover with the printer slightly hanging over the edge of the workspace. Do not let the printer tip and fall off of the workspace when removing the cover. Figure 5-659 Remove the cover 2 1 3 Removal and replacement: Formatter case 845

14. Remove the left cover. IMPORTANT: The black-plastic cassette front and rear guides (located inside the tray cavity) can be easily dislodged. Do not lose the guides when the cover is removed or installed. NOTE: An MFP printer is shown in this section. However, the procedure is correct for all printer models. a. Before proceeding, take note of the location of the tabs and bosses on the inside of the cover. Reinstallation tip: When reinstalling the cover, take note of the location of the tabs and bosses on the inside of the cover. Figure 5-660 Locate of the tabs and bosses b. Remove one screw (callout 1). Figure 5-661 Remove one screw 1 846 Chapter 5 Removal and replacement

c. At the front of the printer, release one boss (callout 1), and then rotate the front edge of the cover away from the printer to release three tabs (callout 2). Figure 5-662 Release one boss and three tabs 2 1 d. At the bottom edge of the cover, release two tabs. Figure 5-663 Release two tabs e. Continue to rotate the front edge of the cover away from the printer (callout 1), and then slide the cover toward the rear of the printer (callout 2) to remove it. NOTE: If the cover is difficult to rotate or slide as shown below, make sure that the bottom tabs (released in the previous step) are completely disengaged from the chassis. Removal and replacement: Formatter case 847

Figure 5-664 Remove the cover 1 2 15. Remove the integrated-scanner assembly (ISA) (M527/E52545/M528/E52645). NOTE: The ISA includes the document feeder, sub-scanner assembly (SSA), and the scanner control board (SCB). a. Remove one screw (callout 1). IMPORTANT: This screw fastens the ISA ground plate to the printer chassis. Do not lose this screw. Figure 5-665 Remove one screw 1 848 Chapter 5 Removal and replacement

b. Disconnect three connectors (callout 1), pass the wire harnesses and cables through the opening in the cover (callout 2), and then release them from the retainers (callout 3). NOTE: One cable (callout 4) does not need to pass through the opening in the cover. TIP: It might be easier if the WiFi PCA and holder (not all models; callout 5) is detached from the printer, and then moved out of the way. Figure 5-666 Disconnect cables and connectors 4 1 2 3 5 c. Disconnect three connectors (callout 1), and then remove six screws (callout 2). Figure 5-667 Disconnect connectors and remove screws 1 2 Removal and replacement: Formatter case 849

d. Slightly slide the ISA towards the back of the printer to release it. Figure 5-668 Slide the ISA towards the back of the printer e. Remove the ISA. Figure 5-669 Remove the ISA 16. Remove the top cover (M527/E52545/M528/E52645). 850 Chapter 5 Removal and replacement

a. At the front right of the printer, remove one screw (callout 1), and then remove the sheet-metal plate (callout 2). Figure 5-670 Remove one screw and the plate 1 2 b. At the top rear of the printer, remove three screws (callout 1). Figure 5-671 Remove three screws 1 c. At the top front of the printer, remove three screws (callout 1). NOTE: The screw (callout 2) on the lower-right portion of the cover is a different color than the other two screws, and is surrounded by sheet-metal. It might appear that this screw does not need to be removed. Remove this screw. Removal and replacement: Formatter case 851

Figure 5-672 Remove three screws 1 2 d. At the front left of the printer, release one boss. Figure 5-673 Release one boss e. Rotate the front of the cover up and away from the printer. CAUTION: As the cover is rotated up, carefully pass the cables and wire harnesses the hole in the cover (callout 1). 852 Chapter 5 Removal and replacement

Figure 5-674 Rotate the front of the cover up 1 f. Remove the cover. Figure 5-675 Remove the cover 17. Remove the top cover (M501/M506/E50045/M507/E50145). The M506x/E50045x is shown in this procedure. However, the steps are correct for all M506/E50045/M507/E50145 models and the M501 printer. Removal and replacement: Formatter case 853

a. Remove two screws (callout 1). Figure 5-676 Remove two screws 1 b. M506/E50045/ only: Release one cable retainer from the chassis. TIP: Depress the tab on the retainer to release it. Figure 5-677 Release one cable retainer 854 Chapter 5 Removal and replacement

c. M507/E50145 only: Disconnect two connectors. Figure 5-678 Disconnect two connectors d. Release one boss. Figure 5-679 Release one boss e. M506/E50045/ only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M506x/E50045x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Removal and replacement: Formatter case 855

Figure 5-680 Remove the cover (M506/E50045) 1 f. M507/E50145only: Rotate the front of the cover up and away from the printer, and then remove the cover. CAUTION: M507x/E50145x only: As the cover is rotated up, carefully pass the cables the hole in the chassis (callout 1). IMPORTANT: If the top cover is being replaced, make sure to transfer the WiFi PCA from the discarded cover to the replacement cover. NOTE: LCD control panel models only: Disconnect the control panel before removing the cover. Figure 5-681 Remove the cover (M507/E50145) 1 856 Chapter 5 Removal and replacement

18. Remove the paper delivery tray (output bin). NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. a. Release two tabs (callout 1), and then slide the cover toward the front of the printer (callout 2). Figure 5-682 Release two tabs 1 2 1 b. Remove the bin. Figure 5-683 Remove the bin 19. Remove the formatter case. Removal and replacement: Formatter case 857

a. M506/E50045/M507/E50145 only: Remove two screws (callout 1), and then remove the sheet metal plate (callout 2). NOTE: M507/E50145 only: The M507/E50145 sheet-metal plate includes a separate black plastic cable guide (not shown). Do not lose the guide when removing the plate. Figure 5-684 Remove the sheet-metal plate 2 1 b. Carefully pass all cables and wire harnesses through the opening in the formatter case. NOTE: A SFP printer is shown in this section. However, the procedure is correct for all printer models. Figure 5-685 Pass all cables and wire harnesses through the opening 858 Chapter 5 Removal and replacement

c. Remove one screw (callout 1), and then push down on one tab (callout 2) to release it. Figure 5-686 Remove one screw 1 2 d. Remove the guide. Figure 5-687 Remove the guide Removal and replacement: Formatter case 859

e. Remove four screws (callout 1). Figure 5-688 Remove four screws 1 f. Remove five screws (callout 1). Figure 5-689 Remove five screws 1 860 Chapter 5 Removal and replacement

g. Disconnect one connector (callout 1), and then move the guide out of the way (callout 2). Figure 5-690 Disconnect one connector 2 1 h. Slightly lift up the formatter case (callout 1), rotate the top of the case away from the chassis (callout 2), and then lift up the case to release it (callout 3). CAUTION: Pass the FFC through the opening (callout 4) in the formatter while removing the case. Figure 5-691 Release the formatter case 2 3 1 4 i. Remove the formatter case. NOTE: WiFi models only: If the formatter case is being replaced, make sure that the WiFi PCA and bracket (callout 1) are transferred to the replacement case. Removal and replacement: Formatter case 861

Figure 5-692 Remove the formatter case 1 20. Unpack the replacement assembly. a. Dispose of the defective part. NOTE: HP recommends responsible disposal of the defective part. <http://www8.hp.com/us/en/hp-information/environment/product-recycling.html> b. Unpack the replacement part from the packaging. CAUTION: Some parts are sensitive to electrostatic discharge (ESD). Always perform service work at an ESD-protected workstation or mat. If an ESD workstation or mat is not available, touch the sheet-metal chassis to provide a static ground before touching an ESD sensitive assembly. Protect the ESD-sensitive assemblies by placing them in ESD pouches when they are out of the printer. If the replacement part is a roller or pad, avoid touching the spongy part of it. Skin oils on the roller or pad can cause paper pickup and/or print-quality problems. HP recommends using disposable gloves when handling rollers or pads or washing your hands before touching rollers or pads. IMPORTANT: Make sure that all of the shipping materials (for example shipping tape) are removed from the replacement part prior to installation. c. To install an assembly, reverse the removal steps. NOTE: When applicable, special installation instructions are provided for an assembly at the end of the removal procedure. Always completely read the removal instructions and follow all special installation instructions. Removal and replacement: Fan (FM1) Learn how to remove and replace the fan (FM1). To view a short video of this procedure, click the link below. 862 Chapter 5 Removal and replacement

View a video of how to remove and replace the fan (FM1). Mean time to repair: 12 minutes Service level: Easy

Before performing service

Turn the printer power off

■ Disconnect the power cable. WARNING! To avoid damage to the printer, turn the printer off, wait 30 seconds, and then remove the power cord before attempting to service the printer. Use the table below to identify the correct part number for your printer. To order the part, go to www.hp.com/buy/parts. Table 5-37 Part information

Part number Part description

RK2-8068-000CN Fan (FM1)

Required tools

- Small flat-blade screwdriver
- #2 Phillips screwdriver with a magnetic tip and a 152 mm (6 in) shaft length

After performing service

Turn the printer power on

- Connect the power cable.
- Use the power switch to turn the power on.

Post service test

No post service test is available for this assembly. 1. Remove the tray. Removal and replacement: Fan (FM1) 863

a. Pull the tray straight out of the printer until it stops. Figure 5-693 Pull the tray out until it stops b. Lift the front of the tray, and then pull it out of the printer to remove it. NOTE: If the tray has Fixed Tray Guides installed and are still required, move the hardware to new tray. If necessary, order new kit: 3GY19-67901 Kit-Fixed Tray Guide. Only one kit required per engine. Figure 5-694 Release and remove the tray 2. Remove the cartridge door assembly. NOTE: If the toner cartridge was not removed prior to servicing the printer, remove it now. 864 Chapter 5 Removal and replacement