Atlas**Scientific**™
Environmental Robotics

V 5.4

Revised 7/20

EZO-DO™

Embedded Dissolved Oxygen Circuit

Reads	**Dissolved Oxygen**
Range	**0.01 – 100+ mg/L** **0.1 – 400+ % saturation**
Accuracy	**+/– 0.05 mg/L**
Response time	**1 reading per sec**
Supported probes	**Any galvanic probe**
Calibration	**1 or 2 point**
Temperature, salinity and pressure compensation	**Yes**
Data protocol	**UART & I²C**
Default I²C address	**97 (0x61)**
Operating voltage	**3.3V – 5V**
Data format	**ASCII**

RoHS COMPLIANT

PATENT PROTECTED

Written by Jordan Press
Designed by Noah Press

This is an evolving document, check back for updates.

STOP

SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.

This is sensitive electronic equipment. Get this device working in a solderless breadboard first. Once this device has been soldered it is no longer covered by our warranty.

This device has been designed to be soldered and can be soldered at any time. Once that decision has been made, Atlas Scientific no longer assumes responsibility for the device's continued operation. The embedded systems engineer is now the responsible party.

Get this device working in a solderless breadboard first!

Do not embed this device without testing it in a solderless breadboard!

r 0.1

Table of contents

Circuit dimensions 4
Power consumption 4
Absolute max ratings 4
Operating principle 5
Power and data isolation 6
Correct wiring 8
Calibration theory 9
Preserve calibration solution 12
Default state 13
Available data protocols 14

UART

UART mode 16
Receiving data from device 17
Sending commands to device 18
LED color definition 19
UART quick command page 20
LED control 21
Find 22
Continuous reading mode 23
Single reading mode 24
Calibration 25
Export calibration 26
Import calibration 27
Temperature compensation 28
Salinity compensation 29
Pressure compensation 30
Enable/disable parameters 31
Naming device 32
Device information 33
Response codes 34
Reading device status 35
Sleep mode/low power 36
Change baud rate 37
Protocol lock 38
Factory reset 39
Change to I²C mode 40
Manual switching to I²C 41

I²C

I²C mode 43
Sending commands 44
Requesting data 45
Response codes 46
LED color definition 47
I²C quick command page 48
LED control 49
Find 50
Taking reading 51
Calibration 52
Export calibration 53
Import calibration 54
Temperature compensation 55
Salinity compensation 56
Pressure compensation 57
Enable/disable parameters 58
Naming device 59
Device information 60
Reading device status 61
Sleep mode/low power 62
Protocol lock 63
I²C address change 64
Factory reset 65
Change to UART mode 66
Manual switching to UART 67

Circuit footprint 68
Datasheet change log 69
Warranty 73

 Copyright © Atlas Scientific LLC

EZO™ circuit dimensions

Power consumption

	LED	MAX	STANDBY	SLEEP
5V	ON	13.5 mA	13.1 mA	0.66 mA
	OFF	12.7 mA	12.7 mA	
3.3V	ON	12.1 mA	12 mA	0.3 mA
	OFF	11.9 mA	11.9 mA	

Absolute max ratings

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ D.O.)	-65 °C		125 °C
Operational temperature (EZO™ D.O.)	-40 °C	25 °C	85 °C
VCC	3.3V	5V	5.5V

Copyright © Atlas Scientific LLC

Operating principle

The Atlas Scientific™ EZO™ Dissolved Oxygen circuit works with:

✗ **Optical probe**	Slow response, requires external power, expensive.
✗ **Polar Graphic probe**	Requires external power, output in µA.
✓ **Galvanic probe**	Requires no external power, output in mV.

A galvanic dissolved oxygen probe consists of a PTFE membrane, an anode bathed in an electrolyte and a cathode. Oxygen molecules defuse through the probes membrane at a constant rate (without the membrane the reaction happens too quickly). Once the oxygen molecules have crossed the membrane they are reduced at the cathode and a small voltage is produced. If no oxygen molecules are present, the probe will output 0 mV. As the oxygen increases so does the mV output from the probe. Each probe will output a different voltage in the presence of oxygen. The only thing that is constant is that **0mV = 0 Oxygen**. (A galvanic dissolved oxygen probe can also be used to detect the Oxygen content in gases).

Flow Dependence

One of the drawbacks from using a galvanic probe is that it consumes a ***VERY*** small amount of the oxygen it reads. Therefore, a small amount of water movement is necessary to take accurate readings. **Approximately 60 ml/min**.

Copyright © Atlas Scientific LLC

Power and data isolation

The Atlas Scientific EZO™ Dissolved Oxygen circuit is a very sensitive device. This sensitivity is what gives the Dissolved Oxygen circuit its accuracy. This also means that the Dissolved Oxygen circuit is capable of reading micro-voltages that are bleeding into the water from unnatural sources such as pumps, solenoid valves or other probes/sensors.

When electrical noise is interfering with the Dissolved Oxygen readings it is common to see rapidly fluctuating readings or readings that are consistently off. To verify that electrical noise is causing inaccurate readings, place the Dissolved Oxygen probe in a cup of water by itself. The readings should stabilize quickly, confirming that electrical noise was the issue.

When reading Dissolved Oxygen and Conductivity together, it is ***strongly recommended*** that the EZO™ Dissolved Oxygen circuit is electrically isolated from the EZO™ Conductivity circuit.

Basic EZO™ Inline Voltage Isolator

Without isolation, Conductivity readings will effect Dissolved Oxygen accuracy.

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

This schematic shows exactly how we isolate data and power using the and a few passive components. The ADM3260 can output isolated power up to 150 mW and incorporates two bidirectional data channels.

This technology works by using tiny transformers to induce the voltage across an air gap. PCB layout requires special attention for EMI/EMC and RF Control, having proper ground planes and keeping the capacitors as close to the chip as possible are crucial for proper performance. The two data channels have a 4.7kΩ pull up resistor on both the isolated and non-isolated lines (R1, R2, R3, and R4) The output voltage is set using a voltage divider (R5, R6, and R7) this produces a voltage of 3.9V regardless of your input voltage.

Isolated ground is different from non-isolated ground, these two lines should not be connected together.

Copyright © Atlas Scientific LLC

Correct wiring

Bread board

Bread board via USB

Part # COM-104

Carrier board

Part # ISCCB

USB carrier board

Part # G2-USB-ISO

Electrically Isolated EZO™ Carrier Board

Part # ISCCB-2

X Incorrect wiring

Extended leads

Sloppy setup

Perfboards or Protoboards

NEVER
use Perfboards or Protoboards
Flux residue and shorting wires make it very hard to get accurate readings.

*Embedded into your device

***Only after you are familar with EZO™ circuits operation**

AtlasScientific™
Environmental Robotics
r 0.1

Copyright © Atlas Scientific LLC

Calibration theory

Simple calibration	Advanced calibration
UART mode	**I²C mode**
Continuous readings	Continuously request readings

The most important part of calibration is watching the readings during the calibration process.

It's easiest to calibrate the device in its default state (UART mode, with continuous readings enabled).

Switching the device to I²C mode after calibration ***will not*** affect the stored calibration. If the device must be calibrated in I²C mode be sure to ***continuously request readings*** so you can see the output from the probe.

The Atlas Scientific EZO™ Dissolved Oxygen circuit, has a flexible calibration protocol, allowing for ***single point*** or ***dual point (optional)*** calibration.

Calibrate first, compensate later.
Temperature, salinity and pressure compensation values have no effect on calibration.

Copyright © Atlas Scientific LLC

Single point calibration

Let the Dissolved Oxygen probe sit, exposed to air untill the readings stabalize. *(small movement from one reading to the next is normal).*

Once the readings have stabilized, issue the calibration command. **"cal"**

After calibration is complete, you should see readings between **9.09 – 9.1X mg/L.**
(only if temperature, salinity and pressure compensation are at default values)

 Copyright © Atlas Scientific LLC

Dual point calibration *(optional)*

Only perform this calibration if you require accurate readings *below* 1.0 mg/L

After you have calibrated the EZO™ Dissolved Oxygen circuit using the "Cal" command; Place the probe into the Zero Dissolved Oxygen calibration solution and stir the probe around to remove trapped air *(which could cause readings to go high)*. Let the probe sit in Zero D.O. calibration solution untill readings stabalize. *(small movement from one reading to the next is normal)*.

Once the readings have stabilized, issue the calibration command. **"cal,0"**

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

How to preserve the Zero D.O. calibration solution

Oxygen is everywhere. The Zero D.O. calibration solution has been designed to chemically absorb oxygen. Once the bottle has been opened the test solution has been exposed to oxygen and will slowly stop working.

Inside each bottle of the calibration solution is a small amount of nitrogen gas that helps displace oxygen out of the bottle during the filling process. When the Dissolved Oxygen probe is removed from the bottle, oxygen will enter the bottle and begin to dissolve into the solution.

In order slow down this process, fill the void space of the bottle with any gas *(other than oxygen)* to preserve the calibration solution. Gas from a lighter works great if other gases are currently unubtainable.

 Copyright © Atlas Scientific LLC

Default state

UART mode

Baud	9,600
Readings	continuous
Speed	1 reading per second
Temperature compensation	20 °C
Salinity compensation	0 (Fresh water)
Pressure compensation	101.3 kPa (Sea level)
LED	on

✓ Available data protocols

UART

Default

I²C

X Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

UART mode

Settings that are retained if power is cut

Baud rate
Calibration
Continuous mode
Device name
Enable/disable parameters
Enable/disable response codes
Hardware switch to I^2C mode
LED control
Protocol lock
Software switch to I^2C mode

Settings that are *NOT* retained if power is cut

Find
Pressure compensation
Salinity compensation
Sleep mode
Temperature compensation

AtlasScientific™
Environmental Robotics

UART mode

8 data bits	no parity
1 stop bit	no flow control

Baud
- 300
- 1,200
- 2,400
- **9,600 default**
- 19,200
- 38,400
- 57,600
- 115,200

RX
Data in

TX
Data out

Vcc 3.3V – 5.5V

Data format

Reading	Dissolved Oxygen	**Data type**	floating point
Units	mg/L & (% sat) when enabled	**Decimal places**	mg/L = 2 % sat = 1
Encoding	ASCII	**Smallest string**	4 characters
Format	string (CSV string when % sat is enabled)	**Largest string**	16 characters
Terminator	carriage return		

Copyright © Atlas Scientific LLC

Receiving data from device

2 parts

ASCII data string
Command

Carriage return <cr>
Terminator

Advanced

ASCII:	7	.	8	2	<cr>
Hex:	37	2E	38	32	0D
Dec:	55	46	56	50	13

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Sending commands to device

2 parts

Command (not case sensitive)

ASCII data string

Carriage return <cr>

Terminator

Advanced

ASCII:	S	l	e	e	p	<cr>
Hex:	53	6C	65	65	70	0D
Dec:	83	108	101	101	112	13

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

LED color definition

Green
UART standby

Cyan
Taking reading

Purple
Changing baud rate

Red
Command not understood

White
Find

	LED ON
5V	**+0.4 mA**
3.3V	**+0.2 mA**

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

UART mode
command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function		Default state
Baud	change baud rate	pg. 37	9,600
C	enable/disable continuous reading	pg. 23	enabled
Cal	performs calibration	pg. 25	n/a
Export	export calibration	pg. 26	n/a
Factory	enable factory reset	pg. 39	n/a
Find	finds device with blinking white LED	pg. 22	n/a
i	device information	pg. 33	n/a
I2C	change to I^2C mode	pg. 40	not set
Import	import calibration	pg. 27	n/a
L	enable/disable LED	pg. 21	enabled
Name	set/show name of device	pg. 32	not set
O	enable/disable parameters	pg. 31	mg/L
P	pressure compensation	pg. 30	101.3 kPa
Plock	enable/disable protocol lock	pg. 38	disabled
R	returns a single reading	pg. 24	n/a
S	salinity compensation	pg. 29	n/a
Sleep	enter sleep mode/low power	pg. 36	n/a
Status	retrieve status information	pg. 35	n/a
T	temperature compensation	pg. 28	20˚C
*OK	enable/disable response codes	pg. 34	enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example	Response
L,1 <cr>	*OK <cr>
L,0 <cr>	*OK <cr>
L,? <cr>	?L,1 <cr> or ?L,0 <cr> *OK <cr>

L,1

L,0

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Find

Command syntax

This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example	Response
Find <cr>	*OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Continuous reading mode

Command syntax

C,1 <cr> enable continuous readings once per second **default**

C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)

C,0 <cr> disable continuous readings

C,? <cr> continuous reading mode on/off?

Example	Response
C,1 <cr>	*OK <cr> DO (1 sec) <cr> DO (2 sec) <cr> DO (3 sec) <cr>
C,30 <cr>	*OK <cr> DO (30 sec) <cr> DO (60 sec) <cr> DO (90 sec) <cr>
C,0 <cr>	*OK <cr>
C,? <cr>	?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

Single reading mode

Command syntax

R <cr> **takes single reading**

Example	Response
R <cr>	7.82 <cr> *OK <cr>

Green
Standby

Cyan
Taking reading

Transmitting

600 ms

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Calibration

Command syntax

The EZO™ Dissolved Oxygen circuit uses single and/or two point calibration

Cal	<cr>	calibrate to atmospheric oxygen levels
Cal,0	<cr>	calibrate device to 0 dissolved oxygen
Cal,clear	<cr>	delete calibration data
Cal,?	<cr>	device calibrated?

Example	Response
Cal <cr>	*OK <cr>
Cal,0 <cr>	*OK <cr>
Cal,clear <cr>	*OK <cr>
Cal,? <cr>	?Cal,0 <cr> or ?Cal,1 <cr> (single point) or ?Cal,2 <cr> (two point) *OK <cr>

Copyright © Atlas Scientific LLC

Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,?	<cr>	calibration string info
Export	<cr>	export calibration string from calibrated device

Example	Response
Export,? <cr>	10,120 <cr>
Export <cr>	59 6F 75 20 61 72 <cr> (1 of 10)
Export <cr>	65 20 61 20 63 6F <cr> (2 of 10)
(7 more)	⋮
Export <cr>	6F 6C 20 67 75 79 <cr> (10 of 10)
Export <cr>	*DONE

Response breakdown

10, 120

↑ # of strings to export

↑ # of bytes to export

Export strings can be up to 12 characters long, and is always followed by <cr>

Disabling *OK simplifies this process

Export <cr>

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example	Response
Import, 59 6F 75 20 61 72 <cr> (1 of 10)	*OK <cr>
Import, 65 20 61 20 63 6F <cr> (2 of 10)	*OK <cr>
⋮	⋮
Import, 6F 6C 20 67 75 79 <cr> (10 of 10)	*OK <cr>

Import,n <cr>

*OK <cr>
system will reboot

*ER <cr>

*** If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.**

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.2

Temperature compensation

Command syntax

Default temperature = 20°C
Temperature is always in Celsius
Temperature is not retained if power is cut

T,n <cr> n = any value; floating point or int

T,? <cr> compensated temperature value?

RT,n <cr> set temperature compensation and take a reading*

This is a new command for firmware V2.13

Example	Response
T,19.5 <cr>	*OK <cr>
RT,19.5 <cr>	*OK <cr> 8.91 <cr>
T,? <cr>	?T,19.5 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.2

Salinity compensation

Command syntax

Default value = 0 µs
If the conductivity of your water is less than 2,500µS this command is irrelevant

S,n	<cr>	n = any value in microsiemens
S,n,ppt	<cr>	n = any value in ppt
S,?	<cr>	compensated salinity value?

Example	Response
S,50000 <cr>	*OK <cr>
S,37.5,ppt <cr>	*OK <cr>
S,? <cr>	?S,50000,µS <cr> or ?S,37.5,ppt <cr> *OK <cr>

Copyright © Atlas Scientific LLC

Pressure compensation

Command syntax

Default value = 101.3 kPa
This parameter can be omitted if the water is less than 10 meters deep

P,n <cr> n = any value in kPa

P,? <cr> compensated pressure value?

Example	Response
P,90.25 <cr>	*OK <cr>
P,? <cr>	?,P,90.25 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Enable/disable parameters from output string

Command syntax

O, [parameter],[1,0]	<cr>	enable or disable output parameter
O,?	<cr>	enabled parameter?

Example	Response
O,mg,1 / O,mg,0 <cr>	*OK <cr> enable / disable mg/L
O,%,1 / O,%,0 <cr>	*OK <cr> enable / disable percent saturation
O,? <cr>	?,O,%,mg <cr> if both are enabled

Parameters

mg	mg/L
%	percent saturation

Followed by 1 or 0

1	enabled
0	disabled

* If you disable all possible data types your readings will display "no output".

 Copyright © Atlas Scientific LLC

Naming device

Command syntax

Do not use spaces in the name

Name,n <cr> set name

Name,? <cr> show name

n = _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Up to 16 ASCII characters

Example	Response
Name,zzt <cr>	*OK <cr>
Name,? <cr>	?Name,zzt <cr> *OK <cr>

Name,zzt

*OK <cr>

Name,?

Name,zzt <cr>
*OK <cr>

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Device information

Command syntax

i <cr> device information

Example	Response
i <cr>	?i,D.O.,1.98 <cr> *OK <cr>

Response breakdown

?i,	D.O.,	1.98
	Device	Firmware

 Copyright © Atlas Scientific LLC

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example	Response
R <cr>	7.82 <cr> *OK <cr>
*OK,0 <cr>	no response, *OK disabled
R <cr>	7.82 <cr> *OK disabled
*OK,? <cr>	?*OK,1 <cr> or ?*OK,0 <cr>

Other response codes

*ER	unknown command
*OV	over volt (VCC>=5.5V)
*UV	under volt (VCC<=3.1V)
*RS	reset
*RE	boot up complete, ready
*SL	entering sleep mode
*WA	wake up

These response codes cannot be disabled

 Copyright © Atlas Scientific LLC

Reading device status

Command syntax

Status <cr> **voltage at Vcc pin and reason for last restart**

Example	Response
Status <cr>	?Status,P,5.038 <cr> *OK <cr>

Response breakdown

?Status,	P,	5.038
	Reason for restart	Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Copyright © Atlas Scientific LLC

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example	Response
Sleep <cr>	*OK <cr> *SL <cr>
Any command	*WA <cr> wakes up device

	STANDBY	SLEEP
5V	13.1 mA	0.66 mA
3.3V	12 mA	0.3 mA

Standby
13.1 mA

Sleep <cr>

Sleep
0.66 mA

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.2

Change baud rate

Command syntax

Baud,n <cr> **change baud rate**

Example	Response
Baud,38400 <cr>	*OK <cr>
Baud,? <cr>	?Baud,38400 <cr> *OK <cr>

n =
- 300
- 1200
- 2400
- **9600 default**
- 19200
- 38400
- 57600
- 115200

Standby

Baud,38400 <cr>

Changing baud rate

*OK <cr>

(reboot)

Standby

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr>	enable Plock	
Plock,0 <cr>	disable Plock	default
Plock,? <cr>	Plock on/off?	

Example	Response
Plock,1 <cr>	*OK <cr>
Plock,0 <cr>	*OK <cr>
Plock,? <cr>	?Plock,1 <cr> or ?Plock,0 <cr>

Plock,1

*OK <cr>

I2C,100

cannot change to I²C

*ER <cr>

Short

cannot change to I²C

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Factory reset

Command syntax

Clears calibration LED on "*OK" enabled

Factory <cr> enable factory reset

Example	Response
Factory <cr>	*OK <cr>

Factory <cr>

*OK <cr>

*RS <cr>
*RE <cr>

Baud rate will not change

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Change to I²C mode

Command syntax

Default I²C address 97 (0x61)

I2C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example	Response
I2C,100 <cr>	*OK (reboot in I²C mode)

Wrong example	Response
I2C,139 <cr> n ≯ 127	*ER <cr>

I2C,100

Green
*OK <cr>

Blue
now in I²C mode

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.2

Manual switching to I²C

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Green to Blue
- Disconnect ground (power off)
- Reconnect all data and power

Manually switching to I²C will set the I²C address to 97 (0x61)

Example

Wrong Example

Copyright © Atlas Scientific LLC

I²C mode

The I²C protocol is *considerably more complex* than the UART (RS–232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode click here

Settings that are retained if power is cut

Calibration
Change I²C address
Enable/disable parameters
Hardware switch to UART mode
LED control
Protocol lock
Software switch to UART mode

Settings that are *NOT* retained if power is cut

Find
Pressure compensation
Salinity compensation
Sleep mode
Temperature compensation

AtlasScientific™
Environmental Robotics

I²C mode

I²C address	(0x01 – 0x7F) 97 (0x61) default
Vcc	3.3V – 5.5V
Clock speed	100 – 400 kHz

SDA

SCL

Data format

Reading	Dissolved Oxygen	Data type	floating point
Units	mg/L & (% sat) when enabled	Decimal places	mg/L = 2 % sat = 1
Encoding	ASCII	Smallest string	4 characters
Format	string (CSV string when % sat is enabled)	Largest string	16 characters

Copyright © Atlas Scientific LLC

Sending commands to device

Example

Advanced

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Requesting data from device

Advanced

1	55	46	56	50	0	= 7.82
Dec	ASCII				Dec	

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.

Example

```
I2C_start;
I2C_address;
I2C_write(EZO_command);
I2C_stop;

delay(300);   Processing delay

I2C_start;
I2C_address;
Char[ ] = I2C_read;
I2C_stop;
```

The response code will always be 254, if you do not wait for the processing delay.

Response codes

Single byte, not string

255	no data to send
254	still processing, not ready
2	syntax error
1	successful request

Copyright © Atlas Scientific LLC

LED color definition

Blue	Green	Purple	Red	White
I²C standby	Taking reading	Changing I²C address	Command not understood	Find

	LED ON
5V	+0.4 mA
3.3V	+0.2 mA

Copyright © Atlas Scientific LLC

I²C mode
command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	change back to UART mode	pg. 66
Cal	performs calibration	pg. 52
Export	export calibration	pg. 53
Factory	enable factory reset	pg. 65
Find	finds device with blinking white LED	pg. 50
i	device information	pg. 60
I2C	change I²C address	pg. 64
Import	import calibration	pg. 54
L	enable/disable LED	pg. 49
Name	set/show name of device	pg. 59
O	removing parameters	pg. 58
P	pressure compensation	pg. 57
Plock	enable/disable protocol lock	pg. 63
R	returns a single reading	pg. 51
S	salinity compensation	pg. 56
Sleep	enter sleep mode/low power	pg. 62
Status	retrieve status information	pg. 61
T	temperature compensation	pg. 55

 Copyright © Atlas Scientific LLC

LED control

Command syntax

300ms processing delay

L,1	LED on	default
L,0	LED off	
L,?	LED state on/off?	

Example	Response
L,1	Wait 300ms; 1 (Dec) 0 (Null)
L,0	Wait 300ms; 1 (Dec) 0 (Null)
L,?	Wait 300ms; 1 (Dec) ?L,1 (ASCII) 0 (Null) or 1 (Dec) ?L,0 (ASCII) 0 (Null)

L,1

L,0

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Find

300ms processing delay

Command syntax

This command will disable continuous mode
Send any character or command to terminate find.

Find LED rapidly blinks white, used to help find device

Example	Response
Find	Wait 300ms; 1 (Dec); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Taking reading

Command syntax

600ms processing delay

R return 1 reading

Example	Response
R	Wait 600ms; 1 (Dec); 7.82 (ASCII); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Calibration

Command syntax

1300ms processing delay

Cal	calibrate to atmospheric oxygen levels
Cal,0	calibrate device to 0 dissolved oxygen
Cal,clear	delete calibration data
Cal,?	device calibrated?

The EZO™ Dissolved Oxygen circuit uses single and/or two point calibration

Example	Response
Cal	Wait 1300ms; 1 (Dec) 0 (Null)
Cal,0	Wait 1300ms; 1 (Dec) 0 (Null)
Cal,clear	Wait 300ms; 1 (Dec) 0 (Null)
Cal,?	Wait 300ms; 1 (Dec) ?Cal,0 (ASCII) 0 (Null) or 1 (Dec) ?Cal,1 (ASCII) 0 (Null) or 1 (Dec) ?Cal,2 (ASCII) 0 (Null)

Copyright © Atlas Scientific LLC

Export calibration

300ms processing delay

Command syntax

Export: Use this command to download calibration settings

Export,?	calibration string info
Export	export calibration string from calibrated device

Example	Response
Export,?	Wait 300ms — 1 (Dec) — 10,120 (ASCII) — 0 (Null)
Export	Wait 300ms — 1 (Dec) — 59 6F 75 20 61 72 (ASCII) — 0 (Null) — (1 of 10)
Export	Wait 300ms — 1 (Dec) — 65 20 61 20 63 6F (ASCII) — 0 (Null) — (2 of 10)
(7 more)	⋮
Export	Wait 300ms — 1 (Dec) — 6F 6C 20 67 75 79 (ASCII) — 0 (Null) — (10 of 10)
Export	Wait 300ms — 1 (Dec) — *DONE (ASCII) — 0 (Null)

Response breakdown

10, 120

10, ↑ # of strings to export

120 ↑ # of bytes to export

Export strings can be up to 12 characters long

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Import calibration

300ms processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example		Response		
Import, 59 6F 75 20 61 72	(1 of 10)	Wait 300ms	1 Dec	0 Null
Import, 65 20 61 20 63 6F	(2 of 10)	Wait 300ms	1 Dec	0 Null
⋮		⋮		
Import, 6F 6C 20 67 75 79	(10 of 10)	Wait 300ms	1 Dec	0 Null

Import,n

1 Dec | *Pending ASCII | 0 Null

system will reboot

reboot

*** If one of the imported strings is not correctly entered, the device will not accept the import and reboot.**

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Temperature compensation

Command syntax

Default temperature = 20°C
Temperature is always in Celsius
Temperature is not retained if power is cut

T,n	n = any value; floating point or int	300ms processing delay
T,?	compensated temperature value?	
RT,n	set temperature compensation and take a reading*	

This is a new command for firmware V2.13

Example	Response
T,19.5	Wait 300ms; 1 (Dec); 0 (Null)
RT,19.5	Wait 900ms; 1 (Dec); 8.91 (ASCII); 0 (Null)
T,?	Wait 300ms; 1 (Dec); ?T,19.5 (ASCII); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.2

Salinity compensation

Command syntax

300ms processing delay

S,n	n = any value in microsiemens	default
S,n,ppt	n = any value in ppt	
S,?	compensated salinity value?	

Example	Response
S,50000	Wait 300ms; 1 (Dec); 0 (Null)
S,37.5,ppt	Wait 300ms; 1 (Dec); 0 (Null)
S,?	Wait 300ms; 1 (Dec); ?S,50000,µS (ASCII); 0 (Null) or 1 (Dec); ?S,37.5,ppt (ASCII); 0 (Null)

If the conductivity of your water is less than 2,500µS this command is irrelevant

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Pressure compensation

Command syntax

300ms processing delay

P,n n = any value in kPa

P,? compensated pressure value?

This parameter can be omitted if the water is less than 10 meters deep

Example	Response
P,90.25	Wait 300ms; 1 (Dec); 0 (Null)
P,?	Wait 300ms; 1 (Dec); ?,P,90.25 (ASCII); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific Environmental Robotics

Enable/disable parameters from output string

Command syntax

300ms processing delay

O, [parameter],[1,0]	enable or disable output parameter
O,?	enabled parameter?

Example	Response
O,mg,1 / O,mg,0	Wait 300ms; 1 (Dec); 0 (Null); enable / disable mg/L
O,%,1 / O,%,0	Wait 300ms; 1 (Dec); 0 (Null); enable / disable percent saturation
O,?	Wait 300ms; 1 (Dec); ?,O,%,mg (ASCII); 0 (Null); if both are enabled

Parameters

mg	mg/L
%	percent saturation

Followed by 1 or 0

1	enabled
0	disabled

* If you disable all possible data types your readings will display "no output".

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Naming device

300ms processing delay

Command syntax

Do not use spaces in the name

Name,n	set name	n = _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16)
Name,?	show name	Up to 16 ASCII characters

Example	Response
Name,zzt	Wait 300ms; 1 (Dec); 0 (Null)
Name,?	Wait 300ms; 1 (Dec); ?Name,zzt (ASCII); 0 (Null)

Name,zzt

1 0

Name,?

1 ?Name,zzt 0

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Device information

Command syntax

300ms processing delay

i device information

Example	Response
i	Wait 300ms; 1 (Dec); ?i,D.O.,1.98 (ASCII); 0 (Null)

Response breakdown

?i, D.O., 1.98

D.O. ↑ Device

1.98 ↑ Firmware

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Reading device status

Command syntax

300ms processing delay

Status voltage at Vcc pin and reason for last restart

Example	Response			
Status	Wait 300ms	1	?Status,P,5.038	0
		Dec	ASCII	Null

Response breakdown

?Status,	P,	5.038
	Reason for restart	Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Sleep mode/low power

Command syntax

Sleep	enter sleep mode/low power

Send any character or command to awaken device.

Example	Response
Sleep	no response
Any command	wakes up device

Do not read status byte after issuing sleep command.

	STANDBY	SLEEP
5V	13.1 mA	0.66 mA
3.3V	12 mA	0.3 mA

Standby

Sleep

Sleep

 Copyright © Atlas Scientific LLC

Protocol lock

Command syntax

300ms processing delay

Locks device to I²C mode.

Plock,1	enable Plock	
Plock,0	disable Plock	default
Plock,?	Plock on/off?	

Example	Response
Plock,1	Wait 300ms; 1 (Dec); 0 (Null)
Plock,0	Wait 300ms; 1 (Dec); 0 (Null)
Plock,?	Wait 300ms; 1 (Dec); ?Plock,1 (ASCII); 0 (Null)

Plock,1

Baud, 9600

cannot change to UART

cannot change to UART

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

I²C address change

Command syntax

300ms processing delay

I2C,n sets I²C address and reboots into I²C mode

Example	Response
I2C,100	device reboot

Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until your CPU is updated with the new I²C address.

Default I²C address is 97 (0x61).

n = any number 1 – 127

I2C,100

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory	enable factory reset

I²C address will not change

Example	Response
Factory	device reboot

Clears calibration
LED on
Response codes enabled

Factory

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Change to UART mode

Command syntax

Baud,n switch from I²C to UART

Example	Response
Baud,9600	reboot in UART mode

n =
- 300
- 1200
- 2400
- 9600
- 19200
- 38400
- 57600
- 115200

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PGND
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power

Example

Wrong Example

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

EZO™ circuit footprint

1 In your CAD software place a 8 position header.

2 Place a 3 position header at both top and bottom of the 8 position.

3 Delete the 8 position header. The two 3 position headers are now 17.78mm (0.7”) apart from each other.

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Datasheet change log

Datasheet V 5.4

Revised artwork within datasheet.

Datasheet V 5.3

Moved Default state to pg 13.

Datasheet V 5.2

Updated firmware changes on page 70.

Datasheet V 5.1

Revised response for the sleep command in UART mode on pg 36.

Datasheet V 5.0

Revised calibration theory on page 9, and added more information on the Export calibration and Import calibration commands.

Datasheet V 4.9

Corrected temperature compensation typo on pages 26 & 52.

Datasheet V 4.8

Revised isolation schematic on pg. 10

Datasheet V 4.7

Added new command:
"RT,n" for Temperature compensation located on pages 26 (UART) & 52 (I^2C).
Added firmware information to Firmware update list.

 Copyright © Atlas Scientific LLC

Datasheet V 4.6

Added more information about temperature compensation on pages 26 & 52.

Datasheet V 4.5

Changed "Max rate" to "Response time" on cover page.

Datasheet V 4.4

Removed note from certain commands about firmware version.

Datasheet V 4.3

Added information to calibration theory on pg 7.

Datasheet V 4.2

Revised definition of response codes on pg 44.

Datasheet V 4.1

Updated firmware changes on pg. 66.

Datasheet V 4.0

Revised Enable/disable parameters information on pages 29 (UART) & 55 (I^2C).

Datasheet V 3.9

Revised information on cover page.

Datasheet V 3.8

Update firmware changes on pg. 66.

Datasheet V 3.7

Revised Plock pages to show default value.

 Copyright © Atlas Scientific LLC

Datasheet change log

Datasheet V 3.6

Added new commands:
"Find" pages 21 (UART) & 48 (I^2C).
"Export/Import calibration" pages 25 (UART) & 51 (I^2C).
Added new feature to continous mode "C,n" pg 22.

Datasheet V 3.5

Added accuracy range on cover page, and revised isolation info on pg. 10.

Datasheet V 3.4

Added manual switching to UART information on pg. 59.

Datasheet V 3.3

Updated firmware changes to refeclt V1.99 update.

Datasheet V 3.2

Revised entire datasheet.

 Copyright © Atlas Scientific LLC

Firmware updates

V1.1 – Initial release (Oct 30, 2014)
- Change output to mg/L, then percentage (was previously percentage, then mg/L).

V1.5 – Baud rate change (Nov 6, 2014)
- Change default baud rate to 9600

V1.6 – I^2C bug (Dec 1, 2014)
- Fixed I^2C bug where the circuit may inappropriately respond when other I^2C devices are connected.

V1.7 – Factory (April 14, 2015)
- Changed "X" command to "Factory"

V1.95 – Plock (March 31, 2016)
- Added protocol lock feature "Plock"

V1.96 – EEPROM (April 26, 2016)
- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup.

V1.97 – EEPROM (Oct 10, 2016)
- Fixed bug in the cal clear command, improves how it calculates the DO, adds calibration saving and loading.

V1.98 – EEPROM (Nov 14, 2016)
- Updated firmware for new circuit design.

V1.99 – (Feb 2, 2017)
- Revised "O" command to accept mg.

V2.10 – (April 12, 2017)
- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.

V2.11 – (Sept 28, 2017)
- Fixed bug where the temperature would default to 0 on startup.

V2.12 – (Dec 19, 2017)
- Improved accuracy of dissolved oxygen equations.

V2.13 – (July 16, 2018)
- Added "RT" command to Temperature compensation.

V2.14 – (June 7, 2019)
- Fixed bug where the output buffer overflows when the cal and cal,0 point are too close together.

Warranty

Atlas Scientific™ Warranties the EZO™ class Dissolved Oxygen circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™class Dissolved Oxygen circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class Dissolved Oxygen circuit is inserted into a bread board, or shield. If the EZO™ class Dissolved Oxygen circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class Dissolved Oxygen circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class Dissolved Oxygen circuit exclusively and output the EZO™ class Dissolved Oxygen circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class Dissolved Oxygen circuit warranty:

- **Soldering any part of the EZO™ class Dissolved Oxygen circuit.**
- **Running any code, that does not exclusively drive the EZO™ class Dissolved Oxygen circuit and output its data in a serial string.**
- **Embedding the EZO™ class Dissolved Oxygen circuit into a custom made device.**
- **Removing any potting compound.**

 Copyright © Atlas Scientific LLC

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class Dissolved Oxygen circuit, against the thousands of possible variables that may cause the EZO™ class Dissolved Oxygen circuit to no longer function properly.

Please keep this in mind:

1. **All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**

2. **All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**

3. **All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class Dissolved Oxygen circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.

 Copyright © Atlas Scientific LLC