Atlas**Scientific**™
Environmental Robotics

V 3.4

Revised 1/20

EZO-RTD™

Embedded Temperature Circuit

Reads	**Temperature**
Range	**-126.000 °C – 1254 °C**
Resolution	**0.001**
Accuracy	**+/– (0.1 + 0.0017 x ˚C)**
Response time	**1 reading per sec**
Supported probes	**Any type & brand PT-100 or PT-1000 RTD**
Calibration	**Single point**
Temperature output	**°C, °K, or °F**
Data protocol	**UART & I²C**
Default I²C address	**102 (0x66)**
Operating voltage	**3.3V – 5.5V**
Data format	**ASCII**
Onboard Data Logger	**50 Readings**

Electrical Isolation not needed

Written by Jordan Press
Designed by Noah Press

This is an evolving document, check back for updates.

STOP

SOLDERING THIS DEVICE VOIDS YOUR WARRANTY.

This is sensitive electronic equipment. Get this device working in a solderless breadboard first. Once this device has been soldered it is no longer covered by our warranty.

This device has been designed to be soldered and can be soldered at any time. Once that decision has been made, Atlas Scientific no longer assumes responsibility for the device's continued operation. The embedded systems engineer is now the responsible party.

Get this device working in a solderless breadboard first!

Do not embed this device without testing it in a solderless breadboard!

r 0.1

Table of contents

Circuit dimensions 4
Power consumption 4
Absolute max ratings 4
Temperature circuit range 5
Temperature circuit accuracy 5
Atlas Scientific PT-1000 probe 6
Using other brand PT-100/PT-1000 7
Operating principle 8
Correct wiring 10
Calibration theory 11
On board data logger 12
Default state 13
Available data protocols 14

UART

UART mode 16
Receiving data from device 17
Sending commands to device 18
LED color definition 19
UART quick command page 20
LED control 21
Find 22
Continuous reading mode 23
Single reading mode 24
Calibration 25
Export calibration 26
Import calibration 27
Temperature scale 28
Enable/disable data logger 29
Memory recall 30
Memory clear 31
Naming device 32
Device information 33
Response codes 34
Reading device status 35
Sleep mode/low power 36
Change baud rate 37
Protocol lock 38
Factory reset 39
Change to I²C mode 40
Manual switching to I²C 41

I²C

I²C mode 43
Sending commands 44
Requesting data 45
Response codes 46
LED color definition 47
I²C quick command page 48
LED control 49
Find 50
Taking reading 51
Calibration 52
Export calibration 53
Import calibration 54
Temperature scale 55
Enable/disable data logger 56
Memory recall 57
Memory clear 58
Naming device 59
Device information 60
Reading device status 61
Sleep mode/low power 62
Protocol lock 63
I²C address change 64
Factory reset 65
Change to UART mode 66
Manual switching to UART 67

Circuit footprint 68
Datasheet change log 69
Warranty 71

EZO™ circuit dimensions

Power consumption

	LED	MAX	STANDBY	SLEEP
5V	ON	16 mA	15.4 mA	0.4 mA
	OFF	15.3 mA	15 mA	
3.3V	ON	14.3 mA	13.8 mA	0.09 mA
	OFF	14 mA	13.6 mA	

Absolute max ratings

Parameter	MIN	TYP	MAX
Storage temperature (EZO™ RTD)	-65 °C		125 °C
Operational temperature (EZO™ RTD)	-40 °C	25 °C	85 °C
VCC	3.3V	5V	5.5V

Copyright © Atlas Scientific LLC

EZO™ RTD temperature sensing range

EZO™ RTD temperature sensing accuracy

Copyright © Atlas Scientific LLC

Atlas Scientific PT-1000 probe

- Accuracy +/- (0.15 + (0.002*t))
- Probe type: class A platinum, RTD
- Cable length: 81cm (32")
- Cable material: silicone rubber
- 30mm sensing area (304 SS)
- 6mm diameter
- BNC connector
- Reaction time: 90% value in 13 seconds
- Probe output: analog
- Full sensing range -200 °C to 850 °C
- Cable max temp 125 °C
- Cable min temp -55 °C

The Atlas Scientific EZO™ RTD Temperature circuit only works with PT-100 and PT-1000 probes.

To read temperatures above, or below the max cable temperature, an additional probe housing (thermowell) is needed to protect the cable.

100mm Temperature Thermowell

50mm Temperature Thermowell

30mm Temperature Thermowell

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Using other brand PT-100/PT-1000

The EZO™ RTD Temperature circuit will auto-detect if the connected probe is PT-100 or PT-1000.

Probe class	Accuracy
AA	+/- (0.1 + 0.0017 × ˚C)
A	+/- (0.15 + 0.002 × ˚C)
B	+/-(0.3 + 0.005 × ˚C)
C	+/- (0.6 + 0.01 × ˚C)

It makes no difference which lead of the temperature probe is connected to the two probe pins.

Copyright © Atlas Scientific LLC

Operating principle

The Atlas Scientific EZO™ RTD Temperature circuit is a small footprint computer system that is specifically designed to be used in robotic applications where the embedded systems engineer requires accurate and precise measurements of temperature through a generic PT-100/PT-1000 temperature probe.

RTD = Resistance Temperature Detector
PT = Platinum
PT-100 = 100 Ω at 0˚C
PT-1000 = 1k Ω at 0˚C

Unlike any other material, platinums correlation between resistance and temperature seems to be woven into the fabric of the universe. It is for this reason, that the platinum RTD temperature sensor is the industrial standard for temperature measurement.

Copyright © Atlas Scientific LLC

Power and data isolation

ELECTRICAL ISOLATION IS *NOT* NEEDED.

Copyright © Atlas Scientific LLC

Correct wiring

Carrier board

USB carrier board

Bread board

Bread board via USB

Electrically Isolated EZO™ Carrier Board

Incorrect wiring

Extended leads

Sloppy setup

Perfboards or Protoboards

*Embedded into your device

NEVER
use Perfboards or Protoboards
Flux residue and shorting wires make it very hard to get accurate readings.

***Only after you are familar with EZO™ circuits operation**

AtlasScientific™
Environmental Robotics
r 0.1

Copyright © Atlas Scientific LLC

Calibration theory

The most important part of calibration is watching the readings during the calibration process. It's easiest to calibrate the device in its default state (UART mode, continuous readings). Switching the device to I²C mode after calibration ***will not*** affect the stored calibration. If the device must be calibrated in I²C mode be sure to request readings continuously so you can see the output from the probe.

Calibration can be done at any value, a simple method is to calibrate the probe in boiling water.

100 °C

Atlas Scientific recommends calibration be done every three years.

Elevation and boiling point table

Elevation in meters	Boiling point
305	98.9 °C
229	99.2 °C
152	99.5 °C
76	99.7 °C
0	100 °C
-76	100.3 °C
-152	100.5 °C

Use purified/distilled water

For accurate calibration using different temperature vaules, you must use a tool called a *"dry block calibrator."*

 Copyright © Atlas Scientific LLC

On board data logger

- 50 readings
- Programmable storage interval

Minimum – 10 seconds
Maximum – 320,000 seconds

Temperature readings that are stored to the data logger will be retained even if the power is cut.

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Default state

UART mode

Baud	9,600
Temperature	°C
Readings	continuous
Speed	1 reading per second
With probe	ttt.ttt
Without probe	-1023.000
LED	on

✓ Available data protocols

UART

Default

I²C

X Unavailable data protocols

SPI

Analog

RS-485

Mod Bus

4–20mA

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

UART mode

Settings that are retained if power is cut

Baud rate
Calibration
Continuous mode
Temperature scale
Device name
Enable/disable response codes
Hardware switch to I^2C mode
LED control
Protocol lock
Software switch to I^2C mode

Settings that are *NOT* retained if power is cut

Find
Sleep mode

UART mode

8 data bits	no parity
1 stop bit	no flow control

Baud
- 300
- 1,200
- 2,400
- **9,600 default**
- 19,200
- 38,400
- 57,600
- 115,200

RX
Data in

TX
Data out

Vcc 3.3V – 5.5V

Data format

Reading	temperature	**Data type**	floating point
Units	°C, °K, or °F	**Decimal places**	3
Encoding	ASCII	**Smallest string**	4 characters
Format	string	**Largest string**	40 characters
Terminator	carriage return		

Copyright © Atlas Scientific LLC

Receiving data from device

2 parts

ASCII data string
Command

Carriage return <cr>
Terminator

Advanced

ASCII:	2	5	.	1	0	4	<cr>
Hex:	32	35	2E	31	30	34	0D
Dec:	50	53	46	49	48	52	13

Copyright © Atlas Scientific LLC

Sending commands to device

2 parts

Command (not case sensitive)

ASCII data string

Carriage return <cr>

Terminator

Advanced

ASCII:	S	l	e	e	p	<cr>
Hex:	53	6C	65	65	70	0D
Dec:	83	108	101	101	112	13

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

LED color definition

Green
UART standby

Cyan
Taking reading

Purple
Changing baud rate

Red
Command not understood

White
Find

	LED ON
5V	**+0.4 mA**
3.3V	**+0.2 mA**

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.2

UART mode
command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function		Default state
Baud	change baud rate	pg. 37	9,600
C	enable/disable continuous reading	pg. 23	enabled
Cal	performs calibration	pg. 25	n/a
D	enable/disable data logger	pg. 29	disabled
Export	export calibration	pg. 26	n/a
Factory	enable factory reset	pg. 39	n/a
Find	finds device with blinking white LED	pg. 22	n/a
i	device information	pg. 33	n/a
I2C	change to I^2C mode	pg. 40	not set
Import	import calibration	pg. 27	n/a
L	enable/disable LED	pg. 21	enabled
M	memory recall/clear	pg. 30	n/a
Name	set/show name of device	pg. 32	not set
Plock	enable/disable protocol lock	pg. 38	disabled
R	returns a single reading	pg. 24	n/a
S	temperature scale (°C, °K, °F)	pg. 28	celsius
Sleep	enter sleep mode/low power	pg. 36	n/a
Status	retrieve status information	pg. 35	n/a
*OK	enable/disable response codes	pg. 34	enable

LED control

Command syntax

L,1 <cr> LED on **default**

L,0 <cr> LED off

L,? <cr> LED state on/off?

Example	Response
L,1 <cr>	*OK <cr>
L,0 <cr>	*OK <cr>
L,? <cr>	?L,1 <cr> or ?L,0 <cr> *OK <cr>

L,1

L,0

 Copyright © Atlas Scientific LLC

Find

Command syntax

This command will disable continuous mode
Send any character or command to terminate find.

Find <cr> LED rapidly blinks white, used to help find device

Example	Response
Find <cr>	*OK <cr>

 Copyright © Atlas Scientific LLC

Continuous reading mode

Command syntax

C,1 <cr> enable continuous readings once per second **default**

C,n <cr> continuous readings every n seconds (n = 2 to 99 sec)

C,0 <cr> disable continuous readings

C,? <cr> continuous reading mode on/off?

Example	Response
C,1 <cr>	*OK <cr> °C (1 sec) <cr> °C (2 sec) <cr> °C (n sec) <cr>
C,30 <cr>	*OK <cr> °C (30 sec) <cr> °C (60 sec) <cr> °C (90 sec) <cr>
C,0 <cr>	*OK <cr>
C,? <cr>	?C,1 <cr> or ?C,0 <cr> or ?C,30 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

Single reading mode

Command syntax

R <cr> **takes single reading**

Example	Response
R <cr>	25.104 <cr> *OK <cr>

Green
Standby

Cyan
Taking reading

Transmitting

600 ms

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Calibration

Command syntax

The EZO™ RTD circuit uses single point calibration.

Cal,t	<cr>	t = any temperature
Cal,clear	<cr>	delete calibration data
Cal,?	<cr>	device calibrated?

Example	Response
Cal,100.00 <cr>	*OK <cr>
Cal,clear <cr>	*OK <cr>
Cal,? <cr>	?Cal,1 <cr> or ?Cal,0 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Export calibration

Command syntax

Export: Use this command to download calibration settings

Export,?	<cr>	calibration string info
Export	<cr>	export calibration string from calibrated device

Example	Response
Export,? <cr>	10,120 <cr>
Export <cr>	59 6F 75 20 61 72 <cr> (1 of 10)
Export <cr>	65 20 61 20 63 6F <cr> (2 of 10)
(7 more)	⋮
Export <cr>	6F 6C 20 67 75 79 <cr> (10 of 10)
Export <cr>	*DONE

Response breakdown

10, 120

10, ↑ # of strings to export

120 ↑ # of bytes to export

Export strings can be up to 12 characters long, and is always followed by <cr>

Disabling *OK simplifies this process

Export <cr>

*DONE

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Import calibration

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n <cr> import calibration string to new device

Example	Response
Import, 59 6F 75 20 61 72 <cr> (1 of 10)	*OK <cr>
Import, 65 20 61 20 63 6F <cr> (2 of 10)	*OK <cr>
⋮	⋮
Import, 6F 6C 20 67 75 79 <cr> (10 of 10)	*OK <cr>

Import,n <cr>

*OK <cr>
system will reboot

*ER <cr>

*** If one of the imported strings is not correctly entered, the device will not accept the import, respond with *ER and reboot.**

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.2

Temperature scale (°C, °K, °F)

Command syntax

S,c <cr> celsius **default**
S,k <cr> kelvin
S,f <cr> fahrenheit
S,? <cr> temperature scale?

Example	Response
S,c <cr>	*OK <cr>
S,k <cr>	*OK <cr>
S,f <cr>	*OK <cr>
S,? <cr>	?S,c <cr> or ?S,k <cr> or ?S,f <cr> *OK <cr>

Copyright © Atlas Scientific LLC
AtlasScientific Environmental Robotics

Enable/disable data logger

Command syntax

The time period (n) is in 10 second intervals and can be any value from 1 to 32,000.

D,n <cr> n = (n x 10 seconds)

D,0 <cr> disable **default**

D,? <cr> data logger storage interval?

Example	Response
D,6 <cr>	*OK <cr>
D,0 <cr>	*OK <cr>
D,? <cr>	?D,6 <cr> *OK <cr>

D,6

60 seconds

* <cr>

* indicates reading has been logged

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Memory recall

Command syntax

Disable data logger to recall memory.

M	<cr>	recall 1 sequential stored reading
M,all	<cr>	recall all readings in a CSV string
M,?	<cr>	display memory location of last stored reading

Example	Response
M <cr>	1,100.00 <cr> 2,104.00 <cr> *OK <cr>
M,all <cr>	100.00,104.00,108.00,112.00 <cr> Oldest Newest
M,? <cr>	?M,4 <cr> *OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Memory clear

Command syntax

M,clear <cr> clear all stored memory

Example	Response
M,clear <cr>	*OK <cr>

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Naming device

Command syntax

Name,n <cr> set name

Name,? <cr> show name

n = _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _

1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16

Up to 16 ASCII characters

Example	Response
Name,zzt <cr>	*OK <cr>
Name,? <cr>	?Name,zzt <cr> *OK <cr>

Name,zzt

*OK <cr>

Name,?

Name,zzt <cr>
*OK <cr>

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Device information

Command syntax

i <cr> device information

Example	Response
i <cr>	?i,RTD,2.01 <cr> *OK <cr>

Response breakdown

?i,	RTD,	2.01
	↑ Device	↑ Firmware

 Copyright © Atlas Scientific LLC

Response codes

Command syntax

*OK,1 <cr> enable response **default**
*OK,0 <cr> disable response
*OK,? <cr> response on/off?

Example	Response
R <cr>	25.104 <cr> *OK <cr>
*OK,0 <cr>	no response, *OK disabled
R <cr>	25.104 <cr> *OK disabled
*OK,? <cr>	?*OK,1 <cr> or ?*OK,0 <cr>

Other response codes

*ER	unknown command
*OV	over volt (VCC>=5.5V)
*UV	under volt (VCC<=3.1V)
*RS	reset
*RE	boot up complete, ready
*SL	entering sleep mode
*WA	wake up

These response codes cannot be disabled

 Copyright © Atlas Scientific LLC

Reading device status

Command syntax

Status <cr> **voltage at Vcc pin and reason for last restart**

Example	Response
Status <cr>	?Status,P,5.038 <cr> *OK <cr>

Response breakdown

?Status,	P,	5.038
	↑ Reason for restart	↑ Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

 Copyright © Atlas Scientific LLC

Sleep mode/low power

Command syntax

Send any character or command to awaken device.

Sleep <cr> enter sleep mode/low power

Example	Response
Sleep <cr>	*OK <cr> *SL <cr>
Any command	*WA <cr> wakes up device

	STANDBY	SLEEP
5V	15.40 mA	0.4 mA
3.3V	13.80 mA	0.09 mA

Standby
15.40 mA

Sleep <cr>

Sleep
3.00 mA

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Change baud rate

Command syntax

Baud,n <cr> **change baud rate**

Example	Response
Baud,38400 <cr>	*OK <cr>
Baud,? <cr>	?Baud,38400 <cr> *OK <cr>

n =
- 300
- 1200
- 2400
- **9600 default**
- 19200
- 38400
- 57600
- 115200

Standby

Baud,38400 <cr>

Changing baud rate

*OK <cr>

(reboot)

Standby

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Protocol lock

Command syntax

Locks device to UART mode.

Plock,1 <cr>	enable Plock	
Plock,0 <cr>	disable Plock	default
Plock,? <cr>	Plock on/off?	

Example	Response
Plock,1 <cr>	*OK <cr>
Plock,0 <cr>	*OK <cr>
Plock,? <cr>	?Plock,1 <cr> or ?Plock,0 <cr>

Plock,1

*OK <cr>

I2C,100

cannot change to I²C

*ER <cr>

Short

cannot change to I²C

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Factory reset

Clears calibration
LED on
"*OK" enabled
Clears data logger

Command syntax

Factory <cr> enable factory reset

Example	Response
Factory <cr>	*OK <cr>

Factory <cr>

*OK <cr>

*RS <cr>
*RE <cr>

Baud rate will not change

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Change to I²C mode

Command syntax

Default I²C address 102 (0x66)

I2C,n <cr> sets I²C address and reboots into I²C mode

n = any number 1 – 127

Example	Response
I2C,100 <cr>	*OK (reboot in I²C mode)

Wrong example	Response
I2C,139 <cr> n ≯ 127	*ER <cr>

I2C,100

Green
*OK <cr>

Blue
now in I²C mode

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.2

Manual switching to I²C

Connecting TX to PRB only works for the EZO-RTD™ and the EZO-FLO™ circuits

Manually switching to I²C will set the I²C address to 102 (0x66)

Example

Wrong Example

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

I²C mode

The I²C protocol is *considerably more complex* than the UART (RS–232) protocol. Atlas Scientific assumes the embedded systems engineer understands this protocol.

To set your EZO™ device into I²C mode click here

Settings that are retained if power is cut

Calibration
Change I²C address
Temperature scale
Hardware switch to UART mode
LED control
Protocol lock
Software switch to UART mode

Settings that are *NOT* retained if power is cut

Find
Sleep mode

AtlasScientific™
Environmental Robotics
r 0.2

I²C mode

I²C address	(0x01 – 0x7F) **102 (0x66) default**
Vcc	3.3V – 5.5V
Clock speed	100 – 400 kHz

SDA

SCL

Data format

Reading	temperature	Data type	floating point
Units	°C, °K, or °F	Decimal places	3
Encoding	ASCII	Smallest string	4 characters
Format	string	Largest string	40 characters

Copyright © Atlas Scientific LLC

Sending commands to device

Example

Advanced

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Requesting data from device

Advanced

1	50	53	46	49	48	52	0	= 25.104
Dec	ASCII						Dec	

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Response codes

After a command has been issued, a 1 byte response code can be read in order to confirm that the command was processed successfully.

Reading back the response code is completely optional, and is not required for normal operation.

Example

```
I2C_start;
I2C_address;
I2C_write(EZO_command);
I2C_stop;
```

delay(300); → **Processing delay**

```
I2C_start;
I2C_address;
Char[ ] = I2C_read;
I2C_stop;
```

If there is no processing delay or the processing delay is too short, the response code will always be 254.

Response codes

Single byte, not string

255	no data to send
254	still processing, not ready
2	syntax error
1	successful request

 Copyright © Atlas Scientific LLC

LED color definition

Blue	Green	Purple	Red	White
I²C standby	Taking reading	Changing I²C address	Command not understood	Find

	LED ON
5V	+0.4 mA
3.3V	+0.2 mA

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

I²C mode
command quick reference

All commands are ASCII strings or single ASCII characters.

Command	Function	
Baud	switch back to UART mode	pg. 66
Cal	performs calibration	pg. 52
D	enable/disable data logger	pg. 56
Export	export calibration	pg. 53
Factory	enable factory reset	pg. 65
Find	finds devices with white blinking LED	pg. 50
i	device information	pg. 60
I2C	change I²C address	pg. 64
Import	import calibration	pg. 54
L	enable/disable LED	pg. 49
M	memory recall/clear	pg. 57
Name	set/show name of device	pg. 59
Plock	enable/disable protocol lock	pg. 63
R	returns a single reading	pg. 51
S	temperature scale (°C, °K, °F)	pg. 55
Sleep	enter sleep mode/low power	pg. 62
Status	retrieve status information	pg. 61

 Copyright © Atlas Scientific LLC

LED control

Command syntax

300ms processing delay

L,1	LED on	default
L,0	LED off	
L,?	LED state on/off?	

Example	Response
L,1	Wait 300ms; 1 (Dec) 0 (Null)
L,0	Wait 300ms; 1 (Dec) 0 (Null)
L,?	Wait 300ms; 1 (Dec) ?L,1 (ASCII) 0 (Null) or 1 (Dec) ?L,0 (ASCII) 0 (Null)

L,1

L,0

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Find

300ms processing delay

Command syntax

This command will disable continuous mode
Send any character or command to terminate find.

Find	**LED rapidly blinks white, used to help find device**

Example	Response
Find <cr>	Wait 300ms 1 Dec 0 Null

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Taking reading

Command syntax

600ms processing delay

R return 1 reading

Example	Response
R	Wait 600ms; 1 (Dec); 25.104 (ASCII); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics
r 0.1

Calibration

Command syntax

600ms processing delay

Cal,t	t = any temperature
Cal,clear	delete calibration data
Cal,?	device calibrated?

EZO™ RTD circuit uses single point calibration.

Example	Response
Cal,t	Wait 600ms; 1 (Dec) 0 (Null)
Cal,clear	Wait 300ms; 1 (Dec) 0 (Null)
Cal,?	Wait 300ms; 1 (Dec) ?Cal,1 (ASCII) 0 (Null) or 1 (Dec) ?Cal,0 (ASCII) 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Export calibration

300ms processing delay

Command syntax

Export: Use this command to download calibration settings

Export,?	calibration string info
Export	export calibration string from calibrated device

Example	Response
Export,?	Wait 300ms — 1 (Dec) — 10,120 (ASCII) — 0 (Null)
Export	Wait 300ms — 1 (Dec) — 59 6F 75 20 61 72 (ASCII) — 0 (Null) — (1 of 10)
Export	Wait 300ms — 1 (Dec) — 65 20 61 20 63 6F (ASCII) — 0 (Null) — (2 of 10)
(7 more)	⋮
Export	Wait 300ms — 1 (Dec) — 6F 6C 20 67 75 79 (ASCII) — 0 (Null) — (10 of 10)
Export	Wait 300ms — 1 (Dec) — *DONE (ASCII) — 0 (Null)

Response breakdown

10, 120

10 ↑ # of strings to export

120 ↑ # of bytes to export

Export strings can be up to 12 characters long

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Import calibration

300ms processing delay

Command syntax

Import: Use this command to upload calibration settings to one or more devices.

Import,n import calibration string to new device

Example		Response		
Import, 59 6F 75 20 61 72	(1 of 10)	Wait 300ms	1 Dec	0 Null
Import, 65 20 61 20 63 6F	(2 of 10)	Wait 300ms	1 Dec	0 Null
⋮		⋮		
Import, 6F 6C 20 67 75 79	(10 of 10)	Wait 300ms	1 Dec	0 Null

*** If one of the imported strings is not correctly entered, the device will not accept the import and reboot.**

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Temperature scale (°C, °K, °F)

Command syntax

300ms processing delay

S,c	celsius	default
S,k	kelvin	
S,f	fahrenheit	
S,?	temperature scale?	

Example	Response
S,c	Wait 300ms; 1 (Dec) 0 (Null)
S,k	Wait 300ms; 1 (Dec) 0 (Null)
S,f	Wait 300ms; 1 (Dec) 0 (Null)
S,?	Wait 300ms; 1 (Dec) ?S,f (ASCII) 0 (Null) or 1 (Dec) ?S,k (ASCII) 0 (Null) or 1 (Dec) ?S,k (ASCII) 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Enable/disable data logger

Command syntax

300ms processing delay

The time period (n) is in 10 second intervals and can be any value from 1 to 32,000.

D,n n = (n x 10 seconds)

D,0 disable

D,? data logger storage interval?

Example	Response
D,6	Wait 300ms; 1 (Dec); 0 (Null)
D,0	Wait 300ms; 1 (Dec); 0 (Null)
D,?	Wait 300ms; 1 (Dec); ?D,6 (ASCII); 0 (Null)

 Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Memory recall

Disable data logger to recall memory.

Command syntax

300ms processing delay

M	recall 1 sequential stored reading
M,?	display memory location of last stored reading

Example	Response
M	Wait 300ms; 1 Dec; 1,100.00 ASCII; 0 Null
M,?	Wait 300ms; 1 Dec; 4,112.00 ASCII; 0 Null

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Memory clear

Command syntax

300ms processing delay

M,clear clear all stored memory

Example	Response
M,clear	Wait 300ms; 1 (Dec); 0 (Null)

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Naming device

300ms processing delay

Command syntax

Do not use spaces in the name

Name,n	set name	n = _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ _ (1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16)
Name,?	show name	Up to 16 ASCII characters

Example	Response
Name,zzt	Wait 300ms; 1 (Dec); 0 (Null)
Name,?	Wait 300ms; 1 (Dec); ?Name,zzt (ASCII); 0 (Null)

Name,zzt

1 0

Name,?

1 ?Name,zzt 0

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

Device information

Command syntax

300ms processing delay

i device information

Example	Response
i	Wait 300ms; 1 (Dec); ?i,RTD,2.01 (ASCII); 0 (Null)

Response breakdown

?i, RTD, 2.01

RTD: Device

2.01: Firmware

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Reading device status

Command syntax

300ms processing delay

Status voltage at Vcc pin and reason for last restart

Example	Response
Status	Wait 300ms; 1 (Dec); ?Status,P,5.038 (ASCII); 0 (Null)

Response breakdown

?Status,	P,	5.038
	Reason for restart	Voltage at Vcc

Restart codes

P	powered off
S	software reset
B	brown out
W	watchdog
U	unknown

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Sleep mode/low power

Command syntax

Sleep	enter sleep mode/low power

Send any character or command to awaken device.

Example	Response
Sleep	no response
Any command	wakes up device

Do not read status byte after issuing sleep command.

	STANDBY	SLEEP
5V	15.40 mA	0.4 mA
3.3V	13.80 mA	0.09 mA

Standby

Sleep

Sleep

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

Protocol lock

Command syntax

300ms processing delay

Locks device to I²C mode.

Plock,1	enable Plock	
Plock,0	disable Plock	default
Plock,?	Plock on/off?	

Example	Response
Plock,1	Wait 300ms; 1 (Dec); 0 (Null)
Plock,0	Wait 300ms; 1 (Dec); 0 (Null)
Plock,?	Wait 300ms; 1 (Dec); ?Plock,1 (ASCII); 0 (Null)

Plock,1

Baud, 9600

cannot change to UART

cannot change to UART

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

I²C address change

Command syntax

300ms processing delay

I2C,n sets I²C address and reboots into I²C mode

Example	Response
I2C,100	device reboot

Warning!

Changing the I²C address will prevent communication between the circuit and the CPU until the CPU is updated with the new I²C address.

Default I²C address is 102 (0x66).

n = any number 1 – 127

I2C,100

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.2

Factory reset

Command syntax

Factory reset will not take the device out of I²C mode.

Factory	enable factory reset

I²C address will not change

Example	Response
Factory	device reboot

Clears calibration
LED on
Response codes enabled
Clears data logger

Factory

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Change to UART mode

Command syntax

Baud,n switch from I²C to UART

Example	Response
Baud,9600	reboot in UART mode

n =
- 300
- 1200
- 2400
- 9600
- 19200
- 38400
- 57600
- 115200

 Copyright © Atlas Scientific LLC

Manual switching to UART

- Disconnect ground (power off)
- Disconnect TX and RX
- Connect TX to PRB
- Confirm RX is disconnected
- Connect ground (power on)
- Wait for LED to change from Blue to Green
- Disconnect ground (power off)
- Reconnect all data and power

Connecting TX to PRB only works for the EZO-RTD™ and the EZO-FLO™ circuits

Example

Wrong Example

Copyright © Atlas Scientific LLC

AtlasScientific™ Environmental Robotics

r 0.1

EZO™ circuit footprint

1 In your CAD software place a 8 position header.

2 Place a 3 position header at both top and bottom of the 8 position.

3 Delete the 8 position header. The two 3 position headers are now 17.78mm (0.7”) apart from each other.

Copyright © Atlas Scientific LLC

AtlasScientific™
Environmental Robotics
r 0.1

Datasheet change log

Datasheet V 3.4

Revised accuracy equation on pg 7.

Datasheet V 3.3

Moved Default state to pg 13.

Datasheet V 3.2

Revised response for the sleep command in UART mode on pg 36.

Datasheet V 3.1

Added more information on the Export calibration and Import calibration commands.

Datasheet V 3.0

Changed "Max rate" to "Response time" on cover page.

Datasheet V 2.9

Removed note from certain commands about firmware version.

Datasheet V 2.8

Added information to calibration theory on pg 9.

Datasheet V 2.7

Revised definition of response codes on pg 45.

Datasheet V 2.6

Updated calibration processing delay time on pg.51.

Datasheet V 2.5

Revised Plock pages to show default value.

Datasheet V 2.4

Added new commands:
"Find" pages 22 & 49.
"Export/Import calibration" pages 26 & 52.
Added new feature to continous mode "C,n" pg 23.

 Copyright © Atlas Scientific LLC

Datasheet change log

Datasheet V 2.3

Added manual switching to UART information on pg. 59.

Datasheet V 2.2

Revised Baud command information on pg. 33.

Datasheet V 2.1

Revised entire datasheet.

Firmware updates

V1.02 – Plock (March 31, 2016)
- Added protocol lock feature "Plock"

V1.03 – EEPROM (April 26, 2016)
- Fixed bug where EEPROM would get erased if the circuit lost power 900ms into startup

V1.11 – Bug Fix (June 9, 2016)
- Fixed bug where a blank name would result in garbage ouput

V2.01 – Update (January 1, 2017)
- Replaced command "response" with "*OK"
- Replaced command "Serial" with "Baud"

V2.02 – Bug Fix (February 16, 2017)
- Fixed bug where calibration would not accept floating point numbers.

V2.10 – (May 9, 2017)
- Added "Find" command.
- Added "Export/import" command.
- Modified continuous mode to be able to send readings every "n" seconds.
- Sleep current is lowered.

 Copyright © Atlas Scientific LLC

Warranty

Atlas Scientific™ Warranties the EZO™ class RTD circuit to be free of defect during the debugging phase of device implementation, or 30 days after receiving the EZO™class RTD circuit (which ever comes first).

The debugging phase

The debugging phase as defined by Atlas Scientific™ is the time period when the EZO™ class RTD circuit is inserted into a bread board, or shield. If the EZO™ class RTD circuit is being debugged in a bread board, the bread board must be devoid of other components. If the EZO™ class RTD circuit is being connected to a microcontroller, the microcontroller must be running code that has been designed to drive the EZO™ class RTD circuit exclusively and output the EZO™ class RTD circuit data as a serial string.

It is important for the embedded systems engineer to keep in mind that the following activities will void the EZO™ class RTD circuit warranty:

- **Soldering any part of the EZO™ class RTD circuit.**
- **Running any code, that does not exclusively drive the EZO™ class RTD circuit and output its data in a serial string.**
- **Embedding the EZO™ class RTD circuit into a custom made device.**
- **Removing any potting compound.**

 Copyright © Atlas Scientific LLC

Reasoning behind this warranty

Because Atlas Scientific™ does not sell consumer electronics; once the device has been embedded into a custom made system, Atlas Scientific™ cannot possibly warranty the EZO™ class RTD circuit, against the thousands of possible variables that may cause the EZO™ class RTD circuit to no longer function properly.

Please keep this in mind:

1. **All Atlas Scientific™ devices have been designed to be embedded into a custom made system by you, the embedded systems engineer.**
2. **All Atlas Scientific™ devices have been designed to run indefinitely without failure in the field.**
3. **All Atlas Scientific™ devices can be soldered into place, however you do so at your own risk.**

Atlas Scientific™ is simply stating that once the device is being used in your application, Atlas Scientific™ can no longer take responsibility for the EZO™ class RTD circuits continued operation. This is because that would be equivalent to Atlas Scientific™ taking responsibility over the correct operation of your entire device.

 Copyright © Atlas Scientific LLC