

# Carrier Controller

1. ON / OFF SWITCH
2. STOP – START / CONTINUOUS FUNCTION
3. SET POINT TEMP UP
4. SET POINT TEMP DOWN
5. ENTER
6. ENGINE / STAND-BY SWITCH. (MUST KEPT ON ENGINE)

