

MITSUBISHI TFV 150 GA

1. ON / OFF
2. SET POINT UP
3. SET POINT DOWN
4. SET POINT ENTER / CONTINUOUS

