

Pegasus Controller.

1. TURN FRIDGE ON / OFF
2. START -STOP / CONTINUOUS
3. SET POINT UP
4. SET POINT DOWN
5. ENTER
6. ENGINE STANDBY

