

Carrier APX Controllers.

1. ON / OFF
2. STOP – START / CONTINUOUS
3. SET POINT UP
4. SET POINT DOWN
5. SET POINT ENTER

