

- things correctly!
- —If you want to program the teensy while it's socketed on the board, you either need to unplug the 2V power while doing it, or sacrifice a micro-USB cable by cutting the 5V line in the cable. This will prevent having your computer and the 7805 supplying 5V at the same time. (Not sure if this is an actual problem, but didn't want to take chances)

Sheet: File: nixie_board.kicad_pcb Title: Size: A4 Date: Rev: KiCad E.D.A. pcbnew 4.0.7 ld: 1/1