



WJ-C1 Extended Mode Quick Start

Quick Start Essential Parameters

AA101 – Frequency (Speed) Source (default 07
Keypad [parameter FA-01])

AA111 – Run Command Source (default 02
Keypad [Run Key])

AA115 – Stop Mode Selection (default 00
[Decelerate to Stop])

Hb102 – Motor Capacity in kilowatts

Hb103 – Motor Poles (default 01 - 4 poles)

Hb104 – Base Frequency (default 60Hz)

Hb105 – Maximum Frequency (default
60Hz)

Hb106 – Motor Voltage

Hb108 – Motor Current in Amps

FA-01 – Keypad Speed Setting (default 0.00)

FA-10 – Acceleration Time (default 10 seconds)

FA-12 – Deceleration Time (default 10 seconds)

To Enter Programming Mode and Use the C1 Keypad for Programming

KEYPAD FUNCTIONS

The keypad provides an easy to use, interactive way to access and enter the parameters.

- A** The jog dial is used to navigate through parameters
- B** The center of the jog dial is the Enter key
- C** Run is the Green top key
- D** Stop/Reset is the Red bottom key
- E** Esc enters programming mode



To Set the Motor Data

The motor parameters are grouped together intuitively for simple programming.

- 1** Press the Esc key to enter Programming Mode
- 2** Press Esc until H file group is reached Press the enter key
- 3** Rotate the jog dial clockwise until the Hb parameters are reached
- 4** Enter the motor data in the parameters listed below

- | | |
|------------------------------|-------------------------------|
| • Hb102- Motor Capacity (kw) | • Hb105- Max Frequency (Hz) |
| • Hb103- Motor Poles | • Hb106- Motor Voltage (VAC) |
| • Hb104- Base Frequency (Hz) | • Hb108- Motor Current (Amps) |

- 5** Press the Enter key to save the data for each parameter

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM

To Set the Speed Reference

- 1 Press the Esc key to enter Programming Mode
- 2 Press the Esc until A file group is reached
- 3 Rotate the jog dial until the AA101 parameter is displayed
- 4 Press the enter key
- 5 Select the speed reference from the options below

1- Analog Input 1 (Ai1)
2- Analog Input 2 (Ai2)
7- Keypad (parameter FA-01)
8- RS485 (Modbus communication)
9- Option

12- Pulse Input
14- EzSq (Easy Sequence Program)
15- PID
16- VR (Potentiometer on external Keypad)

To Set the Run Command Source

- 1 Press the Esc key to enter Programming Mode
- 2 Press Esc until A group is reached
- 3 Rotate the jog dial until the AA111 parameter is displayed
- 4 Press the enter key
- 5 Now you can select the Run Command source from the options below

0- Terminal 2-Wire (FW) / (RV)

3- RS485 (Modbus communication)

1- Terminal 3-Wire (Start) / (Stop)

4- Option

2- Run key (Keypad)

- 6 Press the Enter key to save the data

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM

- 6 Press Enter to save the data

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM



To Set the Speed in Hz Using the Keypad Parameters

- 1 Press the Esc key to enter Programming Mode
- 2 Press Esc until the FA-01 parameter is reached
- 3 Press the Enter key
- 4 Using the jog dial you can adjust the speed by rotating the jog dial clockwise (increase) and counterclockwise (decrease)
- 5 Press Enter to save the desired speed

This parameter can be changed while the motor is running or stopped

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM



To Set the Acceleration and Deceleration Times

- 1 Press the Esc key to enter Programming Mode
- 2 Press the Esc key until FA-01 is reached
- 3 Rotate the jog dial clockwise until FA-10 (Acceleration) or FA-12 (Deceleration)
- 4 Press Enter to select the parameter
- 5 Now you can adjust the Acceleration/Deceleration time using the jog dial
- 6 Press the Enter key to save the data

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM



To Set the Stop Mode

- 1 Press the Esc key to enter Programming Mode
- 2 Press the Esc key until parameter AA101 is reached
- 3 Rotate the jog dial until parameter AA115 is reached
- 4 Press the enter key
- 5 Now you can select the Stop Mode from the options below

0- Decelerate To STOP

1- Free Run STOP

- 6 Press the Enter key to save the data

BE SURE TO PRESS THE ENTER KEY TO SAVE THE DATA TO EEPROM



TECH SUPPORT

980-500-7141

WEBSITE

www.hitachi-iesa.com/ac-drives-inverters

EMAIL

inverter.info@hitachi-iesa.com



SCAN THIS QR CODE
to access the manual
or register your
product for warranty

HITACHI