Case 5a Data Master -> Node Node -> Data Master Data Master Data Master Data Master Data Master WR node WR node WR node WR node **ACTIVE ACTIVE INACTIVE INACTIVE GPS GPS** D&TM D&TM D&TM D&TM **Backup Port** Forwarding **Alternate Port** blocking/discarding