

Левая боковина (продолжение на листе 1)

	Цепи оперативного тока			Х	
		○ 38	X:38	UZ1:1	+
		○ 39	X:39	SG1:8	—
		○ 40			
		○ 41			
		○ 42			
		○ 43			
		○ 44			
		45	X:45	A1-M4.XB:1	—
		46	X:46	A1-M4.XB:3	—
		47	X:47	A1-M4.XB:5	—
		48	X:48	A1-M4.XB:7	—
		49	X:49	A1-M4.XB:9	—
		50	X:50	A1-M4.XB:11	—
		51	X:51	A1-M4.XB:13	—
		52	X:52	A1-M4.XB:15	—
		53	X:53	A1-M4.XB:17	—
		54	X:54	A1-M4.XB:19	—
		55	X:55	A1-M4.XB:21	—
		56	X:56	A1-M4.XB:23	—
		57	X:57	A1-M4.XB:25	—
		58	X:58	A1-M4.XB:27	—
		59	X:59	A1-M4.XB:29	—
		60	X:60	A1-M4.XB:31	—
		61	X:61	A1-M5.XB:1	—
		62	X:62	A1-M5.XB:3	—
		63	X:63	A1-M5.XB:5	—
		64	X:64	A1-M5.XB:7	—
		65			
		66			
		67			
		68			
		69			
		70			
		71			
		72			
		73			
		74			
		75			
		76			
		77			
		78			
		79			
		○ 80	X:80	UZ1:4	+
		○ 81	X:81	A1-M5.XB:10	—
	Выходные цепи			Х	
		82	X:82	A1-M2.XB:2	—
		83	X:83	A1-M2.XB:4	—
		84	X:84	A1-M2.XB:6	—
		85	X:85	A1-M2.XB:8	—
		86	X:86	A1-M2.XB:10	—
		87	X:87	A1-M2.XB:12	—
		88	X:88	A1-M2.XB:14	—
		89	X:89	A1-M2.XB:16	—
		90	X:90	A1-M2.XB:18	—
		91			
		92			
		93			
		94			
		95			
		96			
		97			
		98			
		99			
		100			
		101			

Левая боковина (продолжение на листе 3)