

Левая боковина (начало)						
	Цепи переменного тока /ЛЭП			X		
		1	X:1	SG1:2	≠	
		2	X:2	SG1:4	≠	
		3	X:3	SG1:6	≠	
		4	X:4	SG1:8	≠	
		5	X:5	SG1:10	≠	
		6	X:6	SG1:12	≠	
		7				
		8				
	Цепи переменного напряжения			X		
		9	X:9	SG2:2	≠	
		10	X:10	SG2:4	≠	
	Цепи переменного напряжения			X		
		11	X:11	SG3:2	+	
		12	X:12	SG3:4	+	
		13	X:13	SG3:6	+	
		14	X:14	SG3:8	+	
		15	X:15	SG4:2	+	
		16	X:16	SG4:4	+	
		17	X:17	SG4:6	+	
		18	X:18	SG4:8	+	
	Цепи отбора напряжения			X		
			19	X:19	SG5:2	+
			20	X:20	SG5:4	+
		21	X:21	SG5:6	+	
	Цепи оперативного тока			X		
			22	X:22	UZ1:1	+
			23	X:23	SG1:14	—
			24			
			25			
			26			
			27			
			28			
		29	X:29	A1-M5.XB:1	—	
		30	X:30	A1-M5.XB:3	—	
		31	X:31	A1-M5.XB:5	—	
		32	X:32	A1-M5.XB:7	—	
		33	X:33	A1-M5.XB:9	—	
		34	X:34	A1-M5.XB:11	—	
		35	X:35	A1-M5.XB:13	—	
		36				
		37				
		38	X:38	A1-M5.XB:15	—	
		39				
		40				

Левая боковина (продолжение на листе 2)

Правая боковина (начало)				
X	Выходные цепи			
A1-M2.XB:2	X:120	120		
A1-M2.XB:4	X:121	121		
A1-M2.XB:6	X:122	122		
A1-M2.XB:8	X:123	123		
A1-M2.XB:10	X:124	124		
A1-M2.XB:12	X:125	125		
A1-M2.XB:20	X:126	126		
A1-M2.XB:22	X:127	127		
A1-M2.XB:24	X:128	128		
A1-M2.XB:26	X:129	129		
A1-M2.XB:28	X:130	130		
K2:1	X:131	131		
K2:2	X:132	132		
K2:9	X:133	133		
K2:10	X:134	134		
A1-M3.XB:2	X:135	135		
A1-M3.XB:4	X:136	136		
SA7:9	X:137	137		
SA7:13	X:138	138		
SA7:17	X:139	139		
A1-M3.XB:6	X:140	140		
A1-M3.XB:8	X:141	141		
A1-M3.XB:10	X:142	142		
A1-M3.XB:12	X:143	143		
		144		
		145		
		146		
		147		
		148		
		149		
		150		
		151		
		152		
		153		
SA4:4	X:154	154		
SA5:4	X:155	155		
SA3:4	X:156	156		
SA3:6	X:157	157		
SA3:8	X:158	158		
SA3:10	X:159	159		
SA2:4	X:160	160		
SA2:6	X:161	161		
SA2:8	X:162	162		
SA6:4	X:163	163		
SA6:6	X:164	164		
K2:3	X:165	165		
K2:4	X:166	166		
K2:11	X:167	167		

Правая боковина (продолжение на листе 2)

Условные обозначения

