

		43		A1-M4.XB-9
		44		A1-M4.XB-11
		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53		
		54	X-54	A1-M1.XP-20
		55	X-55	UZ1-4
	Цепи сигнализации ТТ			X
		○ 56	X-56	A1-M4.XB-29
		○ 57		
		○ 58		
		○ 59		
		60	X-60	A1-M4.XB-13
		61	X-61	A1-M4.XB-13
		62	X-62	A1-M4.XB-13
		63	X-63	A1-M4.XB-13
		64	X-64	A1-M4.XB-13
		65	X-65	A1-M4.XB-13
		66	X-66	A1-M4.XB-13
		67	X-67	A1-M4.XB-13
		68		
		69		
		70		
		71		
		72		
		73		
		74		
		○ 75	X-75	A1-M4.XB-30
		○ 76		
	Выходные цепи			X
		77	X-77	A1-M2.XB-2
		78	X-78	A1-M2.XB-4
		79	X-79	A1-M2.XB-6
		80	X-80	A1-M2.XB-8
		81	X-81	A1-M2.XB-10
		82	X-82	A1-M2.XB-12
		83	X-83	A1-M2.XB-14
		84	X-84	A1-M2.XB-16
		85	X-85	A1-M2.XB-18
		86	X-86	A1-M2.XB-20
		87	X-87	A1-M2.XB-22
		88	X-88	A1-M2.XB-24
		89	X-89	A1-M2.XB-26
		90	X-90	A1-M2.XB-28
		91	X-91	A1-M2.XB-30
		92	X-92	A1-M2.XB-32
		93	X-93	A1-M3.XB-2
		94	X-94	A1-M3.XB-4
		95	X-95	A1-M3.XB-6
		96	X-96	A1-M3.XB-8
		97	X-97	A1-M3.XB-10
		98	X-98	A1-M3.XB-12
		99		
		100		
		101	X-101	SA1-4
		102	X-102	SA1-6
		103	X-103	SA1-8
		104	X-104	SA1-10
		105	X-105	SA1-12
		106	X-106	SA1-14
		107	X-107	SA1-16
		108	X-108	SA2-4
		109	X-109	SA3-4
		110	X-110	SA3-6