

Левая баковина (начало)				
	Цепи переменного тока В			Х
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи переменного тока ОВ			Х
		9	X:9	SG2:2
		10	X:10	SG2:4
		11	X:11	SG2:6
		12	X:12	SG2:8
		13	X:13	SG2:10
		14	X:14	SG2:12
		15		
		16		
	Цепи переменного тока нейтрали			Х
		17	X:17	SG3:2
		18	X:18	SG3:4
		19	X:19	SG3:6
		20	X:20	SG3:8
		21	X:21	SG3:10
		22	X:22	SG3:12
		23		
		24		
	Цепи переменного тока средней перемычки			Х
		25	X:25	SG4:2
		26	X:26	SG4:4
		27	X:27	SG4:6
		28	X:28	SG4:8
		29	X:29	SG4:10
		30	X:30	SG4:12
		31	X:31	
		32	X:32	
	Цепи переменного тока нейтрального провода			Х
		33	X:33	SG5:2
		34	X:34	SG5:4
	Цепи переменного напряжения			Х
		35	X:35	SG6:2
		36	X:36	SG6:4
		37	X:37	SG6:6
		38	X:38	SG6:8
		39	X:39	SG7:2
		40	X:40	SG7:4
		41	X:41	SG7:6
		42	X:42	SG7:8

Левая баковина (продолжение на листе 2)

Правая баковина (начало)				
Х	Цепи переменного тока			
SG10:2	X:181	181		
SG10:4	X:182	182		
SG10:6	X:183	183		
SG10:8	X:184	184		
SG10:10	X:185	185		
SG10:12	X:186	186		
		187		
		188		
Х	Цепи оперативного тока терминала			
UZ2:1	X:189	189		
SG10:14	X:190	190		
		191		
		192		
A2-M5.XB:1	X:193	193		
A2-M5.XB:3	X:194	194		
A2-M5.XB:5	X:195	195		
A2-M5.XB:7	X:196	196		
A2-M5.XB:9	X:197	197		
		198		
		199		
		200		
		201		
		202		
		203		
		204		
		205		
		206		
		207		
UZ2:4	X:208	208		
A2-M5.XB:2	X:209	209		
Х	Цепи сигнализации выключателя и ТТ			
A2-M5.XB:11	X:210	210		
		211		
A2-M5.XB:13	X:212	212		
A2-M5.XB:15	X:213	213		
A2-M5.XB:17	X:214	214		
A2-M5.XB:19	X:215	215		
A2-M5.XB:21	X:216	216		
A2-M5.XB:23	X:217	217		
A2-M5.XB:25	X:218	218		
A2-M5.XB:27	X:219	219		
A2-M5.XB:29	X:220	220		
A2-M5.XB:31	X:221	221		
A2-M6.XB:1	X:222	222		
A2-M6.XB:3	X:223	223		
		224		
		225		
		226		
		227		
		228		

Правая баковина (продолжение на листе 2)