

Левая боковина (продолжение на листе 1)

	Цепи переменного напряжения ОВ			X
		43	X:43	SG8-2
		44	X:44	SG8-4
		45	X:45	SG8-6
		46	X:46	SG8-8
		47	X:47	SG9-2
		48	X:48	SG9-4
		49	X:49	SG9-6
		50	X:50	SG9-8
	Цепи оперативного тока терминала			X
		51	X:51	UZ1:1
		52	X:52	SG1:14
		53		
		54		
		55	X:55	A1-M4.XB-1
		56		
		57		
		58		
		59		
		60		
		61		
		62		
		63		
		64		
		65	X:65	UZ1:4
		66	X:66	A1-M4.XB-2
	Цепи сигнализации ТТ			X
		67	X:67	A1-M4.XB-15
		68		
		69		
		70		
		71	X:71	A1-M4.XB-3
		72	X:72	A1-M4.XB-5
		73	X:73	A1-M4.XB-7
		74	X:74	A1-M4.XB-9
		75	X:75	A1-M4.XB-11
		76	X:76	A1-M4.XB-13
		77		
		78		
		79		
		80		
		81		
		82		
		83		
		84		
		85		
		86		
		87		
		88		
		89		
		90		
		91		
		92		
		93		
		94		
		95		
		96	X:96	A1-M4.XB-16
		97		

Левая боковина (продолжение на листе 3)

Правая боковина (продолжение на листе 1)

		229		
		230		
		231		
		232		
		233		
		234		
		235		
		236		
		237		
		238		
		239		
		240		
		241		
		242		
		243		
		244		
		245		
		246		
A2-M5.XB-12	X:247	247		
		248		
X	Цепи ЭМВ и ЭМ01			
A2-M2.XB-14	X:249	249		
KA1:2	X:250	250		
		251		
		252		
		253		
		254		
		255		
		256		
		257		
		258		
		259		
		260		
		261		
A2-M6.XB-5	X:262	262		
KA1:A	X:263	263		
KA1:B	X:264	264		
		265		
A2-M6.XB-7	X:266	266		
KA2:A	X:267	267		
KA2:B	X:268	268		
		269		
A2-M6.XB-9	X:270	270		
KA3:A	X:271	271		
KA3:B	X:272	272		
		273		
SA6-10	X:274	274		
		275		
		276		
		277		
KA4:A	X:278	278		
A2-M6.XB-11	X:279	279		
KA4:B	X:280	280		
		281		
SA6-12	X:282	282		
		283		
		284		
		285		
KA5:A	X:286	286		
A2-M6.XB-13	X:287	287		
KA5:B	X:288	288		

Правая боковина (продолжение на листе 3)