

Левая доковина (начало)					
	Цепи переменного тока В БСК (В1)			X	
		1	X:1	SG1:2	#
		2	X:2	SG1:4	#
		3	X:3	SG1:6	#
		4	X:4	SG1:8	#
		5	X:5	SG1:10	#
		6	X:6	SG1:12	#
			7		
			8		
	Цепи переменного тока ОВ (В2)			X	
		9	X:9	SG2:2	#
		10	X:10	SG2:4	#
		11	X:11	SG2:6	#
		12	X:12	SG2:8	#
		13	X:13	SG2:10	#
		14	X:14	SG2:12	#
			15		
			16		
	Цепи переменного тока нейтрали			X	
		17	X:17	SG3:2	#
		18	X:18	SG3:4	#
		19	X:19	SG3:6	#
		20	X:20	SG3:8	#
		21	X:21	SG3:10	#
		22	X:22	SG3:12	#
			23		
			24		
	Цепи переменного тока средней перемычки			X	
		25	X:25	SG4:2	#
		26	X:26	SG4:4	#
		27	X:27	SG4:6	#
		28	X:28	SG4:8	#
		29	X:29	SG4:10	#
		30	X:30	SG4:12	#
			31		
			32		
	Цепи переменного тока цепи заземления нейтрали			X	
		33	X:33	SG5:2	#
		34	X:34	SG5:4	#

Левая доковина (продолжение на листе 2)

Условные обозначения

