

Левая боковина (начало)

	Цепи переменного тока В1		Х	
		1 X1	SG12	#
		2 X2	SG14	#
		3 X3	SG16	#
		4 X4	SG18	#
		5 X5	SG110	#
		6 X6	SG112	#
		7		
		8		
	Цепи переменного тока В2		Х	
		9 X7	SG2-2	#
		10 X8	SG2-4	#
		11 X9	SG2-6	#
		12 X10	SG2-8	#
		13 X11	SG2-10	#
		14 X12	SG2-12	#
		15		
		16		
	Цепи переменного тока В3		Х	
		17 X17	SG3-2	#
		18 X18	SG3-4	#
		19 X19	SG3-6	#
		20 X20	SG3-8	#
		21 X21	SG3-10	#
		22 X22	SG3-12	#
		23		
		24		
	Цепи переменного тока В4		Х	
		25 X25	SG4-2	#
		26 X26	SG4-4	#
		27 X27	SG4-6	#
		28 X28	SG4-8	#
		29 X29	SG4-10	#
		30 X30	SG4-12	#
		31		
		32		
	Цепи переменного тока В5		Х	
		33 X33	SG5-2	#
		34 X34	SG5-4	#
		35 X35	SG5-6	#
		36 X36	SG5-8	#
		37 X37	SG5-10	#
		38 X38	SG5-12	#
		39		
		40		

Левая боковина (продолжение на листе 2)

Правая боковина (начало)

	Цепи фиксации присоединений		Х	
		136		
		137		
		138		
		139		
		140		
		141		
		142		
		143		
		144		
		145		
		146		
		147		
A1-M8.XB-11	X-148	148		
A1-M8.XB-13	X-149	149		
A1-M8.XB-15	X-150	150		
A1-M8.XB-17	X-151	151		
A1-M8.XB-19	X-152	152		
A1-M8.XB-21	X-153	153		
A1-M8.XB-23	X-154	154		
A1-M8.XB-25	X-155	155		
A1-M8.XB-27	X-156	156		
A1-M8.XB-29	X-157	157		
A1-M8.XB-31	X-158	158		
A1-M9.XB-1	X-159	159		
A1-M9.XB-3	X-160	160		
A1-M9.XB-5	X-161	161		
A1-M9.XB-7	X-162	162		
A1-M9.XB-9	X-163	163		
A1-M9.XB-11	X-164	164		
A1-M9.XB-13	X-165	165		
		166		
		167		
		168		
		169		
		170		
		171		
		172		
A1-M8.XB-12	X-173	173		
		174		
Х	Выходные цепи			
A1-M2.XB-2	X-175	175		
A1-M2.XB-4	X-176	176		
A1-M2.XB-6	X-177	177		
A1-M2.XB-8	X-178	178		
A1-M2.XB-10	X-179	179		
A1-M2.XB-12	X-180	180		
A1-M2.XB-14	X-181	181		

Правая боковина (продолжение на листе 2)

Условные обозначения

