

1 секция. Левая боковина				
	Цепи оперативного тока			X
		169	X:169	UZ1:1
		170	X:170	SG1:22
		171		
		172		
		173		
		174		
		175		
		176		
		177		
		178		
		179		
		180		
		181		
		182		
		183		
		184		
		185		
		186		
		187		
		188		
		189	X:189	A1-M5.XB:1
		190	X:190	A1-M5.XB:2
		191	X:191	A1-M5.XB:3
		192	X:192	A1-M5.XB:4
		193	X:193	A1-M5.XB:5
		194	X:194	A1-M5.XB:6
		195	X:195	A1-M5.XB:7
		196	X:196	A1-M5.XB:9
		197	X:197	A1-M5.XB:10
		198	X:198	A1-M5.XB:11
		199	X:199	A1-M5.XB:12
		200	X:200	A1-M5.XB:13
		201	X:201	A1-M5.XB:14
		202	X:202	A1-M5.XB:15
		203	X:203	A1-M5.XB:17
		204	X:204	A1-M5.XB:18
		205	X:205	A1-M5.XB:19
		206	X:206	A1-M5.XB:20
		207	X:207	A1-M5.XB:21
		208	X:208	A1-M5.XB:22
		209	X:209	A1-M5.XB:23
		210	X:210	A1-M5.XB:25
		211	X:211	A1-M5.XB:26
		212	X:212	A1-M5.XB:27
		213	X:213	A1-M5.XB:28
		214	X:214	A1-M5.XB:29
		215	X:215	A1-M5.XB:30
		216	X:216	A1-M5.XB:31
		217	X:217	A1-M6.XB:1
		218	X:218	A1-M6.XB:2
		219	X:219	A1-M6.XB:3
		220	X:220	A1-M6.XB:4
		221	X:221	A1-M6.XB:5
		222	X:222	A1-M6.XB:6
		223	X:223	A1-M6.XB:7
		224	X:224	A1-M6.XB:9
		225	X:225	A1-M6.XB:10
		226	X:226	A1-M6.XB:11
		227	X:227	A1-M6.XB:12
		228	X:228	A1-M6.XB:13
		229	X:229	A1-M6.XB:14
		230		
		231		
		232		
		233		
		234		
		235		
		236		
		237		
		238		
		239	X:239	UZ1:4
		240	X:240	A1-M5.XB:8

1 секция. Правая боковина				
X	Цепи сигнализации			
A1-M1.XP:2	X:473	473		
		474		
		475		
		476		
		477		
		478		
		479		
		480		
		481		
		482		
		483		
		484		
HL1:2	X:485	485		
		486		
X	Цепи регистрации			
A1-M1.XP:5	X:487	487		
A1-M1.XP:15	X:488	488		
		489		
A1-M1.XP:4	X:490	490		
A1-M1.XP:14	X:491	491		
X	Освещение			
SQ1:11	X:492	492		
SQ3:11	X:493	493		
SQ1:21	X:494	494		
SQ3:21	X:495	495		
X	Резерв/Транзит			
		496		
		497		
		498		
		499		
		500		
		501		
		502		
		503		
		504		
		505		
		506		
		507		
		508		
		509		
		510		
		511		
		512		
		513		
		514		
		515		
		516		
		517		
		518		
		519		
		520		
		521		
		522		
		523		
		524		
		525		