

Левая боковина (начало)

	Цепи переменного тока В1		Х	
		1 X1	SG12	#
		2 X2	SG14	#
		3 X3	SG16	#
		4 X4	SG18	#
		5 X5	SG110	#
		6 X6	SG112	#
		7		
		8		
	Цепи переменного тока В2		Х	
		9 X7	SG2.2	#
		10 X8	SG2.4	#
		11 X9	SG2.6	#
		12 X10	SG2.8	#
		13 X11	SG2.10	#
		14 X12	SG2.12	#
		15		
		16		
	Цепи переменного тока В3		Х	
		17 X17	SG3.2	#
		18 X18	SG3.4	#
		19 X19	SG3.6	#
		20 X20	SG3.8	#
		21 X21	SG3.10	#
		22 X22	SG3.12	#
		23		
		24		
	Цепи переменного тока В4		Х	
		25 X25	SG4.2	#
		26 X26	SG4.4	#
		27 X27	SG4.6	#
		28 X28	SG4.8	#
		29 X29	SG4.10	#
		30 X30	SG4.12	#
		31		
		32		
	Цепи переменного тока В5		Х	
		33 X33	SG5.2	#
		34 X34	SG5.4	#
		35 X35	SG5.6	#
		36 X36	SG5.8	#
		37 X37	SG5.10	#
		38 X38	SG5.12	#
		39		
		40		

Левая боковина (продолжение на листе 2)

Правая боковина (начало)

Х	Выходные цепи			
A1-M2.XB-2	X-153	153		
A1-M2.XB-4	X-154	154		
A1-M2.XB-6	X-155	155		
A1-M2.XB-8	X-156	156		
A1-M2.XB-10	X-157	157		
A1-M2.XB-12	X-158	158		
A1-M2.XB-14	X-159	159		
A1-M2.XB-16	X-160	160		
A1-M2.XB-18	X-161	161		
A1-M2.XB-20	X-162	162		
A1-M2.XB-22	X-163	163		
A1-M2.XB-24	X-164	164		
A1-M2.XB-26	X-165	165		
A1-M2.XB-28	X-166	166		
A1-M2.XB-30	X-167	167		
A1-M2.XB-32	X-168	168		
A1-M3.XB-2	X-169	169		
A1-M3.XB-4	X-170	170		
A1-M3.XB-6	X-171	171		
A1-M3.XB-8	X-172	172		
A1-M3.XB-10	X-173	173		
A1-M3.XB-12	X-174	174		
A1-M3.XB-14	X-175	175		
A1-M3.XB-16	X-176	176		
A1-M3.XB-18	X-177	177		
A1-M3.XB-20	X-178	178		
A1-M3.XB-22	X-179	179		
A1-M3.XB-24	X-180	180		
A1-M3.XB-26	X-181	181		
A1-M3.XB-28	X-182	182		
A1-M3.XB-30	X-183	183		
A1-M3.XB-32	X-184	184		
A1-M4.XB-2	X-185	185		
A1-M4.XB-4	X-186	186		
A1-M4.XB-6	X-187	187		
A1-M4.XB-8	X-188	188		
A1-M4.XB-10	X-189	189		
A1-M4.XB-12	X-190	190		
A1-M4.XB-14	X-191	191		
A1-M4.XB-16	X-192	192		
	X-193	193		
	X-194	194		
	X-195	195		
	X-196	196		
	X-197	197		
	X-198	198		
	X-199	199		
	X-200	200		

Правая боковина (продолжение на листе 2)

Условные обозначения

