

Левая боковина (продолжение на листе 2)

	Цепи переменного напряжения 2 секции		X	
	93	X:90	SG12.2	+
	94	X:94	SG12.4	+
	95	X:95	SG12.6	+
	96			
	Цепи оперативного тока		X	
	97	X:97	UZ11	+
	98	X:98	SG114	
	99			
	100			
	101			
	102			
	103			
	104			
	105			
	106			
	107			
	108			
	109			
	110			
	111	X:111	A1-M7.XB.1	
	112			
	113			
	114			
	115			
	116			
	117	X:117	A1-M7.XB.3	
	118			
	119			
	120			
	121			
	122			
	123	X:123	A1-M7.XB.5	
	124	X:124	A1-M7.XB.7	
	125	X:125	A1-M7.XB.9	
	126	X:126	A1-M7.XB.11	
	127	X:127	A1-M7.XB.13	
	128	X:128	A1-M7.XB.15	
	129	X:129	A1-M7.XB.17	
	130	X:130	A1-M7.XB.19	
	131	X:131	A1-M7.XB.21	
	132	X:132	A1-M7.XB.23	
	133	X:133	A1-M7.XB.25	
	134	X:134	A1-M7.XB.27	
	135			
	136			
	137			
	138			
	139			
	140			
	141	X:141	UZ14	+
	142	X:142	A1-M8.XB.4	
	Цепи фиксации ОБ		X	
	143	X:143	A1-M8.XB.1	
	144			
	145			
	146	X:146	A1-M7.XB.29	
	147	X:147	A1-M7.XB.31	
	148			
	149			
	150			
	151	X:151	A1-M8.XB.2	
	152			

Правая боковина (продолжение на листе 2)

	HL12	X:265	265	♀		
			266	♀		
	X	Цепи регистрации				
	A1-M1.XP.5	X:267	267	♀		
	A1-M1.XP.15	X:268	268	♀		
			269			
	A1-M1.XP.4	X:270	270			
	A1-M1.XP.14	X:271	271			
	X	Освещение				
WE2	кч	SQ111	X:272	272	♀	
WE4	кч	SQ311	X:273	273	♀	
	с	SQ121	X:274	274	♀	
	с	SQ321	X:275	275	♀	
	X	Резерв/Транзит				
				276		
				277		
				278		
				279		
				280		
				281		
				282		
				283		
				284		
				285		
				286		
				287		
				288		
				289		
				290		
				291		
				292		
				293		
				294		
				295		
				296		
				297		
				298		
				299		
				300		
				301		
				302		
				303		
				304		
				305		