

Левая боковина (продолжение на листе 2)

	Цепи переменного напряжения 2 секции			X
		93	X:90	SG12:2
		94	X:94	SG12:4
		95	X:95	SG12:6
		96		
	Цепи оперативного тока			X
		97	X:97	UZ1:1
		98	X:98	SG1:14
		99		
		100		
		101		
		102		
		103		
		104		
		105		
		106		
		107		
		108		
		109		
		110		
		111	X:111	A1-M7.XB-1
		112		
		113		
		114		
		115		
		116		
		117	X:117	A1-M7.XB-3
		118		
		119		
		120		
		121		
		122		
		123	X:123	A1-M7.XB-5
		124	X:124	A1-M7.XB-7
		125	X:125	A1-M7.XB-9
		126	X:126	A1-M7.XB-11
		127	X:127	A1-M7.XB-13
		128	X:128	A1-M7.XB-15
		129	X:129	A1-M7.XB-17
		130	X:130	A1-M7.XB-19
		131	X:131	A1-M7.XB-21
		132	X:132	A1-M7.XB-23
		133	X:133	A1-M7.XB-25
		134	X:134	A1-M7.XB-27
		135		
		136		
		137		
		138		
		139		
		140		
		141	X:141	UZ1:4
		142	X:142	A1-M8.XB-4
	Цепи фиксации ОБ			X
		143	X:143	A1-M8.XB-1
		144		
		145		
		146	X:146	A1-M7.XB-29
		147	X:147	A1-M7.XB-31
		148		
		149		
		150		
		151	X:151	A1-M8.XB-2
		152		

Правая боковина (продолжение на листе 2)

	HL1:2	X:265	265		
			266		
	X	Цепи регистрации			
	A1-M1.XP-5	X:267	267		
	A1-M1.XP-15	X:268	268		
			269		
	A1-M1.XP-4	X:270	270		
	A1-M1.XP-14	X:271	271		
	X	Освещение			
WE2	SQ1:11	X:272	272		
WE4	SQ3:11	X:273	273		
	SQ1:21	X:274	274		
	SQ3:21	X:275	275		
	X	Резерв/Транзит			
			276		
			277		
			278		
			279		
			280		
			281		
			282		
			283		
			284		
			285		
			286		
			287		
			288		
			289		
			290		
			291		
			292		
			293		
			294		
			295		
			296		
			297		
			298		
			299		
			300		
			301		
			302		
			303		
			304		
			305		