

Левая боковина (продолжение на листе 1)

		45		
		46		
		47		
		48		
		49		
		50		
		51		
		○ 52	X:52	UZ14
		○ 53	X:53	A1-M6.XB:28
	Цепи сигнализации выключателя/ТТ			X
		○ 54	X:54	A1-M5.XB:15
		○ 55		
		56	X:56	A1-M5.XB:17
		57	X:57	A1-M5.XB:19
		58	X:58	A1-M5.XB:21
		59	X:59	A1-M5.XB:23
		60	X:60	A1-M5.XB:25
		61	X:61	A1-M5.XB:27
		62	X:62	A1-M5.XB:29
		63	X:63	A1-M5.XB:31
		64	X:64	A1-M3.XB:2
		65	X:65	A1-M3.XB:32
		66		
		67		
		68		
		69		
		70		
		○ 71	X:71	A1-M5.XB:30
		○ 72		
	Цепи ЭМВ и ЭМ01			X
		○ 73	X:73	A1-M2.XB:2
		○ 74		
		○ 75		
		○ 76		
		○ 77		
		78		
		○ 79	X:79	KA1:A
		○ 80	X:80	A1-M6.XB:2
		81		
		82		
		○ 83	X:83	SA1:6
		○ 84		
		○ 85		
		○ 86		
		○ 87		
		○ 88	X:88	KA2:A
		○ 89	X:89	A1-M6.XB:4
		90	X:90	KA2:B
		91		
		92	X:92	A1-M7.XB:2
	Цепи ЭМ02			X
		○ 93	X:93	A1-M6.XB:9
		○ 94		
		○ 95		
		○ 96		
		○ 97		
		98		
		○ 99	X:99	SA1:8
		○ 100		
		○ 101		
		○ 102		
		○ 103	X:103	KA3:A
		○ 104	X:104	A1-M6.XB:10
		105	X:105	KA3:B
		106		
		107	X:107	A1-M6.XB:14

Правая боковина (продолжение на листе 1)

		A1-M3.XB:13	X:158	158		
		A1-M3.XB:15	X:159	159		
		K2:11	X:160	160		
		K2:12	X:161	161		
		K2:16	X:162	162		
		K3:11	X:163	163		
		A1-M3.XB:17	X:164	164		
		A1-M3.XB:19	X:165	165		
				166		
				167		
	X	Цепи сигнализации				
	A1-M1.XP:2	X:168	168	○		
			169	○		
			170	○		
			171	○		
			172			
			173			
			174			
			175			
			176			
			177			
			178			
	HL1:2	X:179	179	○		
			180	○		
	X	Цепи РАС				
	A1-M1.XP:5	X:181	181	○		
			182	○		
			183			
	A1-M1.XP:4	X:184	184			
	A1-M1.XP:14	X:185	185			
	X	Цепи освещения				
	SQ1:11	X:186	186	○		
			187	○		
	SQ1:21	X:189	188	○		
			189	○		
	X	Резерв/Транзит				
			190			
			191			
			192			
			193			
			194			
			195			
			196			
			197			
			198			
			199			
			200			
			201			
			202			
			203			
			204			
			205			
			206			
			207			
			208			
			209			
			210			
			211			
			212			
			213			
			214			
			215			
			216			
			217			
			218			
			219			