

Левая боковина (продолжение на листе 2)

		103	X:103	A1-M6.XB-11
		104	X:104	KS6-X1-12
		105	X:105	A1-M6.XB-15
		106	X:106	KS7-X1-12
		107	X:107	A1-M6.XB-17
		108	X:108	A1-M6.XB-19
		109	X:109	A1-M6.XB-21
		110	X:110	A1-M6.XB-23
		111	X:111	A1-M6.XB-25
		112	X:112	A1-M6.XB-27
		113	X:113	A1-M6.XB-29
		114	X:114	A1-M6.XB-31
		115	X:115	A1-M7.XB-1
		116		
		117		
		118		
		119		
		120		
		121		
		122		
		123	X:123	R7-2
		124	X:124	A1-M7.XB-7
	Цепи оперативного тока ТЗ ЛРТ А1		X	
		125	X:125	KS8-X1-1
		126	X:126	A1-M7.XB-31
		127	X:127	A1-M7.XB-11
		128	X:128	KS8-X1-12
		129	X:129	A1-M7.XB-15
		130	X:130	KS9-X1-12
		131	X:131	KS10-X1-12
		132	X:132	A1-M7.XB-19
		133	X:133	A1-M7.XB-21
		134	X:134	A1-M7.XB-23
		135		
		136		
		137	X:137	R10-2
		138	X:138	A1-M7.XB-32
	Цепи ЗДЗ НН1		X	
		139	X:139	A1-M8.XB-3
		140		
		141	X:141	A1-M8.XB-1
		142	X:142	A1-M8.XB-4
		143		
	Цепи ввода НН1		X	
		144	X:144	A1-M8.XB-9
		145		
		146	X:146	A1-M8.XB-5
		147	X:147	A1-M8.XB-7
		148	X:148	A1-M8.XB-10
		149		
	Цепи ЗДЗ НН2		X	
		150	X:150	A1-M8.XB-13
		151		
		152	X:152	A1-M8.XB-11
		153	X:153	A1-M8.XB-14
		154		
	Цепи ввода НН2		X	
		155	X:155	A1-M8.XB-19
		156		
		157	X:157	A1-M8.XB-15
		158	X:158	A1-M8.XB-17
		159	X:159	A1-M8.XB-20
		160		

Правая боковина (продолжение на листе 2)

X	Цепи сигнализации А1			
A1-M1.XP-2	X:281	281		
		282		
		283		
		284		
		285		
		286		
A1-M1.XP-3	X:287	287	X:287	X:355
		288		
		289		
		290		
		291		
		292		
HL1-2	X:293	293		
		294	X:294	X:362
X	Цепи РАС А1			
A1-M1.XP-5	X:295	295		
A1-M1.XP-15	X:296	296		
		297		
A1-M1.XP-4	X:298	298		
A1-M1.XP-14	X:299	299		
		300		
X	Цепи переменного тока А2			
SG10-2	X:301	301		
SG10-4	X:302	302		
SG10-6	X:303	303		
SG10-8	X:304	304		
SG10-10	X:305	305		
SG10-12	X:306	306		
		307		
		308		
SG11-2	X:309	309		
SG11-4	X:310	310		
SG11-6	X:311	311		
SG11-8	X:312	312		
SG11-10	X:313	313		
SG11-12	X:314	314		
		315		
		316		
SG12-2	X:317	317		
SG12-4	X:318	318		
SG12-6	X:319	319		
SG12-8	X:320	320		
SG12-10	X:321	321		
SG12-12	X:322	322		
		323		
		324		
X	Цепи оперативного постоянного тока А2			
SG12-14	X:325	325		
UZ2-1	X:326	326		
A2-M6.XB-10	X:327	327		
UZ2-4	X:328	328		
X	Выходные цепи А2			
A2-M2.XB-2	X:329	329	X:329	X:60
A2-M2.XB-4	X:330	330		
		331		
		332		
SA17-4	X:333	333	X:333	X:63
SA18-4	X:334	334		
		335		
		336		
		337		
		338		

Правая боковина (продолжение на листе 4)