

Левая боковина (продолжение на листе 2)

		103	X:103	A1-M6.XB-11
		104	X:104	KS6-X1-12
		105	X:105	A1-M6.XB-15
		106	X:106	KS7-X1-12
		107	X:107	A1-M6.XB-17
		108	X:108	A1-M6.XB-19
		109	X:109	A1-M6.XB-21
		110	X:110	A1-M6.XB-23
		111	X:111	A1-M6.XB-25
		112	X:112	A1-M6.XB-27
		113	X:113	A1-M6.XB-29
		114	X:114	A1-M6.XB-31
		115	X:115	A1-M7.XB-1
		116		
		117		
		118		
		119		
		120		
		121		
		122		
		123	X:123	R7-2
		124	X:124	A1-M7.XB-7
	Цепи оперативного тока ТЗ ЛРТ А1		X	
		125	X:125	KS8-X1-1
		126	X:126	A1-M7.XB-31
		127	X:127	A1-M7.XB-11
		128	X:128	KS8-X1-12
		129	X:129	A1-M7.XB-15
		130	X:130	KS9-X1-12
		131	X:131	KS10-X1-12
		132	X:132	A1-M7.XB-19
		133	X:133	A1-M7.XB-21
		134	X:134	A1-M7.XB-23
		135		
		136		
		137	X:137	R10-2
		138	X:138	A1-M7.XB-32
	Цепи ЗДЗ НН1		X	
		139	X:139	A1-M8.XB-3
		140		
		141	X:141	A1-M8.XB-1
		142	X:142	A1-M8.XB-4
		143		
	Цепи Ввода НН1		X	
		144	X:144	A1-M8.XB-9
		145		
		146	X:146	A1-M8.XB-5
		147	X:147	A1-M8.XB-7
		148	X:148	A1-M8.XB-10
		149		
	Цепи ЗДЗ НН2		X	
		150	X:150	A1-M8.XB-13
		151		
		152	X:152	A1-M8.XB-11
		153	X:153	A1-M8.XB-14
		154		
	Цепи Ввода НН2		X	
		155	X:155	A1-M8.XB-19
		156		
		157	X:157	A1-M8.XB-15
		158	X:158	A1-M8.XB-17
		159	X:159	A1-M8.XB-20
		160		

Правая боковина (продолжение на листе 2)

	X	Цепи сигнализации А1		
	A1-M1.XP-2	X:281	281	
			282	
			283	
			284	
			285	
			286	
			287	
			288	
			289	
			290	
			291	
			292	
	HL1-2	X:293	293	
			294	
	X	Цепи РАС А1		
	A1-M1.XP-5	X:295	295	
	A1-M1.XP-15	X:296	296	
			297	
	A1-M1.XP-4	X:298	298	
	A1-M1.XP-14	X:299	299	
	X	Цепи освещения		
	SQ1-11	X:300	300	
			301	
	SQ1-21	X:302	302	
			303	
	X	Резерв/Транзит		
			304	
			305	
			306	
			307	
			308	
			309	
			310	
			311	
			312	
			313	
			314	
			315	
			316	
			317	
			318	
			319	
			320	
			321	
			322	
			323	
			324	
			325	
			326	
			327	
			328	
			329	
			330	
			331	
			332	
			333	