

Левая боковина (начало)						
	Цепи переменного тока			X		
		1	X:1	SG1:2	#	
		2	X:2	SG1:4	#	
		3	X:3	SG1:6	#	
		4	X:4	SG1:8	#	
		5	X:5	SG1:10	#	
		6	X:6	SG1:12	#	
			7			
			8			
	Цепи переменного напряжения			X		
		9	X:9	SG2:2	+	
		10	X:10	SG2:4	+	
		11	X:11	SG2:6	+	
		12	X:12	SG2:8	+	
		13	X:13	SG3:2	+	
		14	X:14	SG3:4	+	
		15	X:15	SG3:6	+	
		16	X:16	SG3:8	+	
	Цепи переменного напряжения 0В			X		
		17	X:17	SG4:2	+	
		18	X:18	SG4:4	+	
		19	X:19	SG4:6	+	
		20	X:20	SG4:8	+	
		21	X:21	SG5:2	+	
		22	X:22	SG5:4	+	
		23	X:23	SG5:6	+	
		24	X:24	SG5:8	+	
	Цепи напряжения НН			X		
		25	X:25	SG4:2	+	
		26	X:26	SG4:4	+	
		27	X:27	SG4:6	+	
		28	X:28	SG4:8	+	
	Цепи оперативного тока терминала			X		
			29	X:29	UZ1:1	+
			30	X:30	SG1:14	—
			31			
			32			
			33			
			34			
			35			
			36			
			37			
			38			
		39	X:39	A1-M9.XB:1	—	
		40	X:40	A1-M9.XB:3	—	
		41	X:41	A1-M9.XB:5	—	
		42	X:42	A1-M9.XB:7	—	
		43	X:43	A1-M9.XB:9	—	
		44	X:44	A1-M9.XB:11	—	
		45	X:45	A1-M9.XB:13	—	

Левая боковина (продолжение на листе 2)

Правая боковина (начало)				
X	Цепи сигнализации			
A1-M1.XP:2	X:261	261		
		262		
		263		
		264		
		265		
		266		
		267		
		268		
		269		
		270		
		271		
		272		
HL1:2	X:273	273		
		274		
X	Цепи регистрации			
A1-M1.XP:5	X:275	275		
A1-M1.XP:15	X:276	276		
		277		
A1-M1.XP:4	X:278	278		
A1-M1.XP:14	X:279	279		
X	Цепи освещения			
SQ1:11	X:280	280		
		281		
SQ1:21	X:282	282		
		283		
X	Резерв/Транзит			
		284		
		285		
		286		
		287		
		288		
		289		
		290		
		291		
		292		
		293		
		294		
		295		
		296		
		297		
		298		
		299		
		300		
		301		
		302		
		303		
		304		
		305		
		306		
		307		

Правая боковина (продолжение на листе 2)

Условные обозначения

