

Левая баковина (продолжение на листе 1)

		46	X:46	A1-M9.XB-15	
		47	X:47	A1-M9.XB-17	
		48	X:48	A1-M9.XB-19	
		49			
		50			
		51			
		52			
		53			
		54			
		55			
		56			
		57			
		58			
		59	X:59	UZ14	
		60	X:60	A1-M6.XB-18	
	Выходные цепи			X	
		61	X:61	A1-M2.XB-2	
		62	X:62	A1-M2.XB-4	
		63	X:63	A1-M2.XB-6	
		64	X:64	A1-M2.XB-8	
		65	X:65	A1-M2.XB-10	
		66	X:66	A1-M2.XB-12	
		67	X:67	A1-M2.XB-14	
		68	X:68	A1-M2.XB-16	
		69	X:69	A1-M2.XB-18	
		70	X:70	A1-M2.XB-20	
		71	X:71	A1-M2.XB-22	
		72	X:72	A1-M2.XB-24	
		73	X:73	A1-M2.XB-26	
		74	X:74	A1-M2.XB-28	
		75	X:75	A1-M2.XB-30	
		76	X:76	A1-M2.XB-32	
		77	X:77	A1-M3.XB-2	
		78	X:78	A1-M3.XB-4	
		79	X:79	A1-M3.XB-6	
		80	X:80	A1-M3.XB-8	
		81	X:81	A1-M3.XB-10	
		82	X:82	A1-M3.XB-12	
		83	X:83	A1-M3.XB-14	
		84	X:84	A1-M3.XB-16	
		85	X:85	A1-M3.XB-18	
		86	X:86	A1-M3.XB-20	
		87	X:87	A1-M3.XB-22	
		88	X:88	A1-M3.XB-24	
		89	X:89	A1-M3.XB-26	
		90	X:90	A1-M3.XB-28	
		91	X:91	A1-M3.XB-30	
		92	X:92	A1-M3.XB-32	
		93	X:93	A1-M4.XB-2	
		94	X:94	A1-M4.XB-4	
		95	X:95	A1-M4.XB-6	
		96	X:96	A1-M4.XB-8	
		97	X:97	A1-M4.XB-10	
		98	X:98	A1-M4.XB-12	
		99	X:99	A1-M4.XB-14	
		100	X:100	A1-M4.XB-16	
		101	X:101	A1-M4.XB-18	
		102	X:102	A1-M4.XB-20	
		103	X:103	A1-M4.XB-22	
		104	X:104	A1-M4.XB-24	
		105	X:105	A1-M4.XB-26	
		106	X:106	A1-M4.XB-28	
		107	X:107	A1-M4.XB-30	
		108	X:108	A1-M4.XB-32	
		109	X:109	A1-M5.XB-2	
		110	X:110	A1-M5.XB-4	
		111	X:111	A1-M5.XB-6	
		112	X:112	A1-M5.XB-8	
		113	X:113	A1-M5.XB-10	
		114	X:114	A1-M5.XB-12	
		115	X:115	A1-M5.XB-14	

Левая баковина (продолжение на листе 3)

Правая баковина (продолжение на листе 1)

		308		
		309		
		310		
		311		
		312		
		313		