

Левая боковина (продолжение на листе 1)

		47		
		48		
		49		
		50		
		51		
		52		
		53		
		54	X:54	UZ14
		55	X:55	A1-M6.XB-8
	Выходные цепи		X	
		56	X:56	A1-M2.XB-2
		57	X:57	A1-M3.XB-14
		58	X:58	A1-M3.XB-16
		59	X:59	A1-M2.XB-4
		60	X:60	A1-M3.XB-18
		61	X:61	A1-M3.XB-20
		62	X:62	A1-M2.XB-6
		63	X:63	A1-M2.XB-8
		64	X:64	A1-M2.XB-10
		65	X:65	A1-M3.XB-22
		66	X:66	A1-M3.XB-24
		67	X:67	A1-M2.XB-12
		68	X:68	A1-M3.XB-26
		69	X:69	A1-M3.XB-28
		70	X:70	A1-M2.XB-14
		71	X:71	A1-M2.XB-16
		72	X:72	A1-M2.XB-18
		73	X:73	A1-M3.XB-30
		74	X:74	A1-M3.XB-32
		75	X:75	A1-M2.XB-20
		76	X:76	A1-M4.XB-2
		77	X:77	A1-M4.XB-4
		78	X:78	A1-M2.XB-22
		79	X:79	A1-M2.XB-24
		80	X:80	A1-M2.XB-26
		81	X:81	A1-M4.XB-6
		82	X:82	A1-M4.XB-8
		83	X:83	A1-M2.XB-28
		84	X:84	A1-M4.XB-10
		85	X:85	A1-M4.XB-12
		86	X:86	A1-M2.XB-30
		87	X:87	A1-M2.XB-32
		88	X:88	A1-M3.XB-2
		89	X:89	A1-M3.XB-4
		90	X:90	A1-M3.XB-6
		91	X:91	A1-M3.XB-8
		92	X:92	A1-M3.XB-10
		93	X:93	A1-M3.XB-12
		94		
		95		
		96	X:96	SA14
		97	X:97	SA16
		98	X:98	SA18
		99	X:99	SA110
		100	X:100	SA112
		101	X:101	SA114
		102	X:102	SA116
		103	X:103	SA2-4
		104	X:104	SA3-4
		105	X:105	SA3-6
		106	X:106	SA3-8
		107	X:107	SA3-10
		108	X:108	SA3-12
		109	X:109	SA3-14
		110	X:110	SA3-16
		111	X:111	SA4-4
		112	X:112	SA5-4
		113	X:113	SA5-6
		114	X:114	SA5-8
		115	X:115	SA5-10

Левая боковина (продолжение на листе 3)