

Левая доковина (начало)					
Цепи переменного тока /ЛЭП				Х	
		1	X:1	SG1:2	≠
		2	X:2	SG1:4	≠
		3	X:3	SG1:6	≠
		4	X:4	SG1:8	≠
		5	X:5	SG1:10	≠
		6	X:6	SG1:12	≠
		7			
		8			
Цепи напряжения рабочей СШ				Х	
		9	X:9	SG2:2	+
		10	X:10	SG2:4	+
		11	X:11	SG2:6	+
		12	X:12	SG2:8	+
		13	X:13	SG3:2	+
		14	X:14	SG3:4	+
		15	X:15	SG3:6	+
		16	X:16	SG3:8	+
Цепи напряжения ОСШ				Х	
		17	X:17	SG4:2	+
		18	X:18	SG4:4	+
		19	X:19	SG4:6	+
		20	X:20	SG4:8	+
Цепи оперативного тока				Х	
		21	X:21	UZ1:1	+
		22	X:22	SG1:14	—
		23			
		24			
		25			
		26			
		27			
		28	X:28	A1-M5.XB:1	—
		29			
		30	X:30	A1-M5.XB:3	—
		31			
		32	X:32	A1-M5.XB:5	—
		33			
		34			
		35			
		36	X:36	A1-M5.XB:7	—
		37			
		38			
		39			
		40	X:40	A1-M5.XB:9	—
		41	X:41	A1-M5.XB:11	—
		42			
		43			
		44			

Левая доковина (продолжение на листе 2)

Правая доковина (начало)					
Х	Выходные цепи				
A1-M2.XB:8	X:109	109			
A1-M2.XB:10	X:110	110			
A1-M2.XB:12	X:111	111			
A1-M2.XB:14	X:112	112			
A1-M2.XB:16	X:113	113			
A1-M2.XB:18	X:114	114			
A1-M2.XB:20	X:115	115			
A1-M2.XB:22	X:116	116			
A1-M2.XB:24	X:117	117			
A1-M2.XB:26	X:118	118			
SA5:9	X:119	119			
SA5:13	X:120	120			
SA5:17	X:121	121			
A1-M2.XB:32	X:122	122			
A1-M3.XB:2	X:123	123			
K2:9	X:124	124			
K2:10	X:125	125			
K2:14	X:126	126			
K3:9	X:127	127			
A1-M3.XB:4	X:128	128			
A1-M3.XB:6	X:129	129			
		130			
		131			
		132			
		133			
		134			
		135			
		136			
		137			
SA2:4	X:138	138			
SA2:6	X:139	139			
SA2:8	X:140	140			
SA2:10	X:141	141			
SA3:4	X:142	142			
SA3:6	X:143	143			
SA4:4	X:144	144			
SA4:6	X:145	145			
SA4:8	X:146	146			
SA4:10	X:147	147			
SA5:10	X:148	148			
SA5:14	X:149	149			
SA5:18	X:150	150			
A1-M2.XB:31	X:151	151			
A1-M3.XB:1	X:152	152			
K2:11	X:153	153			
K2:12	X:154	154			
K2:16	X:155	155			
K3:11	X:156	156			
A1-M3.XB:3	X:157	157			
A1-M3.XB:5	X:158	158			

Правая доковина (продолжение на листе 2)

Условные обозначения

