

6

Левая боковина (начало)				
	Цепи переменного тока /ЛЭП			X
		1	X-1	SG1-2
		2	X-2	SG1-4
		3	X-3	SG1-6
		4	X-4	SG1-8
		5	X-5	SG1-10
		6	X-6	SG1-12
		7		
		8		
	Цепи переменного напряжения			X
		9	X-9	SG2-2
		10	X-10	SG2-4
		11	X-11	SG2-6
		12	X-12	SG2-8
	Цепи отбора напряжения			X
		13	X-13	SG3-2
		14	X-14	SG3-4
		15	X-15	SG3-6
	Цепи оперативного тока			X
		16	X-16	UZ11
		17	X-17	SG1-14
		18		
		19		
		20		
		21		
		22		
		23	X-23	A1-M5.XB-1
		24		
		25		
		26	X-26	A1-M5.XB-3
		27		
		28		
		29	X-29	A1-M5.XB-5
		30		
		31		
		32		
		33		
		34		
		35	X-35	A1-M5.XB-7
		36		
		37	X-37	A1-M5.XB-9
		38	X-38	A1-M5.XB-11
		39		
		40		
		41		
		42		
		43		
		44		

Левая боковина (продолжение на листе 2)

Правая боковина (начало)				
X	Выходные цепи			
A1-M2.XB-8	X-104	104		
A1-M2.XB-10	X-105	105		
A1-M2.XB-12	X-106	106		
A1-M2.XB-14	X-107	107		
A1-M2.XB-16	X-108	108		
A1-M2.XB-18	X-109	109		
A1-M2.XB-24	X-110	110		
A1-M2.XB-26	X-111	111		
A1-M2.XB-28	X-112	112		
A1-M2.XB-30	X-113	113		
A1-M2.XB-32	X-114	114		
A1-M3.XB-2	X-115	115		
SA5-9	X-116	116		
SA5-13	X-117	117		
SA5-17	X-118	118		
A1-M3.XB-4	X-119	119		
A1-M3.XB-6	X-120	120		
K2-1	X-121	121		
K2-2	X-122	122		
K2-5	X-123	123		
K3-1	X-124	124		
K2-9	X-125	125		
K2-10	X-126	126		
K2-14	X-127	127		
K3-9	X-128	128		
K3-10	X-129	129		
K3-14	X-130	130		
A1-M3.XB-8	X-131	131		
A1-M3.XB-10	X-132	132		
		133		
		134		
		135		
		136		
		137		
		138		
		139		
		140		
		141		
SA2-4	X-142	142		
SA2-6	X-143	143		
SA2-8	X-144	144		
SA2-10	X-145	145		
SA4-4	X-146	146		
SA4-6	X-147	147		
SA3-4	X-148	148		
SA3-6	X-149	149		
SA3-8	X-150	150		
SA3-10	X-151	151		
SA3-12	X-152	152		
SA2-6	X-153	153		

Правая боковина (продолжение на листе 2)

Условные обозначения

