

Левая боковина (продолжение на листе 1)

		45			
		46			
		47			
		48	X:48	UZ1:4	
		49	X:49	A1-M6.XB:28	
	Цепи сигнализации выключателя/ТТ			X	
		50	X:50	A1-M5.XB:13	
		51			
		52	X:52	A1-M5.XB:15	
		53	X:53	A1-M5.XB:17	
		54	X:54	A1-M5.XB:19	
		55	X:55	A1-M5.XB:21	
		56	X:56	A1-M5.XB:23	
		57	X:57	A1-M5.XB:25	
		58	X:58	A1-M5.XB:27	
		59	X:59	A1-M5.XB:29	
		60	X:60	A1-M5.XB:21	
		61	X:61	A1-M5.XB:19	
		62			
		63			
		64			
		65			
		66			
		67	X:67	A1-M5.XB:30	
		68			
	Цепи ЭМВ и ЭМ01			X	
		69	X:69	A1-M5.XB:31	
		70			
		71			
		72			
		73			
		74			
		75	X:75	KA1:A	
		76	X:76	A1-M5.XB:32	
		77			
		78			
		79	X:79	SA1:6	
		80			
		81			
		82			
		83	X:83	KA2:A	
		84	X:84	A1-M6.XB:2	
		85			
		86	X:86	KA2:B	
		87			
		88	X:88	A1-M6.XB:30	
	Цепи ЭМ02			X	
		89	X:89	A1-M6.XB:7	
		90			
		91			
		92			
		93			
		94			
		95	X:95	SA1:8	
		96			
		97			
		98			
		99	X:99	KA3:A	
		100	X:100	A1-M6.XB:8	
		101	X:101	KA3:B	
		102			
		103	X:103	A1-M6.XB:12	

Правая боковина (продолжение на листе 1)

	SA5:10	X:154	154		
	SA5:14	X:155	155		
	SA5:18	X:156	156		
	A1-M3.XB:3	X:157	157		
	A1-M3.XB:5	X:158	158		
	K2:3	X:159	159		
	K2:4	X:160	160		
	K2:7	X:161	161		
	K3:3	X:162	162		
	K2:11	X:163	163		
	K2:12	X:164	164		
	K2:16	X:165	165		
	K3:11	X:166	166		
	K3:12	X:167	167		
	K3:16	X:168	168		
	A1-M3.XB:7	X:169	169		
	A1-M3.XB:9	X:170	170		
			171		
			172		
			173		
			174		
			175		
			176		
			177		
			178		
			179		
			180		
			181		
			182		
			183		
	X	Цепи сигнализации			
	A1-M1.XP:2	X:184	184		
			185		
			186		
			187		
			188		
			189		
			190		
			191		
			192		
			193		
			194		
			195		
	HL1:2	X:196	196		
			197		
	X	Цепи регистрации			
	A1-M1.XP:5	X:198	198		
	A1-M1.XP:15	X:199	199		
			200		
	A1-M1.XP:4	X:201	201		
	A1-M1.XP:14	X:202	202		
	X	Цепи освещения			
	SQ1:11	X:203	203		
		X:204	204		
	SQ1:21	X:205	205		
		X:206	206		
	X	Резерв/Транзит			
			207		
			208		
			209		
			210		
			211		
			212		
			213		
			214		
			215		
			216		

Правая боковина (продолжение на листе 3)