

Левая боковина (начало)					
	Цепи переменного тока /ЛЭП			X	
		1	X:1	SG1:2	≠
		2	X:2	SG1:4	≠
		3	X:3	SG1:6	≠
		4	X:4	SG1:8	≠
		5	X:5	SG1:10	≠
		6	X:6	SG1:12	≠
		7			
		8			
	Цепи переменного напряжения			X	
		9	X:9	SG2:2	≠
		10	X:10	SG2:4	≠
	Цепи переменного напряжения			X	
		11	X:11	SG3:2	+
		12	X:12	SG3:4	+
		13	X:13	SG3:6	+
		14	X:14	SG3:8	+
		15	X:15	SG4:2	+
		16	X:16	SG4:4	+
		17	X:17	SG4:6	+
		18	X:18	SG4:8	+
	Цепи отбора напряжения			X	
		19	X:19	SG5:2	+
		20	X:20	SG5:4	+
		21	X:21	SG5:6	+
	Цепи оперативного тока			X	
		22	X:22	UZ1:1	+
		23	X:23	SG1:14	—
		24			
		25			
		26			
		27			
		28			
		29	X:29	A1-M5.XB:1	—
		30	X:30	A1-M5.XB:3	—
		31	X:31	A1-M5.XB:5	—
		32	X:32	A1-M5.XB:7	—
		33	X:33	A1-M5.XB:9	—
		34	X:34	A1-M5.XB:11	—
		35	X:35	A1-M5.XB:13	—
		36			
		37			
		38	X:38	A1-M5.XB:15	—
		39			
		40			

Левая боковина (продолжение на листе 2)

Правая боковина (начало)				
Х	Выходные цепи			
A1-M2.XB:2	X:120	120		
A1-M2.XB:4	X:121	121		
A1-M2.XB:6	X:122	122		
A1-M2.XB:8	X:123	123		
A1-M2.XB:10	X:124	124		
A1-M2.XB:12	X:125	125		
A1-M2.XB:20	X:126	126		
A1-M2.XB:22	X:127	127		
A1-M2.XB:24	X:128	128		
A1-M2.XB:26	X:129	129		
A1-M2.XB:28	X:130	130		
K2:1	X:131	131		
K2:2	X:132	132		
K2:9	X:133	133		
K2:10	X:134	134		
A1-M3.XB:2	X:135	135		
A1-M3.XB:4	X:136	136		
SA7:9	X:137	137		
SA7:13	X:138	138		
SA7:17	X:139	139		
A1-M3.XB:6	X:140	140		
A1-M3.XB:8	X:141	141		
A1-M3.XB:10	X:142	142		
A1-M3.XB:12	X:143	143		
		144		
		145		
		146		
		147		
		148		
		149		
		150		
		151		
		152		
		153		
SA4:4	X:154	154		
SA5:4	X:155	155		
SA3:4	X:156	156		
SA3:6	X:157	157		
SA3:8	X:158	158		
SA3:10	X:159	159		
SA2:4	X:160	160		
SA2:6	X:161	161		
SA2:8	X:162	162		
SA6:4	X:163	163		
SA6:6	X:164	164		
K2:3	X:165	165		
K2:4	X:166	166		
K2:11	X:167	167		

Правая боковина (продолжение на листе 2)

Условные обозначения

