

Левая доковина (продолжение на листе 1)

		41	X:41	A1-M5.XB-3
		42	X:42	A1-M5.XB-5
		43	X:43	A1-M5.XB-7
		44	X:44	A1-M5.XB-9
		45	X:45	A1-M5.XB-11
		46		
		47	X:47	UZ14
		48	X:48	A1-M6.XB-18
	Цепи оперативного тока ГЗ			X
		49	X:49	KS1-X1:1
		50	X:50	A1-M5.XB-23
		51	X:51	A1-M5.XB-13
		52	X:52	KS1-X1:12
		53	X:53	KS2-X1:12
		54		
		55		
		56		
		57	X:57	A1-M5.XB-14
		58	X:58	R2-2
	Цепи ввода НН1 (НН)			X
		59	X:59	A1-M5.XB-29
		60		
		61	X:61	A1-M5.XB-25
		62	X:62	A1-M5.XB-27
		63	X:63	A1-M5.XB-26
		64		
	Цепи ввода НН2			X
		65	X:65	A1-M6.XB-3
		66		
		67	X:67	A1-M5.XB-31
		68	X:68	A1-M6.XB-1
		69	X:69	A1-M5.XB-32
		70		
	Цепи ввода СН (ННЗ)			X
		71	X:71	A1-M6.XB-9
		72		
		73	X:73	A1-M6.XB-5
		74	X:74	A1-M6.XB-7
		75	X:75	A1-M6.XB-6
		76		
	Цепи ввода НН4			X
		77	X:77	A1-M6.XB-15
		78		
		79	X:79	A1-M6.XB-11
		80	X:80	A1-M6.XB-13
		81	X:81	A1-M6.XB-12
		82		
	Выходные цепи			X
		83	X:83	A1-M2.XB-2
		84	X:84	A1-M2.XB-4
		85	X:85	A1-M2.XB-6
		86	X:86	A1-M2.XB-8
		87	X:87	A1-M2.XB-10
		88	X:88	A1-M2.XB-12
		89	X:89	A1-M2.XB-14
		90	X:90	A1-M2.XB-16
		91	X:91	A1-M2.XB-18
		92	X:92	A1-M2.XB-20
		93	X:93	A1-M2.XB-22
		94	X:94	A1-M2.XB-24
		95	X:95	A1-M2.XB-26
		96	X:96	A1-M2.XB-28
		97	X:97	A1-M2.XB-30
		98	X:98	A1-M2.XB-32

Левая доковина (продолжение на листе 3)