

		47			
		48			
		49			
		50			
		51			
		52			
		53			
		54	X:54	UZ1:4	
		55	X:55	A1-M6.XB:8	
	Выходные цепи			X	
		56	X:56	A1-M2.XB:2	
		57	X:57	A1-M3.XB:14	
		58	X:58	A1-M3.XB:16	
		59	X:59	A1-M2.XB:4	
		60	X:60	A1-M3.XB:18	
		61	X:61	A1-M3.XB:20	
		62	X:62	A1-M2.XB:6	
		63	X:63	A1-M2.XB:8	
		64	X:64	A1-M2.XB:10	
		65	X:65	A1-M3.XB:22	
		66	X:66	A1-M3.XB:24	
		67	X:67	A1-M2.XB:12	
		68	X:68	A1-M3.XB:26	
		69	X:69	A1-M3.XB:28	
		70	X:70	A1-M2.XB:14	
		71	X:71	A1-M2.XB:16	
		72	X:72	A1-M2.XB:18	
		73	X:73	A1-M3.XB:30	
		74	X:74	A1-M3.XB:32	
		75	X:75	A1-M2.XB:20	
		76	X:76	A1-M4.XB:2	
		77	X:77	A1-M4.XB:4	
		78	X:78	A1-M2.XB:22	
		79	X:79	A1-M2.XB:24	
		80	X:80	A1-M2.XB:26	
		81	X:81	A1-M4.XB:6	
		82	X:82	A1-M4.XB:8	
		83	X:83	A1-M2.XB:28	
		84	X:84	A1-M4.XB:10	
		85	X:85	A1-M4.XB:12	
		86	X:86	A1-M2.XB:30	
		87	X:87	A1-M2.XB:32	
		88	X:88	A1-M3.XB:2	
		89	X:89	A1-M3.XB:4	
		90	X:90	A1-M3.XB:6	
		91	X:91	A1-M3.XB:8	
		92	X:92	A1-M3.XB:10	
		93	X:93	A1-M3.XB:12	
		94			
		95			
		96	X:96	SA1:4	
		97	X:97	SA1:6	
		98	X:98	SA1:8	
		99	X:99	SA1:10	
		100	X:100	SA1:12	
		101	X:101	SA1:14	
		102	X:102	SA1:16	
		103	X:103	SA2:4	
		104	X:104	SA3:4	
		105	X:105	SA3:6	
		106	X:106	SA3:8	
		107	X:107	SA3:10	
		108	X:108	SA3:12	
		109	X:109	SA3:14	
		110	X:110	SA3:16	
		111	X:111	SA4:4	
		112	X:112	SA5:4	
		113	X:113	SA5:6	
		114	X:114	SA5:8	
		115	X:115	SA5:10	