

Левая доковина (начало)

	Цепи переменного тока /ЭЗП			X	
		1	X:1	SG1:2	≠
		2	X:2	SG1:4	≠
		3	X:3	SG1:6	≠
		4	X:4	SG1:8	≠
		5	X:5	SG1:10	≠
		6	X:6	SG1:12	≠
		7			
		8			
	Цепи переменного напряжения			X	
		9	X:9	SG2:2	+
		10	X:10	SG2:4	+
		11	X:11	SG2:6	+
		12	X:12	SG2:8	+
		13	X:13	SG3:2	+
		14	X:14	SG3:4	+
		15	X:15	SG3:6	+
		16	X:16	SG3:8	+
	Цепи напряжения ОСШ			X	
		17	X:17	SG4:2	+
		18	X:18	SG4:4	+
		19	X:19	SG4:6	+
	Цепи оперативного тока			X	
		20	X:20	UZ1:1	+
		21	X:21	SG1:14	—
		22			
		23			
		24			
		25			
		26			
		27	X:27	A1-M5.XB:1	—
		28			
		29			
		30	X:30	A1-M5.XB:3	—
		31			
		32			
		33	X:33	A1-M5.XB:5	—
		34			
		35	X:35	A1-M5.XB:7	—
		36	X:36	A1-M5.XB:9	—
		37	X:37	A1-M5.XB:11	—
		38	X:38	A1-M5.XB:13	—
		39			
		40			
		41			
		42			
		43			
		44			

Левая доковина (продолжение на листе 2)

Правая доковина (начало)

X	Выходные цепи			
A1-M2.XB:8	X:108	108		
A1-M2.XB:10	X:109	109		
A1-M2.XB:12	X:110	110		
A1-M2.XB:14	X:111	111		
A1-M2.XB:16	X:112	112		
A1-M2.XB:18	X:113	113		
A1-M2.XB:20	X:114	114		
A1-M2.XB:22	X:115	115		
A1-M2.XB:24	X:116	116		
A1-M2.XB:26	X:117	117		
A1-M2.XB:28	X:118	118		
A1-M2.XB:30	X:119	119		
A1-M3.XB:4	X:120	120		
A1-M3.XB:6	X:121	121		
A1-M3.XB:8	X:122	122		
A1-M3.XB:10	X:123	123		
A1-M3.XB:12	X:124	124		
SA5:9	X:125	125		
SA5:13	X:126	126		
SA5:17	X:127	127		
A1-M3.XB:14	X:128	128		
A1-M3.XB:16	X:129	129		
K2:9	X:130	130		
K2:10	X:131	131		
K2:14	X:132	132		
K3:9	X:133	133		
A1-M3.XB:18	X:134	134		
A1-M3.XB:20	X:135	135		
		136		
		137		
SA2:4	X:138	138		
SA2:6	X:139	139		
SA2:8	X:140	140		
SA2:10	X:141	141		
SA2:12	X:142	142		
SA2:14	X:143	143		
SA4:4	X:144	144		
SA4:6	X:145	145		
SA3:4	X:146	146		
SA3:6	X:147	147		
SA3:8	X:148	148		
SA3:10	X:149	149		
SA3:12	X:150	150		
SA3:14	X:151	151		
SA3:16	X:152	152		
SA3:18	X:153	153		
SA3:20	X:154	154		
SA5:10	X:155	155		
SA5:14	X:156	156		
SA5:18	X:157	157		

Правая доковина (продолжение на листе 2)

Условные обозначения

