

Левая доковина (продолжение на листе 1)

		45		
		46		
		47		
		48		
		49		
		50		
		51		
		○ 52	X:52	UZ1:4
		○ 53	X:53	A1-M6.XB:28
	Цепи сигнализации выключателя/ТТ		X	
		○ 54	X:54	A1-M5.XB:15
		○ 55		
		56	X:56	A1-M5.XB:17
		57	X:57	A1-M5.XB:19
		58	X:58	A1-M5.XB:21
		59	X:59	A1-M5.XB:23
		60	X:60	A1-M5.XB:25
		61	X:61	A1-M5.XB:27
		62	X:62	A1-M5.XB:29
		63	X:63	A1-M5.XB:31
		64	X:64	A1-M3.XB:2
		65	X:65	A1-M3.XB:32
		66		
		67		
		68		
		69		
		70		
		○ 71	X:71	A1-M5.XB:30
		○ 72		
	Цепи ЭМВ и ЭМ01		X	
		○ 73	X:73	A1-M2.XB:2
		○ 74		
		○ 75		
		○ 76		
		○ 77		
		78		
		○ 79	X:79	KA1:A
		○ 80	X:80	A1-M6.XB:2
		81		
		82		
		○ 83	X:83	SA1:6
		○ 84		
		○ 85		
		○ 86		
		○ 87		
		○ 88	X:88	KA2:A
		○ 89	X:89	A1-M6.XB:4
		90	X:90	KA2:B
		91		
		92	X:92	A1-M7.XB:2
	Цепи ЭМ02		X	
		○ 93	X:93	A1-M6.XB:9
		○ 94		
		○ 95		
		○ 96		
		○ 97		
		98		
		○ 99	X:99	SA1:8
		○ 100		
		○ 101		
		○ 102		
		○ 103	X:103	KA3:A
		○ 104	X:104	A1-M6.XB:10
		105	X:105	KA3:B
		106		
		107	X:107	A1-M6.XB:14

Правая доковина (продолжение на листе 1)

	A1-M3.XB:13	X:158	158		
	A1-M3.XB:15	X:159	159		
	K2:11	X:160	160		
	K2:12	X:161	161		
	K2:16	X:162	162		
	K3:11	X:163	163		
	A1-M3.XB:17	X:164	164		
	A1-M3.XB:19	X:165	165		
			166		
			167		
	X	Цепи сигнализации			
	A1-M1.XP:2	X:168	168 ○		
			169 ○		
			170 ○		
			171 ○		
			172		
			173		
			174		
			175		
			176		
			177		
			178		
	HL1:2	X:179	179 ○		
			180 ○		
	X	Цепи РАС			
	A1-M1.XP:5	X:181	181 ○		
			182 ○		
			183		
	A1-M1.XP:4	X:184	184		
	A1-M1.XP:14	X:185	185		
	X	Цепи освещения			
	SQ1:11	X:186	186 ○		
			187 ○		
	SQ1:21	X:189	188 ○		
			189 ○		
	X	Резерв/Транзит			
			190		
			191		
			192		
			193		
			194		
			195		
			196		
			197		
			198		
			199		
			200		
			201		
			202		
			203		
			204		
			205		
			206		
			207		
			208		
			209		
			210		
			211		
			212		
			213		
			214		
			215		
			216		
			217		
			218		
			219		

WE2

кч

с