

		45		
		46		
		47		
		48		
		49		
		50		
		51		
		52		
		53	X:53	UZ1:4
		54	X:54	A1-M6.XB:28
	Цепи сигнализации выключателя/ТТ		X	
		55	X:55	A1-M5.XB:15
		56		
		57	X:56	A1-M5.XB:17
		58	X:57	A1-M5.XB:19
		59	X:58	A1-M5.XB:21
		60	X:59	A1-M5.XB:23
		61	X:60	A1-M5.XB:25
		62	X:61	A1-M5.XB:27
		63	X:62	A1-M5.XB:29
		64	X:63	A1-M5.XB:31
		65	X:64	A1-M3.XB:2
		66	X:65	A1-M3.XB:32
		67		
		68		
		69		
		70		
		71		
		72	X:72	A1-M5.XB:30
		73		
	Цепи ЭМВ и ЭМ01		X	
		74	X:74	A1-M2.XB:2
		75		
		76		
		77		
		78		
		79		
		80	X:80	KA1:A
		81	X:81	A1-M6.XB:2
		82	X:82	KA1:B
		83		
		84	X:84	SA1:6
		85		
		86		
		87		
		88		
		89	X:89	KA2:A
		90	X:90	A1-M6.XB:4
		91	X:91	KA2:B
		92		
		93	X:93	A1-M6.XB:32
	Цепи ЭМ02		X	
		94	X:94	A1-M6.XB:9
		95		
		96		
		97		
		98		
		99		
		100	X:100	SA1:8
		101		
		102		
		103		
		104	X:104	KA3:A
		105	X:105	A1-M6.XB:10
		106	X:106	KA3:B
		107		
		108	X:108	A1-M6.XB:14

		159		
		160		
		161		
		162		
		163		
		164		
		165		
		166		
		167		
		168		
X	Цепи сигнализации			
A1-M1.XP:2	X:169	169		
		170		
		171		
		172		
		173		
		174		
		175		
		176		
		177		
		178		
		179		
		180		
HL1:2	X:181	181		
		182		
X	Цепи РАС			
A1-M1.XP:5	X:183	183		
		184		
		185		
A1-M1.XP:4	X:186	186		
A1-M1XP:14	X:187	187		
X	Цепи освещения			
SQ1:11	X:188	188		
		189		
SQ1:21	X:190	190		
		191		
X	Резерв/Транзит			
		192		
		193		
		194		
		195		
		196		
		197		
		198		
		199		
		200		
		201		

WE2

кч
с

