

Левая доковина (начало)

	Цепи переменного тока /ЛЭП			X
		1	X:1	SG1:2
		2	X:2	SG1:4
		3	X:3	SG1:6
		4	X:4	SG1:8
		5	X:5	SG1:10
		6	X:6	SG1:12
		7		
		8		
	Цепи переменного напряжения			X
		9	X:9	SG2:2
		10	X:10	SG2:4
		11	X:11	SG2:6
		12	X:12	SG2:8
	Цепи отбора напряжения			X
		13	X:13	SG3:2
		14	X:14	SG3:4
		15	X:15	SG3:6
	Цепи оперативного тока			X
		16	X:16	UZ1:1
		17	X:17	SG1:14
		18		
		19		
		20		
		21		
		22		
		23	X:23	A1-M5.XB:1
		24		
		25		
		26	X:26	A1-M5.XB:3
		27		
		28		
		29	X:29	A1-M5.XB:5
		30		
		31		
		32		
		33		
		34		
		35	X:35	A1-M5.XB:7
		36		
		37	X:37	A1-M5.XB:9
		38	X:38	A1-M5.XB:11
		39		
		40		
		41		
		42		
		43		
		44		

Левая доковина (продолжение на листе 2)

Правая доковина (начало)

X	Выходные цепи			
A1-M2.XB:8	X:104	104		
A1-M2.XB:10	X:105	105		
A1-M2.XB:12	X:106	106		
A1-M2.XB:14	X:107	107		
A1-M2.XB:16	X:108	108		
A1-M2.XB:18	X:109	109		
A1-M2.XB:24	X:110	110		
A1-M2.XB:26	X:111	111		
A1-M2.XB:28	X:112	112		
A1-M2.XB:30	X:113	113		
A1-M2.XB:32	X:114	114		
A1-M3.XB:2	X:115	115		
SA5:9	X:116	116		
SA5:13	X:117	117		
SA5:17	X:118	118		
A1-M3.XB:4	X:119	119		
A1-M3.XB:6	X:120	120		
K2:1	X:121	121		
K2:2	X:122	122		
K2:5	X:123	123		
K3:1	X:124	124		
K2:9	X:125	125		
K2:10	X:126	126		
K2:14	X:127	127		
K3:9	X:128	128		
K3:10	X:129	129		
K3:14	X:130	130		
A1-M3.XB:8	X:131	131		
A1-M3.XB:10	X:132	132		
		133		
		134		
		135		
		136		
		137		
		138		
		139		
		140		
		141		
SA2:4	X:142	142		
SA2:6	X:143	143		
SA2:8	X:144	144		
SA2:10	X:145	145		
SA4:4	X:146	146		
SA4:6	X:147	147		
SA3:4	X:148	148		
SA3:6	X:149	149		
SA3:8	X:150	150		
SA3:10	X:151	151		
SA3:12	X:152	152		
SA2:6	X:153	153		

Правая доковина (продолжение на листе 2)

Условные обозначения

