

		42			
		43			
		44			
		45			
		46			
		47			
		48			
		49			
		50			
		51			
		52			
		53			
		54	X:54	UZ14	↗
		55	X:55	A1-M5.XB:28	—
	Выходные цепи			X	
		56	X:56	A1-M2.XB:2	—
		57	X:57	A1-M2.XB:4	—
		58	X:58	A1-M2.XB:6	—
		59	X:59	A1-M2.XB:8	—
		60	X:60	A1-M2.XB:10	—
		61	X:61	A1-M2.XB:12	—
		62	X:62	A1-M2.XB:14	—
		63	X:63	A1-M2.XB:16	—
		64	X:64	A1-M2.XB:18	—
		65	X:65	A1-M2.XB:20	—
		66			
		67			
		68			
		69			
		70	X:70	SA1:4	—
		71	X:71	SA1:6	—
		72	X:72	SA1:8	—
		73	X:73	SA2:4	—
		74	X:74	SA3:4	—
		75	X:75	SA3:6	—
		76	X:76	SA3:8	—
		77	X:77	SA3:10	—
		78	X:78	SA3:12	—
		79	X:79	SA3:14	—
		80			
		81			
		82			
		83			
		84			
		85			
	Цепи сигнализации			X	
		86	X:86	A1-M1.XP:2	—
		87			
		88			
		89			
		90			
		91			
		92			
		93			
		94			
		95			
		96			
		97			
		98	X:98	HL1:2	—
		99			
	Цепи регистрации			X	
		100	X:100	A1-M1.XP:5	—
		101	X:101	A1-M1.XP:15	—
		102			
		103	X:103	A1-M1.XP:4	—
		104	X:104	A1-M1.XP:14	—

	Цепи освещения			X	
		105	X:105	SQ1:11	кч
		106	X:106		WE2
		107	X:107	SQ1:21	с
		108	X:108		
	Резерв/Транзит			X	
		109			
		110			
		111			
		112			
		113			
		114			
		115			
		116			
		117			
		118			