

Левая боковина (продолжение на листе 1)

	Цепи переменного напряжения (НН, СН)			X	
		49	X:49	SG9:2	+
		50	X:50	SG9:4	+
		51	X:51	SG9:6	+
		52			
	Цепи переменного напряжения (НН, СН)			X	
		53	X:53	SG10:2	+
		54	X:54	SG10:4	+
		55	X:55	SG10:6	+
		56			
	Цепи оперативного тока терминала A1			X	
+EC1		57	X:57	SQ133	—
		58	X:58	UZ1:1	+
		59			
X:310	X:60	60			
		61	X:61	A1-M5.XB:1	—
		62			
X:314	X:63	63			
		64	X:64	A1-M5.XB:3	—
		65			
		66	X:66	A1-M5.XB:5	—
		67	X:67	A1-M5.XB:7	—
		68	X:68	A1-M5.XB:9	—
		69	X:69	A1-M5.XB:11	—
		70	X:70	A1-M5.XB:13	—
		71	X:71	A1-M5.XB:15	—
		72	X:72	A1-M5.XB:17	—
		73			
		74			
		75			
		76			
		77			
		78			
		79			
		80			
-EC1		81	X:81	K1:A2	—
		82	X:82	UZ1:4	+
	Цепи оперативного тока ГЗ Т			X	
+EC2		83	X:83	KS1-X1:1	—
		84	X:84	A1-M5.XB:29	—
		85			
		86	X:86	A1-M5.XB:19	—
		87	X:87	KS1-X1:12	—
		88	X:88	KS2-X1:12	—
		89			
		90			
-EC2		91	X:91	A1-M5.XB:20	—
		92	X:92	R2:2	—
	Цепи оперативного тока ТЗ Т			X	
+EC3		93	X:93	KS3-X1:1	—
		94	X:94	A1-M6.XB:29	—
		95			
		96			
		97			
		98	X:98	A1-M6.XB:1	—
		99	X:99	KS3-X1:12	—
		100	X:100	A1-M6.XB:5	—
		101	X:101	KS4-X1:12	—
		102	X:102	A1-M6.XB:7	—
		103	X:103	A1-M6.XB:9	—
		104	X:104	A1-M6.XB:11	—
		105	X:105	A1-M6.XB:13	—
		106	X:106	A1-M6.XB:15	—
		107	X:107	A1-M6.XB:17	—
		108	X:108	A1-M6.XB:19	—
		109	X:109	A1-M6.XB:21	—
		110	X:110	A1-M6.XB:23	—

Левая боковина (продолжение на листе 3)

Правая боковина (продолжение на листе 1)

	SA2:4	X:215	215		
	SA2:6	X:216	216		
	SA3:4	X:217	217		
	SA3:6	X:218	218		
	SA3:8	X:219	219		
	SA4:4	X:220	220		
	SA4:6	X:221	221		
	SA5:4	X:222	222		
	SA5:6	X:223	223		
	SA5:8	X:224	224		
	SA6:4	X:225	225		
	SA6:6	X:226	226		
	SA7:4	X:227	227		
	SA7:6	X:228	228		
	SA7:8	X:229	229		
	SA8:4	X:230	230		
	SA8:6	X:231	231		
	SA9:4	X:232	232		
	SA9:6	X:233	233		
	SA9:8	X:234	234		
	SA10:4	X:235	235		
	SA10:6	X:236	236		
	SA10:8	X:237	237		
	SA11:4	X:238	238		
	SA12:4	X:239	239		
	SA13:4	X:240	240		
	SA14:4	X:241	241		
	SA15:4	X:242	242		
	SA15:6	X:243	243		
	SA16:4	X:244	244		
	A1-M4.XB:3	X:245	245		
	A1-M4.XB:5	X:246	246		
	A1-M4.XB:7	X:247	247		
	A1-M4.XB:9	X:248	248		
	A1-M4.XB:11	X:249	249		
	A1-M4.XB:13	X:250	250		
	A1-M4.XB:15	X:251	251		
			252		
			253		
			254		
			255		
			256		
			257		
			258		
			259		
			260		
			261		
			262		
	X	Цепи сигнализации A1			
	A1-M1.XP:2	X:263	263	—	+EH1
			264	—	
			265	—	(+)EH1
			266	—	
			267		
			268		
	A1-M1.XP:3	X:269	269	X:269	X:326
			270		
			271		
			272		
			273		
			274		
	HL12	X:275	275	—	-EH1
			276	X:276	X:333

Правая боковина (продолжение на листе 3)