

Левая доковина (продолжение на листе 2)				
		111		
		112		
		113		
		114		
		115		
		116		
-EC3		117	X:117	A1-M6.XB:30
		118	X:118	R4:2
	Цепи ЗДЗ (НН, СН)		X	
+EC4		119	X:119	A1-M7.XB:1
		120		
		121	X:121	A1-M6.XB:31
-EC4		122	X:122	A1-M7.XB:2
		123		
	Цепи ввода (НН, СН)		X	
+EC5		124	X:124	A1-M7.XB:7
		125		
		126	X:126	A1-M7.XB:3
		127	X:127	A1-M7.XB:5
-EC5		128	X:128	A1-M7.XB:4
		129		
	Цепи ЗДЗ (НН, СН)		X	
+EC6		130	X:130	A1-M7.XB:11
		131		
		132	X:132	A1-M7.XB:9
-EC6		133	X:133	A1-M7.XB:10
		134		
	Цепи ввода (НН, СН)		X	
+EC7		135	X:135	A1-M7.XB:17
		136		
		137	X:137	A1-M7.XB:13
		138	X:138	A1-M7.XB:15
-EC7		139	X:139	A1-M7.XB:14
		140		
	Цепи ЗДЗ (НН, СН)		X	
+EC8		141	X:141	A1-M7.XB:21
		142		
		143	X:143	A1-M7.XB:19
-EC8		144	X:144	A1-M7.XB:20
		145		
	Цепи ввода (НН, СН)		X	
+EC9		146	X:146	A1-M7.XB:27
		147		
		148	X:148	A1-M7.XB:23
		149	X:149	A1-M7.XB:25
-EC9		150	X:150	A1-M7.XB:24
		151		
	Цепи ЗДЗ (НН, СН)		X	
+EC10		152	X:152	A1-M7.XB:31
		153		
		154	X:154	A1-M7.XB:29
-EC10		155	X:155	A1-M7.XB:30
		156		
	Цепи ввода (НН, СН)		X	
+EC11		157	X:157	A1-M8.XB:5
		158		
		159	X:159	A1-M8.XB:1
		160	X:160	A1-M8.XB:3
-EC11		161	X:161	A1-M8.XB:2
		162		

	X	Цепи РАС А1			
	A1-M1.XP:5	X:277	277		
	A1-M1.XP:15	X:278	278		
			279		
	A1-M1.XP:4	X:280	280		
	A1-M1.XP:14	X:281	281		
	X	Цепи переменного тока А2			
	SG11:2	X:282	282		
	SG11:4	X:283	283		
	SG11:6	X:284	284		
	SG11:8	X:285	285		
	SG11:10	X:286	286		
	SG11:12	X:287	287		
			288		
			289		
	SG12:2	X:290	290		
	SG12:4	X:291	291		
	SG12:6	X:292	292		
	SG12:8	X:293	293		
	SG12:10	X:294	294		
	SG12:12	X:295	295		
			296		
			297		
	SG13:2	X:298	298		
	SG13:4	X:299	299		
	SG13:6	X:300	300		
	SG13:8	X:301	301		
	SG13:10	X:302	302		
	SG13:12	X:303	303		
			304		
			305		
	X	Цепи оперативного постоянного тока А2			
	SG13:14	X:306	306		+EC12
	UZ2:1	X:307	307		
	A2:1-X4:2	X:308	308		-EC12
	A2-M6.XB:2	X:309	309		
	X	Выходные цепи А2			
	A2-M2.XB:2	X:310	310	X:310	X:60
	A2-M2.XB:4	X:311	311		
			312		
			313		
	SA17:4	X:314	314	X:314	X:63
	SA18:4	X:315	315		
			316		
			317		
			318		
			319		
	X	Цепи сигнализации А2			
	A2-M1.XP:2	X:320	320		+EH1
			321		
			322		(+)EH1
			323		
			324		
			325		
	A2-M1.XP:3	X:326	326	X:326	X:269
			327		
			328		
			329		
			330		
			331		
			332		-EH1
			333	X:333	X:276