

Левая боковина (начало)

	Цепи переменного тока А1		Х	
	1	X-1	SG1-2	≠
	2	X-2	SG1-4	≠
	3	X-3	SG1-6	≠
	4	X-4	SG1-8	≠
	5	X-5	SG1-10	≠
	6	X-6	SG1-12	≠
	7			
	8			
	9	X-9	SG2-2	≠
	10	X-10	SG2-4	≠
	11	X-11	SG2-6	≠
	12	X-12	SG2-8	≠
	13	X-13	SG2-10	≠
	14	X-14	SG2-12	≠
	15			
	16			
	17	X-17	SG3-2	≠
	18	X-18	SG3-4	≠
	19	X-19	SG3-6	≠
	20	X-20	SG3-8	≠
	21	X-21	SG3-10	≠
	22	X-22	SG3-12	≠
	23			
	24			
	25	X-25	SG4-2	≠
	26	X-26	SG4-4	≠
	27	X-27	SG4-6	≠
	28	X-28	SG4-8	≠
	29	X-29	SG4-10	≠
	30	X-30	SG4-12	≠
	31			
	32			
	33	X-33	SG5-2	≠
	34	X-34	SG5-4	≠
	35	X-35	SG6-2	≠
	36	X-36	SG6-4	≠
	Цепи переменного напряжения НН1		Х	
	37	X-37	SG7-2	+
	38	X-38	SG7-4	+
	39	X-39	SG7-6	+
	40			
	41	X-41	SG7-10	+
	42	X-42	SG7-12	+
	Цепи переменного напряжения СН (НН2)		Х	
	43	X-43	SG8-2	+
	44	X-44	SG8-4	+
	45	X-45	SG8-6	+
	46			
	47	X-47	SG8-10	+
	48	X-48	SG8-12	+

Левая боковина (продолжение на листе 2)

Правая боковина (начало)

Х	Выходные цепи А1		
A1-M2.XB-2	X-163	163	
A1-M2.XB-4	X-164	164	
A1-M2.XB-6	X-165	165	
A1-M2.XB-8	X-166	166	
A1-M2.XB-10	X-167	167	
A1-M2.XB-12	X-168	168	
A1-M2.XB-14	X-169	169	
A1-M2.XB-16	X-170	170	
A1-M2.XB-18	X-171	171	
A1-M2.XB-20	X-172	172	
A1-M2.XB-22	X-173	173	
A1-M2.XB-24	X-174	174	
A1-M2.XB-26	X-175	175	
A1-M2.XB-28	X-176	176	
A1-M2.XB-30	X-177	177	
A1-M2.XB-32	X-178	178	
A1-M3.XB-2	X-179	179	
A1-M3.XB-4	X-180	180	
A1-M3.XB-6	X-181	181	
A1-M3.XB-8	X-182	182	
A1-M3.XB-10	X-183	183	
A1-M3.XB-12	X-184	184	
A1-M3.XB-14	X-185	185	
A1-M3.XB-16	X-186	186	
A1-M3.XB-18	X-187	187	
A1-M3.XB-20	X-188	188	
A1-M3.XB-22	X-189	189	
A1-M3.XB-24	X-190	190	
A1-M3.XB-26	X-191	191	
A1-M3.XB-28	X-192	192	
A1-M3.XB-30	X-193	193	
A1-M3.XB-32	X-194	194	
K134	X-195	195	
A1-M4.XB-4	X-196	196	
A1-M4.XB-6	X-197	197	
A1-M4.XB-8	X-198	198	
A1-M4.XB-10	X-199	199	
A1-M4.XB-12	X-200	200	
A1-M4.XB-14	X-201	201	
A1-M4.XB-16	X-202	202	
		203	
		204	
		205	
		206	
		207	
		208	
		209	
		210	
		211	
SA14	X-212	212	
SA16	X-213	213	
SA18	X-214	214	

Правая боковина (продолжение на листе 2)

Условные обозначения

